

ROTTLER

F103/4/5 SERIES HEAVY DUTY CNC MACHINING CENTER

OPERATION AND MAINTENANCE MANUAL



MANUAL SECTIONS

INTRODUCTION

INSTALLATION

SAFETY

CONTROL DEFINITIONS

OPERATING INSTRUCTIONS

MAINTENANCE

TROUBLESHOOTING

MACHINE PARTS

OPTIONS

MSDS

ORDERING PROCEDURE

Contact your regional Rottler sales rep for assistance in ordering optional equipment, replacement parts, or tooling.

If you are unable to contact your regional Rottler sales rep, call the factory at 253-872-7050 and ask to speak to the parts sales specialist.

Have the following information handy to expedite the ordering process:

1. Your name, business name, and contact number
2. Customer number
3. If you don't have a customer number, your billing address
4. Shipping address if different from billing address
5. Machine model and serial number
6. Part number and description of what you want to order
7. Preferred method of shipment
8. You may also contact us via e-mail with the above information. Send e-mail requests to:
parts@rottlermfg.com

In some cases you may be requested to send a photo of the part you are ordering if it is a replacement part, or doesn't appear in the database.

If you are unsure which part you need to order, contact our service department and ask to speak to one of our service consultants. They will assist you in determining which part you require.


THERE IS A MINIMUM ORDER OF \$25.00

INTRODUCTION

Contents

Introduction.....	1-1
Description.....	1-2
Disclaimer	1-2
Limited Warranty	1-3
Online Documentation Access.....	1-4

Introduction



READ THE SAFETY CHAPTER BEFORE INSTALLING MACHINE. THOROUGHLY UNDERSTAND ALL SAFETY ISSUES BEFORE OPERATING MACHINE.

ATTENTION OWNER/BUSINESS MANAGER

To validate the warranty on your new Rottler machine, please be sure to sign and complete the “Installation Report” located in the Installation Chapter of this manual.

We suggest that the new user of the F103/4/5A read the CONTROL DEFINITIONS to get an idea how the machine operates.

The Operating Instructions chapter should be read in order to familiarize the user with the actual button pushing sequences required to carry out a job. These chapters in the manual should be considered an introduction. As the operators of the F103/4/5A series machines gain experience with using the different functions of the machine, complicated setups and programs will make more sense.

The rest of the manual contains information and part number reference on fixtures, cutting tools, and machine maintenance. The operator should read and become familiar with these areas as well.

Description

The model F103/4/5A machine is a precision, single point boring, and high-speed surfacing unit. The machine can be equipped with tooling and accessories for surfacing and re-boring most American passenger car and truck engines, In-lines, as well as 90 and 60 degree V-types.

F103/4/5A machines can be easily tooled, to machine a wide range of engines, including European and Asian engines, also, the machine can be easily adapted to perform other boring and surfacing operations.

The machine is designed, to maintain alignment of cylinder bores, and cylinder head, deck surfaces to the pan rails and main bearing bore locations, as was done in the original factory machining. This overcomes the many inaccuracies and out-of-alignment problems associated with clamping portable boring bars to the cylinder head surface of blocks.

Convenient controls, fast block clamping, precise 3 axis CNC positioning and clamping, means considerable savings in floor to floor time, and operator involvement.

Change over or resetting time required to set up V-type or in-line engines is a minimum, making this machine highly suited to the jobber shop where engines cannot be run through in model lots.

All feeds and rapid travels are power operated and controlled from the control panel.

Disclaimer

The F103/4/5A Manual (henceforth to be referred to as the "Manual") is proprietary to Rottler Manufacturing LLC. ("Rottler Manufacturing") and no ownership rights are hereby transferred. No part of the Manual shall be used, reproduced, translated, converted, adapted, stored in a retrieval system, communicated or transmitted by any means, for any commercial purpose, including without limitation, sale, resale, license, rental or lease, without the prior express written consent of Rottler Manufacturing.

Rottler Manufacturing does not make any representations, warranties or guarantees, express or implied, as to the accuracy or completeness of the Manual. Users must be aware that updates and amendments will be made from time to time to the Manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither Rottler Manufacturing nor any of its directors, officers, employees or agents shall not be liable in any manner whatsoever to any person for any loss, damage, injury, liability, cost or expense of any nature, including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of the Manual.

Rottler Manufacturing and its employees or representatives are not responsible for any information regarding final specifications of any workpiece that is created as a final product when using Rottler equipment. It is the responsibility of the end user of Rottler equipment to determine the final dimensions and finishes of the workpiece that they are working on. Any information regarding final dimensions and finishes that appears in any Rottler literature or that is expressed by anyone representing Rottler is to be regarded as general information to help with the demonstration of or for operator training of Rottler equipment.

Limited Warranty

The model F103/4/5A machine is a precision, single point boring, and high-speed surfacing unit. The machine can be equipped with tooling and accessories for surfacing and re-boring most American passenger car and truck engines, In-lines, as well as 90 and 60 degree V-types.

F103/4/5A machines can be easily tooled, to machine a wide range of engines, including European and Asian engines, also, the machine can be easily adapted to perform other boring and surfacing operations.

The machine is designed, to maintain alignment of cylinder bores, and cylinder head, deck surfaces to the pan rails and main bearing bore locations, as was done in the original factory machining. This overcomes the many inaccuracies and out-of-alignment problems associated with clamping portable boring bars to the cylinder head surface of blocks.

Convenient controls, fast block clamping, precise 3 axis CNC positioning and clamping, means considerable savings in floor to floor time, and operator involvement.

Change over or resetting time required to set up V-type or in-line engines is a minimum, making this machine highly suited to the jobber shop where engines cannot be run through in model lots.

All feeds and rapid travels are power operated and controlled from the control panel.

Disclaimer

The F103/4/5A Manual (henceforth to be referred to as the "Manual") is proprietary to Rottler Manufacturing LLC. ("Rottler Manufacturing") and no ownership rights are hereby transferred. No part of the Manual shall be used, reproduced, translated, converted, adapted, stored in a retrieval system, communicated or transmitted by any means, for any commercial purpose, including without limitation, sale, resale, license, rental or lease, without the prior express written consent of Rottler Manufacturing.


Rottler Manufacturing does not make any representations, warranties or guarantees, express or implied, as to the accuracy or completeness of the Manual. Users must be aware that updates and amendments will be made from time to time to the Manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither Rottler Manufacturing nor any of its directors, officers, employees or agents shall not be liable in any manner whatsoever to any person for any loss, damage, injury, liability, cost or expense of any nature, including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of the Manual.

Rottler Manufacturing and its employees or representatives are not responsible for any information regarding final specifications of any workpiece that is created as a final product when using Rottler equipment. It is the responsibility of the end user of Rottler equipment to determine the final dimensions and finishes of the workpiece that they are working on. Any information regarding final dimensions and finishes that appears in any Rottler literature or that is expressed by anyone representing Rottler is to be regarded as general information to help with the demonstration of or for operator training of Rottler equipment.


Online Documentation Access

Online documentation for machines and optional equipment can be accessed at the Rottler website. To access documentation open your browser and navigate to <https://www.rottlermfg.com>.

Scroll to the bottom of the page and under the Owner Resources title click the type of documentation you want to access.



If a log in window pops up asking for user name and password fill in the blanks as shown.



This page intentionally left blank

INSTALLATION

Contents

F103/4/5 INSTALLATION PREPARATION REQUIREMENTS	2-1
F100 SERIES INSTALLATION REPORT	2-3
Removing Machine from Shipping Container.....	2-11
Installation Procedure.....	2-13
Rottler F103/4/5 Series Foundation and Hold Down Requirements	2-13
Lifting Machine with Provided Lift Eyes.....	2-14
F105A Hold Down and Jacking Bolt Locations	2-16
F105A Optional Enclosure Mounting Bolt Locations.....	2-17
F104A Hold Down / Jacking Bolt Locations.....	2-18
F103A Hold Down / Jacking Bolt Locations.....	2-19
F103A Hold Down / Jacking Bolt Locations Sunken Foundation	2-20
F104A Hold Down / Jacking Bolt Locations Sunken Foundation	2-21
F105A Hold Down / Jacking Bolt Locations Sunken Foundation	2-22
F105A Hold Down / Jacking Bolt Locations Sunken Foundation	2-23
Machine Dimensions.....	2-24
Location	2-25
Unpacking.....	2-25
Column Hold Down.....	2-25
Leveling	2-25
Air Supply.....	2-26
Power Supply.....	2-27
Grounding.....	2-27
Creating a Skype Account.....	2-28

F103/4/5 INSTALLATION PREPARATION REQUIREMENTS

1. Floor needs to be prepared with anchor bolts installed. Rottler highly recommends the Hilti system.
2. Machine needs to be set in place with a leveling pad under each leveling bolt. After setting the machine in place, check that each anchor bolt nut turns freely and that there is no damage to the anchor bolt threads.
3. Rough level the machine.
4. Electrical connection made to the machine. Provide 208-240 VAC 3 phase power. 60 amp service is required.
5. Ground rod installed and connected.
6. 6. Air supply to the machine. Minimum 100 PSI of clean, dry air.
7. Fixtures removed from the machine bed, and cleaned of rust preventative.
8. Machine cleaned of rust preventative.
9. Machine requires an Internet connection. Preferably wireless.
10. Have a scrap block available for operator training. Preferably a block commonly repaired at your facility.

ATTENTION OWNER/BUSINESS MANAGER

To validate the warranty on your new Rottler machine, please be sure to sign the installation report after the installation technician has installed the machine and verified the machine is operating correctly and given the operators operation and maintenance training.

Thank you for your cooperation and the opportunity to be of service to you.

ROTTLER MANUFACTURING



OFFICE USE ONLY
Route to: Servicer Mgr → Accounting → Andy → Accounting Warranty Exp Date

ROTTLER MANUFACTURING MUST HAVE THIS REPORT RETURNED TO PROPERLY QUALIFY WARRANTY ON EQUIPMENT

Customer: _____ Address: _____
City: _____ State: _____ Zip: _____ Phone: _____
Country: _____
Machine Model: _____ Serial Number: _____ Representative: _____

MACHINE INSTALLATION: Electrical information MUST be complete to validate this report.

_____ Customer has read and fully understands importance of machine location as explained in the installation section of the manual.

The following is the customer’s responsibility prior to the arrival of Rottler technician. Please initial each item when it is completed.

Customer must provide foundation and hold down bolt system, see following attached drawing and document “F70 and F100 Series Foundation and Hold Down Requirements”



VERY IMPORTANT: Modern design machines contain electronic low voltage circuitry that provides great advantages and a better machine life. BUT, you must have an excellent, stable, isolated power supply along with an isolated ground. If not, electrical noise problems are likely to interfere with machine operation unexpectedly.

Customer is responsible for providing electricity to machine in a manner that meets the local electrical code requirements.

- _____ Remove machine from truck. Weight: F103 14,000 lbs (6,350 kg) F104 16,000 lbs (7257 kg) F105 18,000 lbs (8165 kg) F107 45,000 lbs (20,412 kg) F109 50,000 lbs (22680 kg).
- _____ If the machine was shipped in a container follow the removal procedure in the installation section of the manual. (F103, F104, F105 only)
- _____ Remove fixturing and misc. parts from machine and clean.
- _____ Install machine on foundation with supplied jack pads under jacking bolts.
- _____ Install hold down nuts and bolts, see attached document. – This must e done first.
- _____ Rough Level the machine using a precision level so there is equal tension on all bolts.
- _____ This machine requires between 208 and 240 Volts AC, Three Phase, 50/60 Hz, isolated power supply. For voltages above 240 or below 208 VAC, a 17kva transformer will be required and is available at Rottler. Please specify voltage when ordering. Measure the incoming voltage between L1 and L2, L2 and L3, and L1 and L3. Current requirements for this machine is 60 amps. Measure the incoming AC voltage at least twice during installation.
 1. L1to L2 _____ VAC, L2 to L3 _____ VAC, L1 to L3 _____
 2. L1to L2 _____ VAC, L2 to L3 _____ VAC, L1 to L3 _____

_____ Measure each leg of the incoming supply to ground. Sometimes you may find a “high” leg to ground. When this happens make sure the high leg is running to L3.
 L1 to ground _____ VAC L2 to ground _____ VAC L3 to ground _____ VAC

**CAUTION**

Neutral and machine ground are not the same thing. You should measure an open circuit between Neutral and ground.

**CAUTION**

IF VOLTAGE IS OUTSIDE THE CORRECT RANGE AT ANY TIME THE MACHINE WILL NOT OPERATE PROPERLY AND MAY BE DAMAGED.

- _____ Air of the proper pressure and capacity connected to the machine. Air supply must be free from oil and water. Oil or water will damage electrical and air components.
- _____ Customer should attempt to have junk work piece available.
- _____ Have the operator read through the operation manual before training begins. This will help him be familiar with the button pushing sequences. Have the operator read through the manual again after training and some of the sequences will make more sense.
- _____ Have Internet connection available for the machine. Either via Ethernet cable or Wireless. The machine comes equipped with a wireless USB adapter.

The following is the Rottler technician’s responsibility

- _____ Check column top and spindle base bottom for rust and nicks if spindle must be installed. Clean and stone as required.
- _____ When lifting spindle unit, keep in mind the front to back center of gravity is located approximately 12 inches from the front end and has a tendency to lean forward.
- _____ Each main system is protected internally by circuit breakers. Green indicates the breaker is “tripped” and red indicates the breaker is “Hot” (conducting electricity).
- _____ Clean any rust inhibitor from the machine surfaces. Move the column from side to side continually cleaning the machine base until all inhibitor is removed.
- _____ Install spindle unit on column, if required, using one of the approved methods described in the operation manual. (Spindle unit weighs 6,000 lbs, 2,800 Kgs.)

Using fork lift angle iron brackets

- _____ Bolt brackets to each side of the spindle base.
- _____ Use large C-clamps to clamp the fork lift forks to the angle iron brackets. This will prevent any accidental slips. Loosen 1/2 13 x 3 1/2 Inch bolts on pendent arm to allow it to be moved out of the way.
- _____ Use a forklift to lift the spindle unit onto the column. Be careful to watch clearance of all items.
- _____ Install the Right (Fixed Side Rail) and removable dowel pins. Torque Side Rail bolts to 80 Ft/lbs.
- _____ Lift spindle unit into place. Push spindle base up against Right Side Rail.
- _____ Install left side rail (9202A) with 2 Belleville’s (9024E) opposing each other () on each set screw (9202D), torque side rail bolts to 80 Ft/lbs.
- _____ Adjust the adjustable screws (9202D) on SIDE rails by tightening them until they bottom out, then unscrewing them 1/8 turn.
- _____ Measure the protrusion of the Sides Rails above the spindle base and record.
 Right: Front _____ Rear _____
 Left Front _____ Rear _____
- _____ Install the Right and Left Top Rails.
- _____ Install top rails (9202B) with 2 Belleville’s opposing each other () on each adjustable set screw (9202D). Torque to 80 lbs.

- _____ Adjust the adjustable screws (9202D) on TOP rails by tightening them until they bottom out, then unscrewing them 3/4 turn.
- _____ Remove angle iron brackets from spindle base.
- _____ Connect air and oil lines per air logic diagram.
- _____ Remind customer of the proper air pressure and capacity connected to the machine. Air supply must be free from oil and water. Oil or water will damage electrical and air components.
- _____ Connect electrical wires in main rear enclosure if required using machine wiring diagram.

MACHINE START-UP



When starting the machine for the first time, it may move out of control. Make sure all hands are clear of machine parts. Be ready to press the Emergency Stop button if needed.

- _____ **BEFORE** turning power on to the machine. Check all wires for security by using the correct screw driver and turning CW until movement stops. Stranded wire can “spread” slightly from vibration during transport.
- _____ Install electrical component covers inside the electrical enclosure with fasteners provided.
- _____ Turn main power on at the main disconnect switch located on the rear enclosure.
- _____ If machine moves out of control, turn power off and contact factory for help in trouble shooting.
- _____ If any of the circuit breakers “trip”, reset and call factory for possible trouble shooting.
- _____ Install and test the Internet connection to the machine. DO NOT download any updates unless instructed to do so by Rottler.
- _____ Check the computer control options and make sure that you turn on z-axis bit 2 and spindle bit 3.

MACHINE MOVEMENTS

- _____ Make sure there is nothing obstructing the full vertical, horizontal or In/Out travel of the machine taking special notice of the rear enclosure, way travel and top of the spindle unit.
- _____ Put the machine in hand wheel mode and verify Vertical operation. Put an indicator on the cutter head and verify .001” movement per detent in course mode and .0001” in fine mode. If the indicator is jumpy the outer spindle adjustment may be too tight. Refer to manual and re-adjust.
- _____ Put the machine in hand wheel mode and verify Horizontal operation. Put an indicator on the cutter head and verify .001” movement per detent in course mode and .0001” in fine mode
- _____ Use the rapid buttons and verify proper vertical, horizontal and In/out travel.
- _____ Check limit switch operation with handwheel before using the power feed.
- _____ Move the machine to its vertical limits to verify proper operation.
- _____ Move the machine to its horizontal limits to verify proper operation.
- _____ Move the machine to its In/Out limits to verify proper operation.
- _____ Start the spindle and verify operation at all speeds.
- _____ Use the spindle creep buttons and verify proper operation.
- _____ Prime the oiling system. (See maintenance section of manual for complete details.)
- _____ Use a precision level and level the machine:

Record machine level readings below (must be within .0005). Back Way:

Back Way:

P1 _____ P2 _____ P3 _____ P4 _____ P5 _____ P6 _____ P7 _____ P8 _____

Back to Front Way:

P1 _____ P2 _____ P3 _____ P4 _____ P5 _____ P6 _____ P7 _____ P8 _____

Record Dial Indicator readings:

Spindle to Back Table:

P1 _____ P2 _____ P3 _____ P4 _____ P5 _____ P6 _____ P7 _____ P8 _____

Spindle to Front Table:

P1 _____ P2 _____ P3 _____ P4 _____ P5 _____ P6 _____ P7 _____ P8 _____

_____ Check mill tilt, and lift amounts with Y axis in the middle of travel, and record
Amount of tilt _____ Amount of tilt _____
(See Section 6 of the manual for specification)

The following procedures should be shown to personal involved in machine maintenance.

See maintenance section of manual for complete details. Video of procedure can be viewed at:

www.rottlertube.com

_____ Check, and adjust X axis gibs Should be .0002-.0005 (see maintenance for further instructions.)

_____ Adjust outer spindle bushings.

_____ Adjust inner spindle bearings

_____ Perform spindle sweep adjustment.

_____ Verify ALL axis backlash comp is operating properly, adjust if needed. Record actual readings after verification.

	Auto	Handwheel
X-Axis	_____	_____
Y-Axis	_____	_____
Z-Axis	_____	_____

_____ Install way cover brackets and way covers. Way Cover support brackets should be flush with way surface.

INSTRUCTING THE OPERATOR

Note: Rotter employees and representatives per company policy are not permitted to provide end user of Rottler equipment with any OEM specifications for the workpiece that is created by end user using Rottler equipment.

WARNING

_____ Explain to the customer and operator that at NO time is there to be any software or hardware other than Windows Auto Update and Rottler installed on this machine. This includes screen savers, anti-virus software, and any hardware device that installs software on the machine. Installation of screen savers and anti-virus software can cause dangerous control problems. Any installation of software or hardware will void the warranty on the machine.

_____ Explain to the customer and operator that the machine should be hooked up to the Internet anytime it is on. The software on the machine will automatically connect to our server to send back useful information on machine status.

_____ Connect customer supplied Internet to the machine. Verify that the Internet is accessible from the machine.

_____ Once the machine has been fully setup and is ready for operation create a Skype account for the machine following the instructions in the Installation Section of the manual.

_____ Explain to the customer and the operator how the to log onto Skype and communicate with Rottler when needed.

⚠ WARNING

_____ Computer Viruses will cause the machine control system to become unstable. This may cause the machine to make uncontrolled moves which could create a dangerous environment for the machine operator.

IMPORTANT

_____ Refer to Chapter 4, Control Definitions of the Machine Manual, Section: Computer and Controller System Safety. Explain and discuss this section carefully with Owner/Manager/Operator and have them sign off. Failure to do so will result in the machine warranty being Null and Void.

Signature / Title

_____ Explain to the customer the importance of backing up the block profiles to a separate device. Any computer failure or possible operator input error can result in the loss of all block profiles that were created for the machine. Refer to Chapter 5 of the machine manual for detailed instructions on backing up and restoring block profiles.

_____ Explain to the customer the proper way to turn the machine off when it is not in use. Do not leave the machine on overnight. It is important to close all programs followed by shutting down Windows before turning the main power switch off. Do not turn the main power switch off before shutting down Windows.

_____ Using the operating manual as a guide explain the function of all buttons.

_____ Cycle all machine movements and supervise the handling of same by operator.

_____ Demonstrate the differences of Manual and Auto operation.

_____ Fully explain the entire Auto Cycle from Centering to Auto Retract.

_____ Explain machine parameters and error messages. It is very important that the customer does not change parameter settings without first checking with Rottler Manufacturing. If certain parameters are changed the machine may make uncontrolled moves or not operate at all.

_____ Point out safety features to customer and operator. Do not push any buttons without thinking of safety first.

⚠ CAUTION

Do not assume the cutterhead micrometer has been calibrated.

_____ Install a work piece in the machine and perform an undersize test bore to qualify the micrometer setting to the customers measuring tools.

Note adjustments: + _____, - _____.

_____ Explain precision reset of tool in cutterhead.

_____ The following is a checklist to go through every time the machine is started to begin a cut or automatic cycle.

- Work piece secure
- RPM set
- Feed Rate set
- Correct program in use
- Program oriented correctly (vertical zero at correct place) Centering range adequate
- Guards in place
- Cutterhead secure
- Tool holder adjusted to the correct size
- Tool holder locked in place

_____ Proceed to have operator bore block to size.

- _____ Demonstrate and explain boring with the electronic hand wheel.
- _____ Explain the correct Feed rates and speeds from Cutting Insert Bulletin.
- _____ Cutter head change and expected stub bar performance.
- _____ Parts ordering, refer the to the operating manual for part numbers and description.
- _____ Offset tool bits, calibration of micrometer and anvil setting.
- _____ Train on ALL Rottler programs even if they need to be run in the air.
- _____ If Rottler CAM was provided to the customer train on any programs supplied by Rottler.
- _____ Review Emergency stop procedure with operator per operating manual.

MAINTENANCE SECTION

- _____ Use the manual as a reference when explaining routine maintenance and lubrication.
- _____ Overload devices, There are no mechanical overload devices on this machine. The machine is protected from overload by the motor controllers. If the system is overloaded the controllers shut the motors off. The controllers can be reset by turning the main power off for at least 1 minute, then turning it back on.
- _____ Explain again the proper Inner and Outer spindle adjustment to the operator.
- _____ Dampener cleaning.
- _____ Micrometer and anvil thread adjustment.
- _____ Inspection of tool bit hole in tool holders (deformation due to accidental impact).

Rottler Manufacturing and its employees or representatives are not responsible for any information regarding final specifications of any workpiece that is created as a final product when using Rottler equipment. It is the responsibility of the end user of Rottler equipment to determine the final dimensions and finishes of the workpiece that they are working on. Any information regarding final dimensions and finishes that appears in any Rottler literature or that is expressed by anyone representing Rottler is to be regarded as general information to help with the demonstration of or for operator training of Rottler equipment.

Note: Rotter employees and representatives per company policy are not permitted to provide end user of Rottler equipment with any OEM specifications for the workpiece that is created by end user using Rottler equipment.

General remarks on machine performance, adjustments as received and any further organization or parts required to complete the installation.

Instructions given to: _____

Sales/Service Engineer: _____ Date _____

Shop Foreman/Superintendent or Owner: _____ Date _____

**Once completed send this form to:
Rottler Manufacturing
attn: Service Manager
8029 S 200 St
Kent, WA 98032 USA**

**Alternately you may send this form via fax or e-mail:
fax: [+1] 253-395-0230
e-mail: service@rottermfg.com**

This page intentionally left blank

Removing Machine from Shipping Container

All F100 machines that are shipped in a container must be unloaded using the following method.

Machines will be loaded into containers at the factory mounted on metal tubes. These tubes will facilitate the sliding of the machine out of the container.

If the machine is to be removed from the container for transfer to its final destination the seal must not be broken.

Use lifting straps or chains placed through the tubes to pull the machine from the container. Make certain that the machine is clear of the container before attempting to lift machine.

The photo below shows the machine packed and sealed for placement into a container.



The photos below show the tubes that the machine sits on. Place straps or chains through these tubes to pull the machine out of the container. Take care not to damage the threads of the bolts holding the tubes to the machine.



Using an alternative method to remove the machine from the container that results in damage to the foil packaging seal or to the machine itself could result in the warranty being voided.

Installation Procedure

Rottler F103/4/5 Series Foundation and Hold Down Requirements

Rottler machines require a good concrete foundation and hold down system. It is not recommended to install a machine on a cracked floor or over an expansion joint. The layout/position of the hold down holes can be found on the foundation drawings below.

There are two methods commonly used by customers:

1. Drill the concrete floor as per drawing layout before arrival of machine.
2. Place machine, mark floor through holes in machine base, move machine away then drill the floor.

The machine is provided with jacking bolts and steel pads to place between the jacking bolts and floor. For shipping, the steel pads are packed in a separate box and marked with yellow/black tape so the box is clearly visible. This allows the machine to be unpacked and removed from the shipping crate, placed on the floor on these steel pads without opening the accessory crates. When placing the machine on the jacking bolts, ALWAYS rough level to be sure that the weight of the machine is evenly distributed over all the jacking bolts.

Rottler recommend Hilti products as per attached list. 3/4" (20mm) diameter X 12" (300mm) long studs are recommended. Drill floor approx 7" (180mm) deep with 1" (25mm) drill. As it is difficult to drill concrete exactly on center, it is recommended to drill a pilot hole. After drilling and before injecting epoxy, it is also recommended to move the machine into place and make sure all studs fit through the holes in the base and travel all the way down into the holes so that approx 5" (130mm) protrude out of the floor. The machine may have to be moved a small amount to allow all studs to fit. Once this is checked, the studs can be removed then the epoxy injected into the bottom of the holes. Make sure all dust is vacuumed out of the holes before the epoxy is injected. Ensure that the epoxy is injected starting at the bottom of the holes to be sure the stud has maximum contact with the epoxy. The size of the holes will determine how much epoxy to inject into the holes before fitting the studs. On average, 1/2 to 2/3 of the hole should be filled with epoxy before the stud is installed. Be sure when the stud is installed, that the epoxy fills the hole to the top. Fit the washer and nut and tighten lightly to align the stud then allow the epoxy 24 hours to harden ready for leveling and final anchoring.

The column is tied down with chains for transport, if it is required to move the column to help with installation of the hold down system, the column tie downs can be removed and manually turn the horizontal ball screw nut by hand to move the column sideways. Be sure that the rails are clean and lubed under the column before moving.

The following is a **MINIMUM** recommendation for safe reliable operation.

4000 PSI concrete

Slab thickness of 12" (30cm)

Any slab that is thinner than this may require monitoring of levelness of the machine.

Lifting Machine with Provided Lift Eyes




Lifting a machine using the following method is a dangerous and demanding procedure. Therefore Rottler recommends that the customer hire a licensed and bonded material handling specialists. Rottler will not be held liable for and consequences resulting from mishandling of the machine using this method.


Observe the following precautions:

1. Check the machine invoice to see what the shipping weight was and be certain that the hoists to be used ratings exceed that weight.
2. Be certain that all rigging used is rated for the weight that will be lifted.
3. Check lift eyes for damage and for secure attachment.
4. Nylon straps are preferred over cable and chain in order to prevent damage to machine.







F105A Hold Down and Jacking Bolt Locations




F105A Optional Enclosure Mounting Bolt Locations




F104A Hold Down / Jacking Bolt Locations




F104A Hold Down / Jacking Bolt Locations Sunken Foundation



F105A Hold Down / Jacking Bolt Locations Sunken Foundation




F105A Hold Down / Jacking Bolt Locations Sunken Foundation



Machine Dimensions

Left Side View



**IMPORTANT! Placement of Machine**

It is critical that the machine be placed in an area of the facility that has a stable thermal environment. The machine should be kept away from direct sunlight, large heating units, and doorways that would allow outside air direct contact on the machine.

Exposure to the above and other extremes in temperature will cause thermal drift to occur in the machines which could have a detrimental effect on machining accuracy. A number of unrepeatability errors in machine performance have been linked to this condition.

Location

The productivity of this machine will depend a great deal on its proper initial installation. Pay particular attention to the means by which work pieces are lifted into the machine as well as the material handling to and from other operations in your shop.

The proper loading arrangement and area location for your F103/4/5A machine is extremely important.

A slow travel (6' to 10' per minute) power hoist, operated from either a bridge crane or a jib crane arrangement works very well. Verify the hoist has a rating that exceeds the load being lifted.

For the shop where large production runs are anticipated, the work pieces should be directly loaded and unloaded from a conveyor. If this is not the case we recommend considerable attention be given to the crane so that it covers an adequate area, to allow the operator to back up and remove work pieces without creating a dangerous, cluttered work area.

Unpacking

Use care in removing the crate materials from the machine. Be careful not to use force on any part of the machine.

Remove the toolbox, parallels and optional equipment from the machine. Completely clean these articles as well as the rest of the machine with solvent. Rust inhibitor was applied, at the time of shipment. Any of this left on the machine, will allow cast iron dust to collect in that area, which could cause premature wear.

Column Hold Down

The machine was shipped with the column held in place with chains and turnbuckles to the Main bed. Do not attempt to move the machine under power until these restraints have been removed.

Leveling

Located in the bottom of the main base are the leveling and tie down screws. If care is taken, the main base can be leveled extremely accurately. Start by placing the jacking pads under the jacking screws. Adjust the jacking screws so the lowest point of the main base is at least 1/4" off the jacking pad. Make sure all the jacking screws are touching their jacking pads. Use a precision machinist's level, and check the base at several points to get an idea where the high and low spots are, adjust evenly where necessary. Start with the back way surface. With your precision level, level the back way in the lengthwise direction to .0005" per foot. Take the readings approximately mid way between the jacking points.

Use a precision metal support to span the distance between the front and rear parallels. (Support must be parallel within .0005" in its length). Take readings over every jacking bolt and level within .0005" over the length of the base. Be sure to use the jacking points down the middle of the main base.


Recheck the way surfaces for level. Now check the machine table. Using the front jacking screws level the table within .0005" in both directions.

Be sure that all jacking bolts have approximately equal weight on them. As you go leveling the base snug the tie down bolts to help hold the main base in place. Recheck all areas of the main base for level.

Air Supply

It is very important the air source for the F103/4/5A machine be moisture free. Water and oil in the line will result in early cylinder and valve failure. The factory recommends installing a water trap at the machine.

Attach a 100 PSI air source to the appropriate intake in the small enclosure located on the left rear of the machine near the bottom.



Power Supply

This machine has the following power requirements:


- 208 to 240 VAC
- Three Phase
- 50 or 60 Hertz
- 60 amps

See illustration below for correct connection of “measured” incoming power. Connect three phase wiring to the electrical box located on the back of the machine in the lower right hand corner. See illustration below. If a “high leg” exists, this must be at Line 3. All ground wires go to ground block. Important:

Note: For voltages over 240 VAC (380 – 440 VAC) a transformer needs to be installed with the machine.

Grounding


This machine must be connected to a good earth ground rod. A 6 foot, 1/2” diameter, 15 OHM, Copper grounding rod driven into the earth next to the machines is preferred. **Not providing a grounding rod could void factory warranty.**




IMPORTANT

Electrically connect in accordance with national and local electrical codes.


Creating a Skype Account




Click on create an account



Click on: Use your email instead



Click on: Get new email address




Name the email account using the Rottler machine Model and Serial number.

Ex: H85A111, EM69P001

Create a password that is easy to remember.


Uncheck the box to receive emails from Microsoft.



First Name: Model-Serial Number

Ex: F105A-113

Last Name: RottlerMfg




Select your Country/region

Birthday: Today's date, year 1992




Type the code exactly as it appears.

Click "Next"




Click "Continue"



If your headset and/or web camera are hooked up you can verify that they are working here.

Otherwise, click "Continue"



Click "Add later" to skip this part.

Your Skype account is set up and ready for use.

This page intentionally left blank


SAFETY

Contents

Safety Information	3-1
Safety Instructions for Machine Use	3-1
Electrical Power	3-3
Machine Operator	3-5
Emergency Procedure	3-6
Computer and Controller System Safety	3-6
Electrical Safety Features Of Rottler DM Controlled Machines	3-7

Safety Information

For Your Own Safety Read This Instruction Manual Before Operating This Machine.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in serious injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

Safety Instructions for Machine Use



This machine is capable of causing severe bodily injury

ONLY A QUALIFIED, EXPERIENCED OPERATOR SHOULD OPERATE THIS MACHINE. NEVER ALLOW UNSUPERVISED OR UNTRAINED PERSONNEL TO OPERATE THE MACHINE. Make sure any instructions you give in regards to machine operation are approved, correct, safe, and clearly understood. Untrained personnel present a hazard to themselves and the machine. Improper operation will void the warranty.

KEEP GUARDS IN PLACE and in proper working order. If equipped with doors, they must be in the closed position when the machine is in operation.



KEEP WORK AREA CLEAN. Cluttered areas and benches invite accidents.

KEEP CHILDREN AND VISITORS AWAY. All children and visitors should be kept a safe distance from work area.

WEAR THE PROPER APPAREL. **DO NOT** wear loose clothing, gloves, rings, bracelets, or other jewelry which may get caught in moving parts. Non-Slip foot wear is recommended. Wear protective hair covering to contain long hair.

ALWAYS USE SAFETY GLASSES. Also use face or dust mask if cutting operation is dusty. Everyday eye glasses only have impact resistant lenses, they are NOT safety glasses.



DO NOT OVER-REACH. Keep proper footing and balance at all times.

USE THE RECOMMENDED ACCESSORIES. Consult the manual for recommended accessories. The use of improper accessories may cause risk of injury.

CHECK DAMAGED PARTS. Before further use of the machine, a guard or other part that is damaged should be checked to determine that it will operate properly and perform its intended function. Check for alignment of moving parts, breakage of parts, mounting, and other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced.

NEVER OPERATE A MACHINE WHEN TIRED, OR UNDER THE INFLUENCE OF DRUGS OR ALCOHOL. Full mental alertness is required at all times when running a machine.

IF AT ANY TIME YOU ARE EXPERIENCING DIFFICULTIES performing the intended operation, stop using the machine! Then contact our service department or ask a qualified expert how the operation should be performed.

DO NOT MODIFY OR ALTER THIS EQUIPMENT in any way. If modifications are deemed necessary, all such requests must be approved and/or handled by Rottler Manufacturing. Unauthorized modifications could cause injury and/or damage to machine and will void the warranty.

SAFETY DECALS SHOULD NEVER BE REMOVED. They are there to convey important safety information and warn of potential hazards.

ALL LOCAL SAFETY CODES AND REGULATIONS should be followed when installing this machine.

ONLY QUALIFIED PERSONAL should perform service on the electrical and control systems.


When boring the machine is capable of throwing metal chips over 10- feet from the cutting area. Always use the guards. Eye protection must be worn at all times by the operator and all other personnel in the area of the machine.




CAUTION No list of safety guidelines can be complete. Every piece of shop environment is different. Always consider safety first, as it applies to your individual working conditions. Use this and other machinery with caution and respect. Failure to follow guidelines could result in serious personal injury, damage to equipment or poor work results.

Electrical Power

THIS MACHINE IS AUTOMATICALLY CONTROLLED AND MAY START AT ANYTIME




All electrical power should be removed from the machine before opening the rear electrical enclosure.



In the event of an electrical short, grounding reduces the risk of electric shock by providing a path of least resistance to disperse electric current.

Electrocution or a fire can result if the machine is not grounded correctly. Make sure the ground is connected in accordance with this manual. **DO NOT** operate the machine if it is not grounded.



CAUTION No single list of electrical guidelines can be comprehensive for all shop environments. Operating this machinery may require additional electrical upgrades specific to your shop environment. It is your responsibility to make sure your electrical system comply with all local codes and ordinances.

WARNING This machine operates under computerized control and, as is all computerized equipment, and is susceptible to extraneous electrical impulses internally for externally produced. The machine may make moves out of the operator control at any time. The operator should work in and around the machine with caution at all times.

The operator and nearby personnel should be familiar with the location and operation of the Emergency Stop Button.

Make sure all electrical equipment has the proper overload protection. ***This machine should have a fully isolated power supply*** to prevent damage and uncontrolled movement of the machine. If this machine is on the same power lines that are running to other electrical equipment (grinders, welders, and other AC motors) electrical noise can be induced into this machines electrical system. Electrical noise can cause the controller to see false signals to move. Not supplying a fully isolated supply to the machine may void factory warranty. Refer to the Power supply section located in the Installation section for voltage and


Machine Operator

The operator of this machine should be a skilled machinist craftsman who is well versed in the caution, care, and knowledge required to safely operate metal cutting tools.

If the operator is not a skilled machinist he/she must pay strict attention to the Operating Instructions outlined in this manual, and get instruction from a qualified machinist in both production and operation of this machine.

This machine has the following areas of exposed moving parts that you must train yourself to respect and stay away from when they are in motion:

Cutting Tool Area – Any operation involving hands in the cutter head area, such as inspection or alignment of the cutter head or tools, changing Centering Fingers, tool insertion, and removal, cutter head changes, and size checking etc. requires the machine to be in Neutral.



Machining – Eye protection must be worn during all operations of the machine. Hands must be kept completely away from the cutter head. All chip guards must be in position during machine operations.



CAUTION **Work Loading and Unloading** – Carefully develop handling methods of loading and unloading work pieces so that no injury can result if hoist equipment or lift connection should fail. Periodically check lift components for damage that may cause failure.

CAUTION **Machine Maintenance** – Any machine adjustment, maintenance or parts replacement absolutely requires a complete power disconnection from the machine.

Emergency Procedure

Assuming one of the following has occurred: tool bit set completely off size, work piece or spindle base not clamped, spindle is not properly centered, and these mistakes will become obvious the minute the cut starts

PRESS THE EMERGENCY STOP BUTTON (on the front control panel) **IMMEDIATELY!**

Find out what the problem is; return the spindle to its up position without causing more damage. To restart the machine, turn the Emergency Stop Button CW until the button pops out

Be alert to quickly stop the machine in the event of a serious disruption of the boring process either at the top or bottom of the bores.

“REMEMBER” metal cutting tools have the speed and torque to severely injure any part of the human body exposed to them.

Computer and Controller System Safety

The computer and controller are located in the main rear electrical enclosure. This unit is a full computer, running Windows 7 64 Bit operating system. Contact the factory if more information on the computer system is required.

IMPORTANT The computer in this machine has the ability to connect to the World Wide Web via Ethernet or Wireless using a USB wireless (Wi-Fi) adapter. Updating the Rottler software should **ONLY** be done when directed to do so by a Rottler service technician. Updating Rottler Software when not directed by Rottler personnel will result in a non-operational machine.

The machine should be hooked up to the Internet anytime it is on. The software on the machine will automatically connect to our server to send back useful information on machine status.

Any “IT” personnel should **ALWAYS** get approval from Rottler before doing ANYTHING on the computer.

! DANGER This machine is capable of causing severe injury or death. Doing any of the following without Rottler’s direct consent may cause severe injury or death.

! WARNING Do not attempt to install USB devices in the PCI ports. These ports have high voltage and any attempt to connect a USB device in these ports will result in destruction of that device. There is also the possibility of damage to the computer system of the machine.



IMPORTANT Downloading any program or changing any Rottler or Computer settings may cause the machine and/or software to become unstable. **DO NOT** install ANY screen saver, Anti-Virus, Spyware or any type of Security software on the computer. This could create a hazardous environment for the operator and personnel around the machine. Performing any of the above will also result in the machine warranty being NULL and VOID.

IMPORTANT **DO NOT** connect any type of external hardware to the computer via USB or any other means. Do not install any type of Device Driver. This could create a hazardous environment for the operator and personnel around the machine. Performing any of the above will also result in the machine warranty being NULL and VOID.

Electrical Safety Features Of Rottler DM Controlled Machines

All Rottler machines that use the DM operational control system are designed to comply with all applicable safety standards. This includes but is not limited to the following systems:

Thermal sensors in all motors and motor controls.

1. Current sensors in all motor control panels.
2. Electrical breakers to prevent voltage surges and spikes from reaching electrical system.
3. Electrical lockout on main electrical enclosure.
4. E-Stop that shuts down all operational systems in an event of an emergency.

All thermal and current limits for motors and motor controls are preset at the factory. In the event that any of those parameters are exceeded during operation of the machine, the machine control system will shut down the machine and a warning of the specific fault will appear on the control screen.

CONTROL DEFINITIONS

Contents

Control Definitions	4-1
Computer and Controller System Safety for DM Controlled Machines.....	4-1
Master Power On/Off Switch.....	4-2
Initialization Screen.....	4-3
General Information	4-3
Home.....	4-3
Program Select	4-3
New.....	4-4
Options	4-4
Delete	4-4
Mode Select.....	4-5
New.....	4-5
Std (Standard) Setup	4-6
Options	4-6
Delete	4-7
Basic Machine Controls.....	4-7
Cylinder Bore, General Bore 3 Axis (without Tool Changer).....	4-8
Set Zero Tab.....	4-8
Actual Position	4-8
Velocity Override.....	4-8
Zero Buttons.....	4-8
Handwheel Buttons	4-9
Spindle Start.....	4-9
CW and CCW Creep.....	4-9
Jog Buttons	4-9
Move to	4-9
Move To Zeros	4-9
CW and CCW Index.....	4-9
Using SSV (Spindle Speed Variance).....	4-10
Setting Spindle Index	4-10

Probe Auto Center	4-10
Vertical Stops Tab	4-11
Horizontal Offset for Honing.....	4-12
Left and Right Locations Tab	4-13
Cylinder Bore – Bore Locations	4-13
Blueprint	4-13
Move Buttons	4-13
Bore Buttons	4-14
Indicated	4-14
Set Buttons	4-14
Copy Values.....	4-14
Difference	4-14
Bore Left and Right.....	4-14
Probing	4-15
Probe Buttons	4-15
Probe Left or Right	4-15
Probed Diameter	4-15
LOWER SLEEVE REPAIR	4-15
Block Clearance	4-15
Centering Height	4-16
X-Clearance	4-16
180 index (check box)	4-16
X-Overshoot	4-16
Start Boring Height	4-16
Bottom of the Bore	4-17
Stop and Index Spindle after Cycle.....	4-17
Probing For The Mill Cycle	4-18
Lifter Bore	4-20
Cylinder Bore 4 Axis	4-20
Set Zero Tab.....	4-20
Jog Controls	4-20
4th Axis Degree and Move	4-20
4th axis Brake.....	4-21
Light Clamp	4-21
Full Clamp.....	4-21
Retract.....	4-21
Table Of Tools	4-22

Table Of Tools General Information4-22
Accessing Table Of Tools.....4-22
Add Tool.....4-23
Remove Tool.....4-24
Set Active Tool4-24
Setting Tool Offsets..... 4-25
Z Location from Zero4-26
Z Touch Off Height.....4-26
Add Tool Radius?.....4-26
Applying Table of Tools to Rottler Programs4-27
Fixture Select4-27

Control Definitions

The purpose of this chapter is to define the function of the buttons throughout the various screens. Certain button functions may not make sense right away in this chapter. As the operator reads through the Operating Instructions chapter of this manual, the function of these buttons will become clear.

Computer and Controller System Safety for DM Controlled Machines

The computer and controller are located in the main rear electrical enclosure. This unit is a full computer, running Windows operating system. Contact the factory if more information on the computer system is required.

IMPORTANT: The computer in this machine has the ability to connect to the World Wide Web via Ethernet or Wireless using a USB wireless (Wi-Fi) adapter. Updating the Rottler software should ONLY be done when directed to do so by a Rottler service technician. Updating Rottler Software when not directed by Rottler personnel could result in a non-operational machine.

It is recommended that the machine be hooked up to the Internet anytime it is on. The software on the machine will automatically connect to our server to send back useful information on machine status. It will also record performance parameters that will be used to evaluate any occurrence of a malfunction.

The Auto Update for the Windows Firewall (Security) and Windows Defender (Anti-Virus) is turned on. The computer will automatically download the updates and then install them when the computer is shut down every Friday night.

Any "IT" personnel should ALWAYS get approval from Rottler before doing ANYTHING on the computer.



Downloading ANY program from the Internet or by other means when not directed by Rottler is prohibited and will result in the machine warranty being NULL and VOID.



Downloading any program or changing any Rottler or Computer settings may cause the machine and/or software to become unstable. DO NOT install ANY screen saver, Anti-Virus, Spyware or any type of Security software on the computer. This could create a hazardous environment for the operator and personnel around the machine. Performing any of the above will also result in the machine warranty being NULL and VOID.

Master Power On/Off Switch

This switch is located on the main electrical control enclosure on the right hand side of the machine.

When first applying power to the machine the computer will need to boot up. Be patient, it will take several minutes to complete booting. The Rottler program will not automatically start. Double tap the Rottler_WPF icon on the screen to start Rottler.

When turning the main power to the machine off there is a specific procedure to follow so as not to damage the computer. The computer must shut down its internal systems before main power is removed from it.


Press the “Start” button in the left-hand side of the Start Bar. This will bring up the “Start Menu”. Press the “Shutdown” line at the bottom of the Start Menu. This will bring up a Pop Up menu, make sure that “shut down computer” is selected and press “OK”.

This will shut down the computer. It is now OK to turn Main Power off to the machine.

Initialization Screen

When the F103/4/5A is powered up the Rottler program will not automatically start. It may take several minutes for the computer to power. Start the Rottler program by double tapping the Rottler_WPF icon on the desktop. Once the program is started, the Rottler Program Select will appear.

NOTE: Do not push any buttons or icons on the screen before the Rottler program starts or an error may be caused on the computer.



General Information

The Rottler software operates on a Block Model format. You select or create the block you are working with. Then select or create an operation to be performed on that block.

Home

Pressing this button will cause the machine to run a self check on the electronics. The machine MUST be homed after it is turned on.

Program Select

This is the left section of the screen. This is where you create and select blocks you will be working with.

New

Pressing this in the Upper level will cause a dialog box to appear. Here is where you name and configure the block, the number of cylinders and Inline or V Block.

New Block Options Window

Block Name: Default Block

Number of Cylinders: 8

of intake valves per cylinder: 1

of exhaust valves per cylinder: 1

VBlock

Share Vertical Zero in Group

Share All Values in Groups

OK Cancel

Pressing OK will result in the Block Model being inserted into the left hand side of the screen.

Rottler Block Boring

Program: Test

Mode: General Bore

Continuous DTG: 0.000 Z 0.000 Y 0.000

Feedrate override: 1.00 X 0.000 A 0.000

CHANGE TOOL Home FIXTURE SELECT TABLE OF TOOLS

Setup Software Setup Electronics Help

PROGRAM SELECT

Mode Select

Select New Std Setup

Options Delete

Name	# Cyls	Config
Chev 350	8	VBlock

E-STOP IN

Options

This will bring up the same dialog box as described above if any of the information needs to be changed.

Delete

This will delete whatever block program is selected. A dialog box will appear to ask you if you want that program deleted.


Mode Select

This is the right section of the screen. This is where you create or select operations to be performed on the selected Block. This area will be blank when you first create a block.

You can create only certain modes you will use on a block or use a standard set up that inserts all modes available. You can also create a new mode and rename it for a specific use.

New

Pressing this button will bring up a dialog box with Rottler standard operations.




Select the operation you want to create and then press OK. This will place a general Bore operation under the Cylinder bore mode in the right hand section.



To enter General Bore mode highlight it and then press Select. This will take you to the operation screens that will be described later.

Std (Standard) Setup


Pressing this button will insert all the Rottler operations into the right hand section automatically.



Use the slide bar on the right hand side to scroll through all the operations.

Options

Press this button to bring up a dialog box to allow positive numbers to be entered in the horizontal stops. Most all programs are from left to right, the farther right you go the larger the negative number. However if a different zero point is used a positive number may be needed. For example, if you zero on the first cylinder on the left bank of a block and then "roll it over" the first cylinder is farther to the right than the zero position. Which would be a positive number.



Delete

This will delete the selected Mode. It will ask you if you want this mode deleted before deleting it.

NOTE: Once the control definition for a particular button has been discussed it will not be repeated in the different modes of operation. Only new buttons or buttons with a different function will be discussed in different modes.

For these descriptions the Tool# and Probe # are not being used. They will be described later in this chapter.

Basic Machine Controls

Actual Position

Fixture	
X	0.0000
Y	0.0000
Z	0.0000

Shows the linear position of the axis

SPINDLE 36.04 **Shows the Position of the spindle in 0-360°**

Double click to zero the axis

Click to move handwheel

Handwheel: 0.010, 0.001, 0.0001

Move To

Click to move to a position, a box that lets you enter the position will pop up

Notes

0.0HP Drive 70F: **Tool #:0**

Click to select the correct tool


0.0HP Drive 70F: **Set Active**

Used for ATC and setting proper tool offsets

Cylinder Bore, General Bore 3 Axis (without Tool Changer)

Each buttons function will be described in this section. In the different MODES, the same buttons will not be described again.

Set Zero Tab



Actual Position

These are a numerical display showing the actual distance the axis are away from where they have been zeroed.

Velocity Override

The Velocity override is displayed in the upper left of the Actual Position display. The default is 100% of the programmed Feed Rate. When operating... turning the handwheel Counter Clockwise will override the axis rapid travel and feed rate 100 and 0% when in an automatic cycle.

Zero Buttons

These buttons will erase the actual position display of their associated axis and reset the displayed value to zero.

Handwheel Buttons

These buttons will activate their associated axis for use with the handwheel. The left button of each axis will move the machine in .010" per detent, the middle button .010" per detent and the right .0001" per detent of the handwheel. Pressing any of the axis Jog buttons will disengage the handwheel.

Spindle Start

This button will start the spindle at the RPM that is specified on the Auto Bore Cycle tab. Once the button has been pressed and the spindle is running the button will turn red and read Spindle Stop. Pressing the button again will stop the spindle and cause the button to go back to green.

CW and CCW Creep

These buttons will cause the spindle to rotate slowly CW or CCW direction. The spindle will continue to rotate as long as the button is pressed. The speed at which the spindle will rotate is set in the Machine Parameters and should not be changed unless instructed to do so by the factory.

Jog Buttons

These buttons control the rapid travel of the Vertical, Horizontal and In/Out axis. Pressing these buttons will allow you to move the machine through all ranges of its travel unobstructed. If the spindle is turned on these buttons become feed buttons and the machine will feed in whatever direction you have pressed. The rate at which the machine will feed is determined by the value set in the Auto Bore Cycle tab. When in rapid travel, these buttons are momentary contact and you will have to keep them pressed to keep the machine moving. When the spindle is on, they are latching buttons and once they are pressed the travel will continue until they are pressed again.

Move to

Pressing these buttons will bring up a dialog box for the associated axis. Enter a value that you want the axis to move to and press ENTER. That axis will then move to that position. You can do multiple "Move To" at the same time. One after another.

Move To Zeros

Pressing this button will cause the vertical to move the zero position first. The in/out and horizontal will move after the vertical has moved to zeros.

CW and CCW Index

Pressing either of these buttons will cause the spindle to rotate to the index position. Index position is with the tool to the right as you are facing the machine.

Using SSV (Spindle Speed Variance)

Spindle Speed Variation (SSV) allows you to modify the spindle speed within a range causing it to continuously change. This changes the harmonic frequency of the machining, which can help in the appearance of chatter. Various issues can cause chatter: spindle speed, incorrect feeds, depth of cut, part rigidity, the type of part being machined, thin walls, or diameter-length ratio.

The screenshot shows the Rottler Block Boring control interface. At the top, the program is 'Chev 350' and the mode is 'General Bore'. The 'Continuous DTG' is 0.000 and 'Feedrate override' is 1.00. The main control area has several tabs: 'Set Zeros', 'Vertical Stops', 'Left Locations', and 'Right Locations'. The 'Set Zeros' tab is active, showing the 'Actual Position' for X (0.0008), Y (0.0000), Z (0.0000), and SPINDLE (0.00). A red arrow points from the SPINDLE position to the 'SSV' sub-tab in the 'Feeds Speeds' section. The 'SSV Options' menu is open, showing:

SSV Options	
<input checked="" type="checkbox"/> Enable SSV	
Time per Cycle	0.5000
RPM variation	200.0000

The bottom status bar shows 'MOVE TO ZEROS', 'CW INDEX', 'CCW INDEX', and 'START SPINDLE' buttons. The 'Notes' column on the right indicates 'Tool #:4' and 'Probe #:4'.

Checking enable SSV- will engage it for the machining process you are doing

Time per Cycle- each cycle is measured as a second.

RPM Variation- How much the rpm can vary up and down from what you set in the program

(NOTE: setting this too extreme can cause Spindle errors and spindle crashes.)

IMPORTANT

Setting Spindle Index

Any time the machine has been turned off the spindle index position must be set. Turn the spindle to the index position (tool holder facing to the right at 90 degrees from the operator). Then press the Zero button net to the spindle position read out. This will put a zero value in the display box.

This screen also shows the Spindle Load, programmed Feed Rate and Spindle RPM.

Probe Auto Center

The Probe is an option on the F103/4/5A machine. When this button is pressed a single Probing routine will be run in the position the machine is currently at.

Vertical Stops Tab

This screen is used to set the Vertical stops the machine will use to bore a cylinder. There are four Vertical stops used on this screen plus two optional Lower Clearance stops.

If the machine is equipped with a probe there are two (2) additional stops, Probe Clearance and Probe Height.

The function of the Vertical stops will be defined in the Operating Instructions chapter in this manual.


To enter any of the Vertical Stops press the Data box next to the Vertical stop you want to enter. A pop-up menu will appear. Press the desired numerical value and then press ENTER. The numerical data will then appear in the data box. You can also move the Vertical physically to the location you want the stop to be at and press the "SET" button next to the Data Box. This will take the current position from the Digital read out and insert it into the associated Data Box.

The screenshot displays the 'Rottler Block Boring' control interface. At the top, it shows 'Program: Chev 350' and 'Mode: General Bore'. A status bar indicates 'Continuous DTG' at 0.000 and 'Feedrate override' at 1.00. A coordinate display shows Z=0.000, Y=0.000, X=0.000, and A=0.000. The main interface is divided into several sections: 'CHANGE TOOL', 'PROGRAM SELECT' (with X-, X+, Y+, Z+, Y-, Z-, CW, CCW buttons), and a large red 'E-STOP IN' button. The 'Vertical Stops' tab is active, showing 'BORE PROFILE' settings: Block Clearance (1.2000), Centering Height (0.7500), Start Boring Height (0.1000), and Bottom of Bore (-6.5000). There are also checkboxes for 'X Offset for Honing', 'Washout Cycle', 'Coolant', and 'Stop and Index Spindle After Cycle'. The 'PROBE OPTIONS' section includes 'Probe Clearance' (0.0000) and 'Probing Height' (0.0000), both with 'SET' buttons, and a 'Largest Probe Diameter' of 0.0000. At the bottom, there is a 'HANDWHEEL' section for the Z-axis with buttons for .010, .001, and .0001.

Horizontal Offset for Honing

There is often the need to machine out the “webbing” at the bottom of a cylinder to get the correct honing clearance. Checking the box next to “Horizontal Offset for Honing” will bring up an additional screen section on the lower right.

This is where you will set the amount, direction and speed the offset will cut.



Left and Right Locations Tab

This screen is used to set the Horizontal and In/Out stops the machine will use to bore a block. The number of In/Out and horizontal stop on this page will change with the block configuration i.e V6, V8 or inline.

The function of the Horizontal and In/Out stops will be defined in the Operating Instructions chapter of this manual.

To enter any of the Horizontal and In/Out stops press the Data box next to the Horizontal or In/Out stop you want to enter. A pop-up menu will appear. Press the desired numerical value and then press OK. The numerical data will then appear in the data box

Cylinder Bore – Bore Locations

Rottler Block Boring

Program: Chev 350 Continuous DTG: 0.000 Z 0.000 Y 0.000

Mode: General Bore Feedrate override: 1.00 X 0.000 A 0.000

CHANGE TOOL **Set Zeros** **Vertical Stops** **Left Locations** **Right Locations**

PROGRAM SELECT **BluePrint** **Indicated** **Probed** **Difference**

Copy Values	MOVE1	MOVE2	MOVE3	MOVE4
X	0.0000	0.0000	0.0000	0.0000
Y	0.0000	0.0000	0.0000	0.0000
<input type="checkbox"/> Move Y	BORE1	BORE2	BORE3	BORE4

Move Y 0.0000

HANDWHEEL

X	.010	.001	.0001	Spindle 10x Coarse
Y	.010	.001	.0001	
Z	.010	.001	.0001	

PROBE LEFT

BORE LEFT

E-STOP IN

There are three (3) different modes you can operate the machine in on these screens, Blueprint, Indicated and Probing.

Blueprint

This mode of operation allows you to enter specific values for the bore locations from a blueprint type document.

It is helpful to have the blue print numbers entered on this screen even if you are not going to bore to the blueprint locations on a particular block. They help to set the general area of the bore if you are manually centering (indicating) or probing the block.

Move Buttons

When pressed, these buttons will move the machine, under power, to the Horizontal and In/Out positions shown in the data boxes below the Move button. The Vertical will move to the Clearance height before it makes the Horizontal or In/Out moves. After it has moved to the Horizontal and In/Out positions the Vertical will move to the Centering Height. After this, all motion stops.

Bore Buttons

Pressing this button once will cause it to turn yellow. This indicates when the “Bore Left” button is pressed this cylinder will not be bored.

Touching this button again (with a pause in between touches) will turn the button back to green. All green bores will be bored if the “Bore Left” button is pressed. The control will ask you if you sure you want to bore the selected bores.

Double Clicking a Bore button will keep it green and turn all other bore buttons yellow.

Indicated

This screen is designed to manually indicate each cylinder in for it's specific location.



Set Buttons

Once a cylinder has been indicate, pressing the associated Set Button will take the current machine position and place the values in the Data Box associated with that cylinder.

Copy Values

Pressing this button will bring up another window where you can select to copy the In/Out and Horizontal values from Blueprint, Indicated or Probed screen.

Difference

Checking this Box will cause a green check mark to be placed in the box. The Data Boxes will then display the difference in values from the blueprint screen to the indicated screen. This is helpful to know how far the cylinders actual location is from blueprint values.


Bore Left and Right

Pressing this button will cause the entire Left or Right bank to be bored automatically. The Bore buttons that are yellow will not be bored though.

Probing

The probe is an option on the F103/4/5A machine.

This screen is designed to automatically probe one or all of the cylinders.



Probe Buttons

Pressing this button will cause a probing routine to be run on the associated cylinder.

Probe Left or Right

Pressing this button will cause the entire Left or Right banks to be probed automatically.

Probed Diameter

This Data Box will display the diameter of the cylinders as they are probed.

LOWER SLEEVE REPAIR

Lower Sleeve repair is meant to be used when the Upper Bore is smaller in Diameter than the Lower Bore. Therefore the spindle has to offset in the Horizontal to clear the Upper Bore.


The Lower Sleeve Repair mode operates the same as the Cylinder Bore Mode with the exception of additional parameters in the Vertical Stops Tab.

Block Clearance

This is the distance above the zero position or block deck allowing the cutter head to move to the next bore unobstructed. If you are blueprinting a block the number will be just enough to allow the tool in the cutter head to clear the block deck.

Centering Height

This is a distance above the vertical zero where you will be manually centering the block. The drawing below is a typical set up for manual centering or indexing a cylinder.




X-Clearance

This is the parameter will index the cutter pointing in the x+ direction, (right) three O'clock position. The amount you set will allow the tool to move so it clears the block deck of the upper bore does not contact the block or upper bore. See drawing below. Machine moves in the X axis, and can be set to positive or negative movement. Should be set to negative value ex... -.200 (-5mm)

180 index (check box)

This will make the spindle index with the tool pointing in the (X-) direction, (left) nine O'clock position. Should set X-clearance to a positive value, ex... .200 (5mm)



X-Overshoot

This refers to the amount that it will overshoot the machine to help eliminate any backlash. IMPORTANT- If your X-clearance is negative (-) the overshoot should be a positive value, if the X-clearance is positive the overshoot should be negative (-)

Start Boring Height

This is the distance above zero or the block deck where you want the cutter head to start rotating and the downward feed to start. Generally this is just a short distance above the lower sleeve to minimize the amount of time the machine bores through air.

Bottom of the Bore

This is the distance below zero or the Block deck where you want the machine to stop boring and retract out of the cylinder. When the spindle retracts it will then go to the Block Clearance position.

This is an example of what the above program would look like on the vertical stops.

Stop and Index Spindle after Cycle

Checking this box will cause the spindle to be indexed to the three O'clock position after the cylinder has been bored but before it retracts. It will also offset to the left before the tool is retracted. This is the default setting. You would not want this check in an operation such as Lifter Boring.

Probing For The Mill Cycle

The Rottler Milling program is set up to Automatically Probe the Deck height of a block and then Mill it to a set Deck Height. This can be done on a 3 or 4 axis machine. This will also cover Setting Tool Offsets.

Table of Tools for Milling

You **MUST** use the Table of Tools if you want to Automatically Probe the deck height and cut it to a set height. Once done the Table of Tools Should look similar to the below picture. The 100mm Probe is Tool 1. The 10" Fly Cutter is Tool 2.


Go to Program Select, and then select the block you are working with and then Mill Mode. Install the Probe physically into the spindle. If you have a 4th axis rotate it to Zero degrees. Indicate the Middle flat on the head stock to be sure it is zero all the way across. There should be a number stamped into the headstock.

This is the distance from the Flat to the center of the Crank. Bring the probe down until it just touches the middle flat.

Open the Table of Tools and double click on Tool1 100 mm Probe. Enter the Measured diameter of your probe. This is not used in the Milling Program but needs to be entered accurately for Probing in the Bore mode.

On the open window select Get Length. This will open another Window. There will be a value, that you cannot edit, in the "Z Location from Zero" this is the distance the Vertical Axis is from home when the Probe touches the Middle flat.

In the Data box for "Z Touch off Height" enter the number that is stamped on the Head Stock. This is the distance from the flat to the center line of the Crank.




Select OK on both windows. This will put the Total tool length into the Table of Tools. The Vertical Digital Read Out will now consider the center of the Crank bore to be the Vertical Zero position. When the Probe tip or Cutting insert touches the Deck the Vertical DRO will be reading out the distance from the center of the Crank bore (Actual Deck Height).

Assigning Tools

From the Set Zero Tab, select Probe#. This will open the Tools Select Form. Select Tool 1, 50 mm Probe and click OK.

Select the Tool#.

This will open The Tool Select Form. Select Tool 2, 10 inch Fly Cutter and click OK.



The tools to be used have now been assigned to the program.

Left Deck Probe


Enter the positions you want the Probe to probe here. You can physically move the probe to the locations on the bank you want to probe and hit the set button also.

Right Deck Probe

Roll the block over to the Right Bank. Enter the positions you want the Probe to probe here. You can Physically move the probe to the locations on the bank you want to probe and hit the set button also.

Auto Probing

Press the Start Probing button. The machine will first probe each programmed location on the left bank and record the height. The spindle will move to Vertical Clearance height and the block will roll over to the right bank and probe the programmed locations and record them. If you have a 4th axis The block will then roll back over to the Left bank and the spindle will move to the first Left location and stop.



Lifter Bore

The Lifter Bore Mode and its buttons operate identical to the Bore Mode with a couple of exceptions.

On the Program Vertical Stops screen, lower Clearance Offset is not an option.

After a bore is complete the spindle will not offset .020" for tool clearance unless the "Horizontal Offset after Cycle" box is checked. This is used when a single point boring tool is used for lifter boring.

Cylinder Bore 4 Axis

Most of the Control Definition in the 4th axis is the same as the 3 axis version of software. Only the differences or new features will be discussed in this section.

Set Zero Tab



Jog Controls

4Th-

Pressing this button will cause the 4th axis to rotate in a negative direction while held.

4Th+

Pressing this button will cause the 4th axis to rotate in a positive direction while held.

4th Axis Degree and Move

Touching the 4th Axis Degree Data Box will bring up a Pop-Up Menu so a degree can be entered. Once a value is entered (even zero), pressing the Move button will move the 4th axis to that position.

4th axis Brake

This shows the status of the 4th axis brake as well as manually turning the brake on and off. When the 4th axis is rotated using the jog controls the fixture will automatically switch the brake On and Off.

Light Clamp

Pressing this button will cause light pressure to be exerted from the Tail Stock towards the Head stock. When the 4th axis is rotated using the jog controls the fixture will automatically switch from Full to Light clamp and back.

Full Clamp

Pressing this button will cause full pressure to be exerted from the Tail Stock towards the Head stock.

Retract

Pressing this button will cause the tail stock to fully retract. A dialog box will appear when this button is pressed to assure you want to retract the tail stock. This is to prevent an accidental retraction when a block is in the fixture.

Table Of Tools

The Table Of Tools is a very powerful feature in this software. Most of the Rottler programs are designed to be used without interacting with the Table Of Tools.

Only the program specific uses will be described here.

Table Of Tools General Information


The Table Of Tools is used to set different tool lengths so multiple tools can be used in one program and reference the same vertical zero position.

For Example, if you were to use two boring bars in one program. One boring bar is 8" long and the other is 4" long. There is then a 4" difference in where the cutter of each bar will come into contact with the part to be machined. Using the Table of Tools you can set the 4" difference for one of the boring bars so that both of the cutting tools will come into contact with the material at the same vertical position.

Accessing Table Of Tools

Select TABLE OF TOOLS from any screen in the upper left hand corner. This will open up the Table Of Tools.


On this screen you will be able to Add, Remove or Set that tool Active (installed in spindle and being used).




The Table of Tools comes with Tool 0 installed with no offset amount. Tool 0 will remain tool 0 with no offset always. Tool 0 will be set active when you are using programs that do not require tool offsets.

Add Tool

To add a tool to the Table of Tools press Add Tool. This will open another window. Here you will name the Tool you are adding. Such as 2.9 production Stub. It is important to give an accurate name to the tool. You want the tool easily identifiable by its name. The only other data box the Rottler software uses is the Length Data Box. This will be discussed later. Press OK.



The Added tool will now show in the Table of Tools.




Remove Tool

Pressing this button will remove the highlighted tool from the Table of Tools.

Set Active Tool

Pressing this button will set the highlighted tool to an Active Status (tool installed and will be used) Any Vertical offset associated with that tool will be used when a program is run. You can tell which tool is active because it is highlighted in Red. When no offset is required in a program Tool 0, Default Tool should be active.

When setting a tool active another window will open. This is the Tool Change Form. It is basically there to verify the tool information before it is set to an active status. Verify the information and press OK.



This window will open when the machine does an automatic tool change. This will be discussed in Chapter 5 Operating Instructions. After you press OK another window will open. This is a Warning Dialog box to inform the operator of the possibility of the spindle start if the tool change is done in an automatic program. Press OK.



Setting Tool Offsets

Add all the tools that will need offsets into the table of tools. Leave the Length value at 00.00 when you first enter them.

For this example we will be setting offsets for a 2.9 Production Stub, 100mm Probe and a 10 inch Fly cutter. Add these tools to the table of Tools.

NOTE: Only the Probe will use the Tool Diameter. The Probe will use the Tool Diameter when probing a cylinder, it will not use the Tool Diameter when touch off a surface such as a block deck. Changing this setting will be discussed in later in this Chapter.


The screenshot shows the Rottler Block Boring control interface. At the top, the program is set to 'Chev 350' and the mode is 'Cylinder Bore'. There are buttons for 'Continuous DTG' (set to 0.000) and 'Feedrate override' (set to 1.00). Below these are coordinate readouts for Z (0.000), Y (0.000), X (0.000), and A (0.000). A table lists the tools in the system:

Tool Num...	Tool Name	TC Pocket	Tool Diam...	Tool Length	Type of Tool	Description
0	Default Tool	0	0.0000	0.0000	Drill	
1	Production stub	0	0.0000	0.0000	FlatEndmill	
2	100 mm probe	0	0.0000	0.0000	FlatEndmill	
3	10 inch flycutter	0	0.0000	0.0000	FlatEndmill	

On the left side, there are buttons for 'CHANGE TOOL' and 'PROGRAM SELECT', along with directional controls (X-, X+, Y+, Z+, Y-, Z-, CW, CCW, A-, A+) and a red 'E-STOP IN' button. On the right side, there are buttons for 'Add Tool', 'Remove Tool', 'Set Active Tool', 'Set Active w/o moving to TC position', and 'Load ATC'.

To set Tool Offsets you will need a fixed vertical reference point on the machine that does not change such as the head stock of the 4th axis or Performance Fixture.

Install the first tool such as the 2.9 Production Stub with Cutting insert installed. Bring the cutting insert down until it just touches the flat on the head stock of the 4th axis fixture. Go to the TABLE OF TOOLS and double click the 2.9 Production Stub tool. Select Get Length from that window. This will bring up the Tool Length window.



Z Location from Zero


This is the distance the Vertical Axis is from the home position. NOT where the operator has set the Vertical Zero in the program. This value is set by the computer automatically. In this example the tool just touched the flat at 8.0000.

Z Touch Off Height

This value is an additional value you want added to the Z location from zero. For example, if you wanted to use the center of the Crankshaft as the vertical reference point, but you are touching the tool off of the flat of that head stock, you would enter the distance from where you are touching off to the center of the Crank (this value is stamped into the headstock by Rottler). The values from Z Location from Zero and Z Touch off Height are added together by the computer to get the Final tool Length value. If you are not referencing another vertical position then this value will remain 00.000.

Add Tool Radius?

Checking this box will add the Tool Radius to the Final Tool Length. This is not used in the Rottler programs and should remain unchecked for all tools.



Repeat this procedure for each tool. Touch ALL of them off from the same point.

When running a Rottler program the cutting insert for each tool will reference the Vertical Zero the operator set in the program and come into contact with the surface to be machined at the same vertical value.

Applying Table of Tools to Rottler Programs

The use of the Table of Tools to specific Rottler programs such as Bore and Mill will be defined in Chapter 5 Operating Instructions.

Fixture Select

This is also a very powerful tool. It is not generally used in the Rottler Programs. It's basic function is to offset a program and table of tools a set distance on each axis (if desired) and run the same program without resetting axis zero points.

For example, if you have to fixtures that are identical but are set at a different location on the table you can set the difference values in the table of fixtures and run the program.

It is recommended this is not used unless you are a very experienced operator.

OPERATING INSTRUCTIONS

Contents

Operating Instructions	5-1
Loading Blocks	5-1
Small Gas and Diesel	5-1
Manual V6/V8 Combination Fixture 502-1-72H	5-1
Boring Application	5-1
Normal Operating Procedure	5-3
Surfacing Application	5-5
Normal Operating Procedure	5-7
Retrofitting 502-1-15C Parallels to V6/V8 Combination Fixture	5-8
Diesel Blocks	5-10
6725 Diesel Fixture	5-10
Small Diesel V Blocks	5-10
Triangle Clamping	5-11
Block Clamp Arm	5-11
Small Diesel In Line Blocks	5-13
Triangle Clamping	5-14
6405F Large V-Block	5-16
Triangle Clamping	5-17
6810 Waukesha 7042, 9390 and CAT 379, 398, 399 Block Line Bore Fixture	5-20
6821 Adjustable, Universal Line Bore Parallel Assembly	5-24
7119V Dual Axis Table Assembly	5-29
Instructions for Small In-Line Blocks	5-30
Mounting Block to Table	5-30
Blocks with Main Caps Removed or Raised Main Bearings	5-30
Blocks with Main Caps Installed	5-31
Typical Head Set Up Procedure	5-32
Setting Up Rottler Fly Cutting Tool With Two Inserts	5-34
12" Multi Tooth Milling Head - 6865	5-35
18" Multi Tooth Milling Head 6864	5-35

General Machine Information	5-36
Homing	5-36
Create a Block Program	5-36
New.....	5-36
Options	5-37
Creating Operating Modes for a Block Model	5-37
New	5-38
Std (Standard) Setup	5-39
Select.....	5-39
Options	5-39
Cylinder Bore Mode 3 Axis	5-40
Setting Zeros	5-41
Horizontal and In/Out Zero.....	5-41
Vertical Zero	5-41
Blueprinting	5-43
Programming Vertical Stops	5-43
Block Clearance.....	5-43
Centering Height.....	5-44
Start Boring Height.....	5-44
Bottom of the Bore	5-44
Horizontal Offset for Honing	5-45
Start Offset Height.....	5-45
Horizontal Offset.....	5-45
Change Speeds at Horizontal Offset	5-45
Washout Cycle	5-45
Stop and Index Spindle after Cycle	5-45
Bore Locations	5-46
Left Locations	5-47
Right Locations	5-47
Boring a Block	5-48

Indicating.....	5-48
Vertical Zero	5-48
Programming Vertical Stops	5-49
Block Clearance.....	5-49
Centering Height.....	5-50
Start Boring Height.....	5-50
Bottom of the Bore	5-51
Bore Locations	5-52
Boring a Block	5-54
Probing.....	5-54
Vertical Zero	5-54
Programming Vertical Stops	5-55
Block Clearance.....	5-55
Centering Height.....	5-55
Start Boring Height.....	5-55
Bottom of the Bore	5-56
Probe Height	5-56
Bore Locations	5-57
Probe Auto Center	5-57
Automatic Probing Procedure.....	5-57
Boring a Block	5-58
Cylinder Bore Mode 4th Axis.....	5-58
Setting Zeros	5-58
4th Axis (Rotational) Zero	5-58
Finding the In/Out (Y) Axis Zero with 4th Axis.....	5-58
Building Programs with the 4th Axis.....	5-58
Setting Vertical Clearance with 4th Axis	5-59
Table of Tools for 3 and 4th Axis Bore Mode	5-59
Building a Program with Table of Tools	5-59
Assigning Tools.....	5-59

Setting Tools Active	5-60
Mill Mode 3 Axis.....	5-62
Setting Zeros.....	5-62
Horizontal Zero.....	5-62
In/Out Zero.....	5-62
Vertical Zero	5-62
Example	5-62
Mill Operation.....	5-64
End.....	5-64
Horizontal End.....	5-64
Amount Per Pass	5-64
Vertical Start	5-64
Vertical End	5-64
Copy Lowest Copy Highest	5-65
Rough Settings	5-65
Rough Feed Rate	5-65
Rough Spindle RPM.....	5-65
Finish Cut Settings	5-65
Finish Amount	5-65
Finish Feed Rate	5-65
Finish RPM	5-65
Start Auto Cycle.....	5-66
Mill Mode 4th Axis	5-66
Setting Zeros.....	5-66
Horizontal Zero.....	5-66
In/Out Zero.....	5-66
Vertical Zero	5-66
Mill Operation.....	5-68
End.....	5-68
Horizontal End.....	5-68
Amount Per Pass	5-68
Vertical Start	5-68
Vertical End	5-68
Copy Lowest Copy Highest	5-69
4th Axis Angles	5-69

Left Bank Angle	5-69
Right Bank Angle	5-69
Rollover Vertical Clearance	5-69
In/Out Offset	5-69
Rough Settings	5-69
Rough Feed Rate	5-69
Rough Spindle RPM	5-69
Finish Cut Settings	5-69
Finish Amount	5-69
Finish Feed Rate	5-69
Finish RPM	5-69
Cut Left and Cut Right	5-70
Start Auto Cycle	5-70
Overlap Mill Setting	5-71
Milling Using Automatic Deck Probing	5-72
Table of Tools for Milling	5-72
Assigning Tools	5-74
Setting Tools Active	5-75
Building a Program Using Table of Tools	5-75
Left Deck Probe	5-76
Right Deck Probe	5-76
Auto Probing	5-76
Auto Milling	5-77
Vertical Start	5-77
Vertical End	5-77
Cut Left or Cut Right	5-77
Start Auto Cycle	5-77
Lifter Bore Mode 3 Axis	5-78
In / Out Zero	5-78
Start Boring Height	5-78
Lifter Bore Angle	5-78
Lifter Bore 4th Axis	5-79
Start Boring Height	5-79
Lifter Bore Angle	5-79

Calculate In/Out.....	5-79
Right Angle Drive Installation	5-80
Line Bore Mode.....	5-84
Mounting and Aligning the 90 Degree Head	5-84
Setting Zeros.....	5-84
Horizontal Zero.....	5-85
In/Out and Vertical Zero.....	5-85
Line Bore Options	5-86
Programming Vertical Stops	5-87
Thrust Cutting.....	5-89
Setting Zeros.....	5-89
Horizontal Zero	5-89
Dimensions & Auto Cycle.....	5-90
Thrust Dimensions	5-90
Outside.....	5-90
Inside.....	5-90
Cutter	5-90
Clearances	5-90
Vertical	5-90
Horizontal	5-90
Dimensions	5-90
Main Width.....	5-90
Insert Width	5-91
Left Depth of Cut.....	5-91
Right Depth of Cut	5-91
Cut Right Side	5-91
Cut Left Side.....	5-91
Description and Running of the Auto Cycle	5-91
Start Auto Cycle	5-91
Backing Up and Restoring Block Profiles.....	5-92

Operating Instructions

The purpose of this chapter is to explain and then guide the operator from loading a block through running an automatic cycle.


All modes of operation will be discussed in this chapter.

Note: *We recommend, particularly for operators unfamiliar with the boring machine, to practice on a junk block in order to become familiar with the controls and procedures of the boring machine.*

Loading Blocks

Small Gas and Diesel

Manual V6/V8 Combination Fixture 502-1-72H

 Handle the block and fixture with EXTREME care and guidance. A block hoist is REQUIRED. Mishandling of a heavy engine block and fixture may result in the dropping of parts and personal injury.

The Model 502-1-72H manual V6/V8 combination fixture is a fast, simple and universal system to properly and accurately hold most 60 degree V-type engine blocks for either cylinder boring or deck surfacing.

See illustration on the following page.

Boring Application

NOTE: *The block must have the main bearing caps in place and torqued.*


Care must be taken to assure the contact edges of the locator bar are near the cap split line. A pair of 3/8" and 1/2" spacers are provided for blocks with large main bearing bores, to enable the bar to locate near the main bearing split line. (See figure 2)

V-blocks: (blocks with main bearing center lines no more than 1/2" higher than the pan rail plane) are mounted with the 502-3-8B V-block frame in place. Select the 90-degree option placement of the frame to suit block length, or main bearing caps will interfere with frame. Rotate frame 90 degrees by moving its shoulder screws to alternate set of holes.

Y-Blocks: (blocks with main bearing center lines 2-3/8" to 3-1/2" higher than the pan rail plane) are mounted directly on the fixture. Some Y-blocks (GM 60 degree) have too narrow pan rails and some have too low main bearing location which will require the use of the 502-1-15C precision 1-1/4" x 3" parallel set to raise and or support the block. Use the shoulder screw from the V-block frame and hook the parallels over the back of the V-fixture.

This fixture may be easily repositioned on the support parallels (without a block in place) to shift from the 60 degree support surface to the 90 degree support surface or vice versa.

⚠ WARNING Extreme care must be taken by operator whenever handling large blocks. Large blocks may cause fixture to tip when floated too far outward. We recommend leaving hoist attached when moving these blocks. Large blocks should be lifted from the block bank surface.






FIGURE 1

FIGURE 2

Normal Operating Procedure

The normal operation procedure on smaller V-blocks is to first pick up the block. Place the 502-1-82X locator bar through the main bearings and hoist the block into the fixture. Pulling the block towards you, with the locator against the positioners, will prevent jamming in the slot of the guides during the loading and unloading operations. The locator bar is positioned with the word 'UP' that is on the end of the bar facing up and away from the operator. (see figure 1) After the locator bar is engaged in the positioners, pivot block outwards as you lower it. Slide block to the far left (this is the non adjustable position).

Make sure the block is firmly seated in place and not resting on pan-rail burrs or other interference points. Accurate seating can also be a problem with extremely warped, distorted blocks. Another cause of problems is failure to remove main bearing inserts. The locator bar has a relief for blocks with a small main bearing or seal. Rotate locator bar clamps into position & lightly tighten the hand screws, applying even pressure to both. Clamp the block securely with the main base clamp arms.

Warped or distorted blocks may require leveling of the deck surface in the long direction. This is possible with the hand-screw assembly in the left-hand bar positioner. Loosen both clamp hand-screws and slide the locator bar to the far right position. Retighten both clamp hand-screws. Raise or lower the adjusting hand-screw as required. For the non-adjustable position slide locator bar to the far left.

Push fixture back into bore position. There is a guide block (502-1-105) attached to the bottom of the fixture to aid in guiding the fixture along the support ways.

Operate the block clamp arms, bore, and pull fixture back to the load position.

Loosen locator bar hand screws and rotate clamps out of the way. Lift the block, either from the deck surface or with the optional 502-1-95 block handler. Turn the block 180 degrees & reload to duplicate the operation on the other bank.

After turning the engine block 180 degrees the locator bar must be twisted 180 degrees also. Again the word 'UP' must enter into the positioners facing up and away from the operator. (See figure 1).

Figure 1

502-1-82X main bearing locator bar indexes at point A. When bank is reversed and the bar is twisted 180 degrees, point A still indexes the main bearing.

Point C holds the block down. When bank is reversed and the bar is twisted 180 degrees, point B holds the block down.

Figure 2

502-1-82X main bearing locator bar indexes near bearing split line. Point C does not contact the bearing cap but rests on matched spacers that are provided to fit in the bar positioners slot. If there is a means of holding the block down such as block clamp towers, this method may be used in large bores in order to properly index near the bearing split line. If extreme care is used this method may be used to index blocks without bearing caps attached. (Optional clamp down must be provided).

Surfacing Application

NOTE: The block must have the main bearing caps in place and torqued.

Care must be taken to assure the contact edges of the locator bar are near the cap split line. A pair of 3/8" and 1/2" spacers are provided for blocks with large main bearing bores, to enable the bar to locate near the main bearing split line. (See figure 2)

V-blocks:

(blocks with main bearing center lines no more than 1/2" higher than the pan rail plane) are mounted with the 502-3-8B V-block frame in place. Select the 90-degree option placement of the frame to suit block length, or main bearing caps will interfere with frame. Rotate frame 90 degrees by moving its shoulder screws to alternate set of holes.


Y-Blocks:

(blocks with main bearing center lines 2-3/8" to 3-1/2" higher than the pan rail plane) are mounted directly on the fixture. Some Y-blocks (GM 60 degree) have too narrow pan rails and some have too low main bearing location which will require the use of the 502-1-15C precision 1-1/4" x 3" parallel set to raise and or support the block. Use the shoulder screw from the V-block frame and hook the parallels over the back of the V-fixture.

This fixture may be easily repositioned on the support parallels (without a block in place) to shift from the 60 degree support surface to the 90 degree support surface or vice versa.

⚠ WARNING

Extreme care must be taken by operator whenever handling large blocks. Large blocks may cause fixture to tip when floated too far outward. We recommend leaving hoist attached when moving these blocks. Large blocks should be lifted from the block bank surface.



Normal Operating Procedure

The normal operation procedure on smaller V-blocks is to first pick up the block. Place the 502-1-82X locator bar through the main bearings and hoist the block into the fixture. Pulling the block towards you, with the locator against the positioners, will prevent jamming in the slot of the guides during the loading and unloading operations. The locator bar is positioned with the word 'UP' that is on the end of the bar facing up and away from the operator. (see figure 1) After the locator bar is engaged in the positioners, pivot block outwards as you lower it. Slide block to the far left (this is the non adjustable position).

Make sure the block is firmly seated in place and not resting on pan-rail burrs or other interference points. Accurate seating can also be a problem with extremely warped, distorted blocks. Another cause of problems is failure to remove main bearing inserts. The locator bar has a relief for blocks with a small main bearing or seal. Rotate locator bar clamps into position & lightly tighten the hand screws, applying even pressure to both. Clamp the block securely with the main base clamp arms.

Warped or distorted blocks may require leveling of the deck surface in the long direction. This is possible with the hand-screw assembly in the left-hand bar positioner. Loosen both clamp hand-screws and slide the locator bar to the far right position. Retighten both clamp hand-screws. Raise or lower the adjusting hand-screw as required. For the non-adjustable position slide locator bar to the far left.

Push fixture back into surfacing position with the back of the fixture on the Shim Stock. The shim stock is put in place to raise the back side of the block, you can then use the Jacking Screw to raise and lower the front of the block. There is a guide block (502-1-105) attached to the bottom of the fixture to aid in guiding the fixture along the support ways.

Operate the block clamp arms, surface, and pull fixture back to the load position.

Loosen locator bar hand screws and rotate clamps out of the way. Lift the block, either from the deck surface. Turn the block 180 degrees & reload to duplicate the operation on the other bank.

After turning the engine block 180 degrees the locator bar must be twisted 180 degrees also. Again the word 'UP' must enter into the positioners facing up and away from the operator. (See figure 1).

Figure 1

502-1-82X main bearing locator bar indexes at point A. When bank is reversed and the bar is twisted 180 degrees, point A still indexes the main bearing.

Point C holds the block down. When bank is reversed and the bar is twisted 180 degrees, point B holds the block down.

Figure 2


502-1-82X main bearing locator bar indexes near bearing split line. Point C does not contact the bearing cap but rests on matched spacers that are provided to fit in the bar positioners slot. If there is a means of holding the block down such as block clamp towers, this method may be used in large bores in order to properly index near the bearing split line. If extreme care is used this method may be used to index blocks without bearing caps attached. (Optional clamp down must be provided).

Retrofitting 502-1-15C Parallels to V6/V8 Combination Fixture


(Special Applications)

Some engine blocks with large main bores (3-1/8" and larger) cause a problem of the locator bar bottoming out in the bar positioners and/or the V-shaped relief's of the 502-3-8B V-block frame before clamping the block properly. Mounting the 502-1-15C parallel set as shown below in place of the V-block frame will provide proper clearance for clamping. Older style fixtures and parallels can be modified to this configuration using illustrations below.

V-6 blocks with one-piece 'caged' main bearing caps (all caps are connected) can interfere with 502-3-8B V-block frame. The parallel arrangement shown below will allow proper support and clamping of these blocks.



Some V-6 engine blocks (for example Buick V-6) have main bearing bores that are too low in respect to the pan rails. This presents a problem of the locator bar bottoming out in the bar positioners before the block is properly clamped. Positioning the 502-1-15C parallel set as shown below will raise the block enough to provide proper clamping.



Diesel Blocks

6725 Diesel Fixture

Small Diesel V Blocks

On these blocks it will be necessary to install the 6370Z, 10" parallels or 6794E, 8" parallels onto the bed of the machine. These parallels are keyed, place them onto the deck surface and then push them toward the rear of the machine. This will locate them evenly on the middle keyway of the machine bed. Place the two 6553F main bearing supports onto the parallels, these are also keyed and fit into the machined slots on the parallels. This will put the two main bearing supports in line with each other. Tighten all bolts to lock the parallels and main bearing support into place. Select the correct size main bearing locators and install them into the mains of the block..

Note: Make sure there are no burrs or debris in the main bearing bores where they will contact the main bearing locators. This can cause the block not to clamp properly and may cause tipping or rocking of the block.



Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks. These blocks should be lifted from the block bank surface.

Install the main bearing locators into the mains of the engine block. Lower the block so that the locators go into the main bearing support.




The hoist must remain attached to the block until it is firmly clamped into position. The blocks will have a tendency to tip forward until they are properly supported and clamp. When not properly supported and attached to a hoist these blocks will roll forward and out of the fixture. This will cause severe injury or death to operator.


Select the correct jacking screw to reach the block. Place the jacking screws into the jack bodies and place on the parallels in a location they will support the block from rolling forward.


Position the block clamps so the front of the shoe will clamp the block in the middle on both ends. The following illustration shows the correct triangle clamping system that should be used.

You can raise and lower the ends of the block by rotating the Hex nut located on the ends of the main bearing locators.

Triangle Clamping

Adjust the height so the shoes rest on the clamp points. Tighten the clamp leg handles. Actuate the clamp shoes by turning their knobs. Apply pressure to the two clamps as evenly as possible to avoid tipping the block up on one side.

Block Clamp Arm




Small Diesel In Line Blocks

On these blocks it will be necessary to install the 6370Z, 10" parallels onto the bed of the machine. These parallels are keyed, place them onto the deck surface and then push them toward the rear of the machine. This will locate them evenly on the middle keyway of the machine bed. Place the two 6553F main bearing supports onto the parallels, these are also keyed and fit into the machined slots on the parallels. Use the forward machined slots. This will put the two main bearing supports in line with each other, and on centerline of the machine bed.


Position the fixtures at a distance apart equal to the outboard main journals. Tighten all bolts to lock the parallels and main bearing support into place. Select the correct size main bearing locators, and install them into the mains of the block. Notice the locators have a flat area. Installing with the flat side up will allow end to end height adjustment of the block by rotating the locator. Installing with the round side up will position the block so all machining operations are parallel and perpendicular to the main bore centerline. This simply requires leveling the block in the front to rear direction.

Note: Make sure there are no burrs or debris in the main bearing bores where they will contact the main bearing locators. This can cause the block not to clamp properly and may cause tipping or rocking of the block.

 **WARNING** Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks. These blocks should be lifted from the block bank surface.


Lower the block so that the locators go into the main bearing support. A clevis pin is provided to keep the locator in position on the main bearing support.

For in-line blocks, load the block with the heavier side towards the front.

 **DANGER** The hoist must remain attached to the block until it is firmly clamped into position. The blocks will have a tendency to tip until they are properly supported and clamp. When not properly supported and attached to a hoist these blocks will roll forward or backwards and out of the fixture. This will cause severe injury or death to operator.

Select the correct jacking screws to reach the block. Place the jacking screws into the jack bodies and place on the machine bed in a location they will support the block from rolling forwards. Rough level the block using a spirit level.

The following illustration shows the correct triangle clamping system that should be used.


Triangle Clamping

Adjust the height so the shoes rest on the clamp points. Tighten the clamp leg handles. Actuate the clamp shoes by turning their knobs. Apply pressure to the two clamps as evenly as possible to avoid tipping the block up on one side.

Be sure the clamp is below the deck surface if you to resurface the block.

⚠ WARNING

Do not release the hoist or lifting device from the block until the clamping is secure.



6405F Large V-Block

Place the 6405 supports on the machine bed. Make sure there is no debris or burrs on the mating surfaced. The supports should be placed on the machine bed with the two dowels on the bottom of the supports into the middle keyway. Place the supports the same distance apart as the mains you will be using. On long blocks, it is recommended to use main bearing locations inward from the ends, to more equally balance the block and avoid sag. Push the supports back toward the rear of the machine against the dowel pins. This will line the supports up with each other. Tighten the four (4) mounting bolts on each support.

Install the correct size locators into the main bores that will be used.



Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks. These blocks should be lifted from the block bank surface.



The hoist must remain attached to the block until it is firmly clamped into position. The blocks will have a tendency to tip until they are properly supported and clamp. When not properly supported and attached to a hoist these blocks will roll forward or backwards and out of the fixture. This will cause severe injury or death to operator.


The main bearing bores being used, should be on centerline of each support. Set the jacking bodies, with the proper length jack screw installed onto the machine base. These should be located in the general area of the supports. Temporarily secure to the deck with at least one bolt.

Lower the block down onto the supports. Place a level on the deck of the engine block and check the level front to back. Position the jack stands in a location to properly support the block and secure. To level, use the jacking screws to raise or lower the front of the engine block.


Position the block clamps on the machine bed and secure in a location to allow proper clamping.


The following illustration shows the correct triangle clamping system that should be used.

Triangle Clamping



Adjust the height so the shoes rest on the clamp points. Tighten the clamp leg handles. Actuate the clamp shoes by turning their knobs. Apply pressure to the two clamps as evenly as possible to avoid tipping the block up on one side.






6810 Waukesha 7042, 9390 and CAT 379, 398, 399 Block Line Bore Fixture


This fixture is designed to be mounted directly on the bed of an F100 Series machine. Due to the large size of the Waukesha 7042 block, care must be taken when loading and unloading to avoid bumping the block into the column or spindle unit.

⚠ WARNING Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks.


Use the diagram on the following pages when referring to part numbers listed below. This Line Bore fixture consists of a stationary cradle and an adjustable support. The Cradle (6811A) is mounted to the machine bed over the locating pivot key and pin assembly. The locating pivot pin (6819) is pressed into the locating pivot key (6820). This assembly is positioned in the center keyway of the machine bed and the (2) set screws (MF-72) are tightened to lock the key in place. The Cradle is positioned over the pin and mounted to the machine bed. With the mounting bolts installed but not tight this provides a standard pivot point for the Cradle.



The support (6812A) is assembled with the adjusting screw (6754V) and the adjusting block (6814). This assembly is mounted to the machine bed with the lower tab of the adjusting block in the center keyway. ***Be sure to install the special ratchet adjusting wrench prior to setting this assembly on the machine bed***




The adjustable tube (6813) is bolted to the Waukesha Block using the Cam Bearing Cap mounting holes. The adjustable tube has ten (10) holes drilled in it. Four (4) of the holes are used to bolt the adjustable tube to the engine block, the remaining six (6) holes are clearance for the cap alignment dowel pins in the engine block. Since the Cam Bearing Caps are not evenly spaced along the block, the adjustable tube must be mounted on the front end of the block as shown in the following illustration.



The upper and lower leveling pads, bracket and screw are already installed in the adjustable tube.

With the adjustable tube installed, the block is ready to be lowered into the Cradle and Support. Use caution to locate the adjustable tube correctly on the support. The two roll pins (MF-229B) installed in the lower leveling pad (6411) are designed to locate the leveling pads properly.



All mounting bolts should be loose to start with. Due to the design of this fixture the Cradle end of the block is stationary both in relationship to the machine bed key way and in height. This end is not adjustable. The adjustable end of the fixture is located on the same machine bed keyway as the cradle. Once the block is loaded into the fixture it is ready to be aligned for the line boring operation. Up and down adjustment is accomplished using the leveling screw (6408) inside the adjustable tube. The block is adjusted in and out by activating the air float on the support, and turning the adjustment screw using the previously installed ratchet wrench. Once the block is located in and out deactivate the air float and tighten the support end mounting bolt to lock into place. Tighten the three (3) mounting bolts on the Cradle end of the fixture now. The alignment of the block should be checked again at this time. Repeat alignment adjustments as needed.

6821 Adjustable, Universal Line Bore Parallel Assembly


This fixture is designed to be mounted directly on the bed of the F90 series machine.

Due to the large size of these blocks, care must be taken when loading and unloading to avoid bumping the block into the column or spindle unit.


⚠ WARNING Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks.

Use diagrams on the following pages when referring to part numbers listed below. This Line Bore fixture consists of a stationary parallel and an adjustable parallel used in conjunction with a cradle that fits the block to be machined.


Install the 6820 Pivot Key (with Pivot Pin already pressed in) into the center keyway on the right hand side of the F90 bed. Tighten the two MF-72 set screws down. This will hold the Pivot key in place while the parallel pivots on the Pivot Pin (6819). Place the parallel onto the pivot pin, install the mounting bolts and washers but do not tighten down.



Install the adjustable parallel onto the left hand side of the machine bed with the In/Out adjusting block (6830) located in the front keyway. Install the mounting bolts and washers but do not tighten down.




Once both parallels are installed on the machine bed, place a magnetic indicator on the spindle towards the main bed. Indicate the adjustable parallel into the stationary parallel to within .002" on the In/Out and height. This lines the fixture up close so the block can be loaded and then use minor adjustments on the fixture to line the block up.



Select the set of V cradles for the block you are going to be machining. There are various types of cradles that can be used on this fixture. There are risers available also that can be mounted to the cradles to accommodate certain blocks. For cradle and riser selection refer to the Options section of this manual. The CAT 3500 series cradle is shown in this example.


Place the cradles on the parallel. Line up the horizontal key on the cradles with the key slot on the parallels. Generally, the rearward key slot is used, but on large blocks such as the CAT 3500, it is necessary to use the front key slot to allow clearance between the machine column, and engine block. Install mounting bolts and lock the cradles down. Due to the extreme weight of these blocks, clamping is usually not required. Threaded rods and clamp bars bridged across the cylinder bore, and threaded into the cradles is a way to secure the block if desired.

For in-line blocks, cradles are not used. In this case, round locators are bolted directly to the parallels. Lower the block with the end cylinders over the locators and push the block towards the front or rear. This will position the block in a straight line with the machine travel. Secure with threaded rods and clamp bars bridged across the cylinder bore, and threaded into the locators.




Lower the block slowly down into the cradles. Using a heavy soft mallet, tap the sides of the cradles to allow the block to settle into position. The block is now ready for alignment.

Up and down adjustment is accomplished by turning the screw on the side of the adjustable parallel. The in/out direction is adjusted by turning screw at the front of the adjustable parallel. Apply air pressure to the fixture while adjusting the in/out direction. Once the block is aligned, tighten down the fixture bolts and recheck alignment. Readjust as necessary.



7119V Dual Axis Table Assembly

REFBUL90-120197



Instructions for Small In-Line Blocks

The Dual Axis Table has the capability of holding small (less than 13 ½" from pan rail to head surface) in-line cylinder blocks for resurfacing. This will require the use of parts from the 7119P Universal Head Fixturing package.


Mounting Block to Table

There are two (2) methods for mounting blocks to the Table. Blocks with the main caps removed or with the raised main bearings can be mounted directly to the table surface. Block with the main bearing caps installed which are lower than the pan rail surface must be mounted using support blocks from the Universal Fixturing package.

Blocks with Main Caps Removed or Raised Main Bearings

Remove any burrs from pan rails of block.

Locate cone washers on table to approximately center block in path of cutter-head and 'hook' the edge of the pan rail in the rear. Clamp the block using clamp handle assembly. We suggest you install the stop rod assembly on the left hand end of the block. This is an added safety precaution.




Check that all bolts and hold downs are tight. Loosen table clamp and level head surface of block in both directions. Lock table clamp and recheck block for level.

Blocks with Main Caps Installed

Remove any burrs from pan rails of block.

Position rear supports and front supports to hold block approximately centered in path of cutter-head. Generally, place the front supports closer together than the rear supports.


Place the block on the supports. Reposition the supports if necessary to clear main caps. Etc. Elevate the cones to hook the pan rail in the rear. Tighten set screws to lock cones in place. Tighten the hex bolts on the supports. Adjust the support block jack to eliminate any rocking. Lightly apply the clamp handle assembly.




Loosen table clamp and level head surface of block in both directions. Lock table clamp. With the level still on the block tighten clamp handle assembly with appropriate clamp nose on the lower portion of a port or indent near the middle of the block. Tighten the clamp 1/8 to 1/4 turn after contacting the block. Do not over-tighten. Watch the level as you tighten to check for movement or warping. If the block moves or warps, repositioning the front supports inward will generally solve the problem. Check to see that the block cannot be moved in the fixture. We suggest that you install the stop rod assembly on the left hand end of the block. This is an added safety precaution.

Typical Head Set Up Procedure

Find the desired ports or bosses, in the head, to position cones (long or short) on rear support blocks.
 Measure the distance between the centerlines of these ports (bosses) within 1/16" (1mm – 5mm).
 Measure the distance from rear support points to front support points on the head.




Position rear support blocks and front support blocks to hold the head approximately centered on the table top and spaced apart per dimensions measured in step '1' above. Generally, place the front blocks closer together than the rear blocks. If necessary, use either 2 or 4 spacers to raise the head for clearing studs or to angle the head so the cutterhead clears the head clamp handle assembly.



Place the head on the support blocks. Elevate the cones to 'hook' the two ports (bosses) on the head and tighten their set-screws. Adjust the position of the front support blocks if necessary. Tighten the hex bolts on the support blocks. Push the head back firmly into the cones. Adjust the support block jack to eliminate any rocking of the head. Do not tighten the head clamp handle assembly yet.

Unlock the table. Using the two hand-wheels, level the head surface to be cut. Lock the table in this position.


REFSETUP3-092292




The head clamp handle assembly has a replaceable nose that pushes on the head. With the level still on the head surface, tighten the head clamp handle assembly on the lower edge of a port or indent near the middle of the head. Tighten the clamp 1/8 to 1/4 turn after contacting the head. Do not over tighten. Watch the level as you tighten to check for movement or warping. Some heads are very sensitive to support block placement, and the front support blocks may have to be moved slightly inward to prevent this warping. Check to see that the head cannot be moved in the fixture.

Slide the end stop block up against the left end of the head towards the rear. If possible, rotate the stop rod to contact a machined area on the end of the head. This will aid in loading a run of similar heads.

REFSETUP4-123192




Visually check for clearance between the cutterhead and head fixture tooling pieces, especially the head clamp handle, assembly. The head should be approximately centered in the path of the cutterhead.



Setting Up Rottler Fly Cutting Tool With Two Inserts

- Travel the spindle to the center of the machine bed.
- Go to the Rottler home screen on the machine before proceeding.
- Remove the cutter head shroud from the fly cutter. Attach a dial runout indicator to a cylinder head or engine block, etc.
- Rotate cutter head and check to see that both inserts are the same distance from the center of the spindle, within .004.
- If adjustment is necessary loosen the tool holder clamp wedge, and the height adjustment screw. Move tool in or out the required distance. Tighten the clamp wedge. Snug up the height adjustment screw. There is a set screw located at the bottom of the tool holder; it locks a dowel pin in place.
- When the in-out adjustment is set, loosen the set screw, the pin will pop out and hit the back of the slot. Tighten the set screw. This way, when a tool holder is removed and then replaced, it will be located very nearly where it was.
- Insert height will still need to be adjusted.
- Rotate cutter head and check to see that both inserts are the same height within .0015-.0003 The closer you get it the more accurate your surface will be.
- If adjustment is necessary loosen the tool holder clamp wedge, then alternately loosen and tighten the height adjusting screw and the retaining screw, until both inserts are set as desired.
- Retighten the tool holder clamp wedge, and recheck both inserts.



12" Multi Tooth Milling Head - 6865

This milling head holds 14 insert cartridges. Each insert has 10 cutting edges, 5 on each side. The inserts need to be adjusted to be at equal height of each other to within .0004" (.01mm). To set the height of the inserts, install the milling head into the machine spindle. Install the inserts. Back off the small set screw above each tool cartridge. Loosen each tool cartridge, push up, and re-tighten.

Using an indicator with a large diameter convex tip, find the insert that is at the lowest setting. Now, adjust the remaining inserts to equal height by turning the small set screw above each tool cartridge.

18" Multi Tooth Milling Head 6864

This milling head holds 9 insert cartridges. Each insert has 10 cutting edges, 5 on each side. The inserts need to be adjusted to be at equal height of each other to within .0004" (.01mm). To set the height of the inserts, install the milling head into the machine spindle. Install the inserts. Back off the small set screw above each tool cartridge. Loosen each tool cartridge, push up, and re-tighten.

Using an indicator with a large diameter convex tip, find the insert that is at the lowest setting. Now, adjust the remaining inserts to equal height by turning the small set screw above each tool cartridge. Install the dampener band around the perimeter of the milling head.

General Machine Information

Before starting to build or use any of the Rottler operating programs it is important to understand how the machine operates internally.

The Rottler F103/4/5A model uses Computerized Numeric Control (CNC). The CNC is always operating when the machine is turned on. However, you will not see the CNC controls unless you switch over to the CNC operating screen.

Homing

The F103/4/5A MUST be homed anytime it is turned off.

Building Programs

NOTE: The instructions in this section are done WITHOUT using tool or Fixture offset values.


Create a Block Program

Block Programs are listed on the left hand side of the screen. Mode programs that are for a specific Block Model are listed on the right side of the screen.

New

From the Program Select screen select New from the Left hand menu. This will open a window where will enter the Block name and configuration i.e. V6, V8 or Inline and number of cylinders.

NOTE: There is an existing program on start-up of new software called Part Program. This can be deleted after the first Block Program is entered.



Options


If you need to change the block configuration or name of a block that has already been created, use the Options button. This will bring up the same window as when the block was created.

Creating Operating Modes for a Block Model

Select the Block model on the left hand side of the screen.

New

Selecting New will bring up a window that lists all the Modes that can be performed on the selected block model. Highlight the Mode you want to create and press OK.



The selected mode will show up on the right hand side of the screen.



Std (Standard) Setup

Pressing Std Setup will cause all of the available Modes to be inserted into the Modes area on the right hand side.




Select

Pressing Select with a Mode highlighted will open the operations screens for using the program.

Options


Pressing the Options button with a Mode highlighted will open a window where you can change the mode name. There is also a check box to allow positive number to be entered into the program where they are normally forced to a negative value.



Cylinder Bore Mode 3 Axis

Select Cylinder Bore and then Rough Through Bore on the screen. This will bring up the boring program with the Set Zeros tab shown.

NOTE: Once a certain feature is discussed in a particular mode it will not be discussed again in the following modes.




Setting Zeros

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis (except the Spindle rotation) will need to have a zero point set for the machine to operate from. Every program will save it's individual zero positions. The next time that program is selected the zero position will be the exact same distance from the Home position for each axis.

Horizontal and In/Out Zero


For this example, the Dowel Pin will be our zero point for the Horizontal and In/Out axis. Using an indicator or electronic probe center the spindle on the Dowel Pin then press the Horizontal and In/Out Zero buttons. The display next to these buttons will go to zeroes. The Horizontal and In/Out zero positions have now been set.



Vertical Zero

There are three different ways to use the boring software, Blueprinting, Indicating and Probing. It is not unusual for all three modes to be used on the same size block. The vertical stops for these different operating programs will vary. Be sure the vertical stops are set correctly for the mode you are using.

For this example the deck will be our zero for the Vertical axis. Insert a tool holder into the cutterhead you will be using to bore the block. Center the cutterhead over a cylinder. Using the Vertical Handwheel, bring the cutterhead down until the tool just touches the deck and press the Vertical Zero button. The display next to this button will go to zero. The Vertical zero has now been set.




The zeros points for all axis have now been set. All the numbers entered from this point on will reference these zero positions. You are finished with the Set Zeros screen, select the next Tab to the Right, Vertical Stops.

Blueprinting

Even if you are not going to be boring a block to the blue print specifications it is recommended to have the Blueprint values entered. It will speed up the process of indicating and probing a block by giving the operator a close estimate of bore location.


Programming Vertical Stops

To build a program you must set the Vertical Stops for the program.



Block Clearance

This is the distance above the zero position or block deck allowing the cutterhead to move to the next bore unobstructed. If you are Blueprinting a block the number will be just enough to allow the cutterhead to clear the block deck.




Centering Height

When Blueprinting this stop is not needed. It should be the same as the block Clearance Height.

Start Boring Height


This is the distance above zero or the block deck where you want the cutterhead to start rotating and the downward feed to start. Generally this is just a short distance above the block deck to minimize the amount of time the machine bores through air.



Bottom of the Bore

This is the distance below zero or the Block deck where you want the machine to stop boring and retract out of the cylinder. When the spindle retracts it will then go to the Block Clearance position.

This is an example of what the above program would look like on the vertical stops.



When Blueprinting the Probe is not used. It will be discussed later in this Chapter.

Horizontal Offset for Honing

This feature is designed to offset the cutter at a certain height in the lower bore to cut out block web intrusions to make room for the honing process.

Checking this box will bring up another value to be entered on the left hand side of the screen.

The screenshot shows the Rottler Block Boring control interface. At the top, it displays 'Program: Chev 350' and 'Mode: General Bore'. There are two green buttons: 'Continuous DTG' and 'Feedrate override'. Below these are numerical values for Z (-4.7967), Y (-8.7622), X (-41.4783), and A (0.000). The interface is divided into several sections: 'CHANGE TOOL', 'PROGRAM SELECT' (with X-, X+, Y+, Z+, Y-, Z-, CW, CCW buttons), 'E-STOP IN', 'Set Zeros', 'Vertical Stops', 'Left Locations', and 'Right Locations'. The 'Vertical Stops' section is active, showing 'BORE PROFILE' settings: Block Clearance (1.2000), Centering Height (0.7500), Start Boring Height (0.1000), Start Offset Height (0.0000), and Bottom of Bore (-6.5000). There are 'SET' buttons for each of these values. The 'X Offset for Honing' checkbox is checked. Below this are 'Washout Cycle' and 'Coolant' checkboxes, and a checked 'Stop and Index Spindle After Cycle' checkbox. The 'HANDWHEEL' section shows 'Z' with buttons for .010, .001, and .0001. The 'PROBE OPTIONS' section shows 'Probe Clearance' (0.0000) and 'Probing Height' (0.0000) with 'SET' buttons, and 'Largest Probe Diameter' (0.0000). There is an unchecked 'Set Zero on Probe' checkbox. The 'After offset' and 'Dwell options' sections are also visible, with 'Horizontal Offset' set to 0.0000 and an unchecked 'Change Speeds At Horizontal Offset' checkbox. At the bottom, there are 'Left Bank' and 'Right Bank' dropdown menus, both set to 'No Offset'.

Start Offset Height

This is the vertical depth at which the cutter will shift to the side to start cutting.

Horizontal Offset

This is the distance the cutter will offset from the bore center.

Change Speeds at Horizontal Offset

Often the clearance cut is much larger than the cut for the rest of the bore. For this you can check this box and enter a different RPM and Feed Rate. If a different speed and feed are not needed do not check this box and the same feed and speed will be used that was used to bore the cylinder.

For each bank (of a V Block) you can select the direction the offset should go.

Washout Cycle

Checking this box will open another window on the right hand side of the screen. Here you can enter the RPM and number of revolutions that will be performed when the cutter reaches the Bottom of Bore position. In Through Boring this is not generally used. This is used when a certain type of finish is required on a counter bore or the bottom of a sleeve cut.

Stop and Index Spindle after Cycle

Checking this box will cause the spindle to be indexed to the three O'clock position after the cylinder has been bored but before it retracts. It will also offset to the left before the tool is retracted. This is the default setting. You would not want this check in an operation such as Lifter Boring.

The following is an example of what the screens would look like for the above block.

Left Locations



Right Locations



The Horizontal and In/Out stops have now been set.

Boring a Block

Once the Vertical, Horizontal and In/Out stops have all been entered the Spindle RPM and Feed Rate need to be entered. This is done on the Set Zeros screen. Once this is done you can go to the Left and/or Right Bore location screens and bore the cylinders.

Pressing the Bore Left for Bore Right buttons Will Bore all the cylinders that have Green bore button below them.

Pressing a Bore button once will turn that button Yellow. Any Yellow button will not be bored when the Bore Left or Right button is pressed.

Double clicking any Bore button will turn all the Bore button yellow EXCEPT the one that was double click.


Indicating

Even if you are not going to be boring a block to the blue print specifications it is recommended to have these values entered. It will speed up the process of indicating and probing a block by giving the operator a close estimate of bore location.

Vertical Zero

There are three different ways to use the boring software, Blueprinting, Indicating and Probing. It is not unusual for all three modes to be used on the same size block. The vertical stops for these different operating programs will vary. Be sure the vertical stops are set correctly for the mode you are using.


For this example the deck will be our zero for the Vertical axis. Insert a tool holder into the cutterhead you will be using to bore the block. Center the cutterhead over a cylinder. Using the Vertical Handwheel, bring the cutterhead down until the tool just touches the deck and press the Vertical Zero button. The display above this button will go to zero. The Vertical zero has now been set.



The zeros points for all axis have now been set. All the numbers entered from this point on will reference these zero positions. You are finished with the Set Zeros screen, select the next Tab to the Right.


Programming Vertical Stops

To build a program you must set the Vertical Stops for the program.




Block Clearance

This is the distance above the zero position or block deck allowing the cutterhead to move to the next bore unobstructed. When you are indicating the cylinders in you must have this stop set so the indicator will clear the block surface when traveling to the next cylinder.




Centering Height

This is a distance above the vertical zero where you will be manually centering the block. The drawing below is a typical set up for manual centering or indicating a cylinder.



Start Boring Height


This is the distance above zero or the block deck where you want the cutterhead to start rotating and the downward feed to start. Generally this is just a short distance above the block deck to minimize the amount of time the machine bores through air. This will be a negative number.



Bottom of the Bore

This is the distance below zero or the Block deck where you want the machine to stop boring and retract out of the cylinder. When the spindle retracts it will then go to the block Clearance position.

This is an example of what the above program would look like on the vertical stops.





The Vertical stops have now been set. You are finished with the Vertical Stops screen, select Left and/or Right Locations.


Bore Locations

To build a program you must set the Horizontal and In/Out Stops for the program. There are eight (8) Horizontal and In/Out stops used in the boring program. All Horizontal and In/Out stop are based from where their zero positions were set.

Select Left Locations and the Blueprint. Program the blueprint values (or close approximation) into the Horizontal and In/Out stops. Do the same for the Right Locations.



Select Left Locations and then Indicated. If you have programmed the blueprint locations into this program then press Copy Values and then Blueprint. This will cause the values from the Blueprint page to be copied into the Indicated page. This give you a starting point to indicate the individual cylinder from.



Press the Move 1 button. The machine will move to the first cylinder and stop at the centering position. Manually indicate the cylinder in using the Horizontal and In/Out handwheel. Once the cylinder is centered press the Set 1 button. This will transfer the current position of the machine into the first set of Data Boxes. Repeat this process for all the cylinders that need to be indicated.

Press the Right Locations tab and repeat the above procedure for the cylinders to be indicated on the right bank.

Boring a Block

Once the Vertical, Horizontal and In/Out stops have all been entered the Spindle RPM and Feed Rate need to be entered. This is done on the Set Zeros screen. Once this is done you can go to the Left and/ or Right Bore location screens and bore the cylinders.

Pressing the Bore Left for Bore Right buttons Will Bore all the cylinders that have Green bore button below them.

Pressing a Bore button once will turn that button Yellow. Any Yellow button will not be bored when the Bore Left or Right button is pressed.

Double clicking any Bore button will turn all the Bore button yellow EXCEPT the one that was double click.


Probing

Even if you are not going to be boring a block to the blue print specifications it is still recommended to have these values entered. It will speed up the process of indicating and probing a block by giving the operator a close estimate of bore location.

Vertical Zero

There are three different ways to use the boring software, Blueprinting, Indicating and Probing. It is not unusual for all three modes to be used on the same size block. The vertical stops for these different operating programs will vary. Be sure the vertical stops are set correctly for the mode you are using.

For this example the deck will be our zero for the Vertical axis. Insert a tool holder into the cutterhead you will be using to bore the block. Center the cutterhead over a cylinder. Using the Vertical Handwheel, bring the cutterhead down until the tool just touches the deck and press the Vertical Zero button. The display above this button will go to zero. The Vertical zero has now been set.



The zeros points for all axis have now been set. All the numbers entered from this point on will reference these zero positions. You are finished with the Set Zeros screen, select the next Tab to the Right.

Programming Vertical Stops

To build a program you must set the Vertical Stops for the program.



Block Clearance


This is the distance above the zero position or block deck allowing the probe to move to the next bore unobstructed.

Centering Height

This stop is not used when you are using the probing feature. It is recommended that it be set to the same value as the Block Clearance.

Start Boring Height


This is the distance above zero or the block deck where you want the cutterhead to start rotating and the downward feed to start. Generally this is just a short distance above the block deck to minimize the amount of time the machine bores through air.



Bottom of the Bore

This is the distance below zero or the Block deck where you want the machine to stop boring and retract out of the cylinder. When the spindle retracts it will then go to the block Clearance position.

This is an example of what the above program would look like on the vertical stops.



Probe Height

When using the optional Probe... install the probe into the spindle after your vertical positions have been set using the cutterhead.

Using the handwheel and bring the Probe down to the location in the cylinder you will be probing. Press the SET button next to Probe height. This will set the probing height position.

Using the handwheel move the probe up until it can safely move horizontal to the next cylinder. Press the SET button next to Probe Clearance. This will set the clearance height.

The Vertical stops have now been set. You are finished with the Vertical Stops screen, select Left and/or Right Locations.

Bore Locations

To build a program you must set the Horizontal and In/Out Stops for the program All Horizontal and In/Out stop are based from where their zero positions were set.

Select Left Locations and the Blueprint. Program the blueprint values (or close approximation) into the Horizontal and In/Out stops. Do the same for the Right Locations.

Select Left Locations and then Probing. You can probe each cylinder individual by pressing the associated Probe button or you can probe the entire bank by pressing the Probe Left Button. This is the same procedure for the Right Bank.

Probe Auto Center


This feature is located on the Set Zero page. This allows easily find the center of a hole or cylinder. Roughly place the probe in the center of a cylinder. Press Probe Auto Center. The cylinder will be probed in 4 places, when finished the probe will move to the center of the probed cylinder. Pressing Horizontal and In/Out zero will then establish the center of that hole.

Automatic Probing Procedure

The probe will move to the center of the cylinder to be probed. It will then move to the right at a slow rate until the side of the cylinder is touched, it will then back off slightly and touch the same spot again to confirm position. The probe will then touch off the cylinder in three more spots and retract from cylinder.

As each cylinder is probed the Probed Diameter, Horizontal and In/Out positions will be placed into the Data Boxes for the corresponding cylinder.

Press the Right Locations tab and repeat the above procedure for the cylinders to be probed on the right bank.



The Horizontal and In/Out stops have now been set.

Boring a Block

Once the Vertical, Horizontal and In/Out stops have all been entered the Spindle RPM and Feed Rate need to be entered. This is done on the Set Zeros screen. Once this is done you can go to the Left and/ or Right Bore location screens and bore the cylinders.

Pressing the Bore Left for Bore Right buttons Will Bore all the cylinders that have Green bore button below them.

Pressing a Bore button once will turn that button Yellow. Any Yellow button will not be bored when the Bore Left or Right button is pressed.

Double clicking any Bore button will turn all the Bore button yellow EXCEPT the one that was double click.

Cylinder Bore Mode 4th Axis

NOTE: The program with the 4th axis installed works basically the same as the 3 axis mode. ONLY the differences in operation and screens will be discussed here. Carefully read through the 3 Axis mode and then the 4th axis mode for operation and building programs.

Select Cylinder Bore and then Through Bore on the control panel. This will bring up the boring program with the Set Zeros tab shown.

Setting Zeros

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis (except the Spindle rotation) will need to have a zero point set for the machine to operate from.

4th Axis (Rotational) Zero

The Zero position for the 4th (Rotational) Axis should be preset from the factory. If the zero needs to be reset use the following procedure.

There are three (3) flats cut onto the Head Stock Plate. Use the middle flat to set the rotational zero. Using an indicator off of the spindle indicate the middle flat to Zero all the way along it. Use the 4th Axis hand wheel to do this. When the middle flat is indicated in press the 4th Axis Zero button. You 4th (Rotational) Zero is set.

Finding the In/Out (Y) Axis Zero with 4th Axis

The Head Stock Plate has a hole in it next to the Middle Flat. This hole is centered on the center of the Main and Cam locator shafts.

Building Programs with the 4th Axis

Program are built the same as in the 3 Axis mode with the exception of setting the Angle for each Bank. The Left and the Right Locations page each have an Angle Data Box. Here you enter the angle of each bank from the 4th Axis (Rotational) zero position. The zero position is with the Cam and Crank Locators lined up vertically.

Example: On a Chevy 350 the Left bank would be positive 45 Degrees and the Right Bank would be a negative -45 Degrees.

Setting Vertical Clearance with 4th Axis

It is very important when setting your Vertical and Probe Clearance height that you be sure to account for the Roll Over of the block from bank to bank. When in an automatic program the block will roll from the Left Bank to the Right bank at the Left Bank Bore1 position. It will also rotate from the Bore1 position when going from Right Bank to Left.

Table of Tools for 3 and 4th Axis Bore Mode

NOTE: The Table of Tools is not needed to run the Rottler automatic programs. It is recommended that it not be used except by the advanced operator.

Building a Program with Table of Tools

Build the program as described above for 3 and 4 Axis programs using the same vertical zero locations. Put the tools to be used into the Table of Tools as described in Chapter 2. In Bore mode you are not referencing another vertical location such as the Crank centerline so the Z Touch off Location will remain at zero.

Assigning Tools

Tools to be used in the boring operations are set on the Set Zeros page. To select a Tool, double click on Tool # on the right side of the screen. This will bring up the Table of Tools window. Highlight the tool you will be using, such as 2.9 Production Stub and select OK.

Do the Same to select the Probe you will be using, such as 100mm Probe.


NOTE: The Tool highlighted in red is the currently Active tool.

The screenshot displays the Rottler Block Boring control interface. At the top, the program is set to '350 Chevy' and the mode is 'R'. The 'Continuous DTG' is set to 0.000. The 'Right Locations' panel shows Z at 0.0000, Y at 0.0000, X at 0.0000, and A at 0.000. The 'Tool Select' window is open, showing a table of tools:

Tool Number	Tool Name	TC Pocket	Tool Diams	Tool Length	Type of Tool
0	Default Tool	0	0.0000	0.0000	Drill
1	2.9 Production stub	0	0.0000	0.0000	Flat Endmill
2	100 mm probe	0	0.0000	0.0000	Flat Endmill
3	10 inch flycutter	0	0.0000	0.0000	Flat Endmill
8	Probe	0	0.2360	0.0000	Ball Endmill

The 'Right Locations' panel shows 'Tool #:1' and 'Probe #:2'. The 'Tool #:1' location is set to 0.0001 with 'Move To' and 'Set Active' buttons. The 'Probe #:2' location is set to 0.0001 with 'Move To' and 'Set Active' buttons. The 'Set Active' button for 'Probe #:2' is highlighted in red. Other buttons include 'MOVE TO ZEROS', 'CW INDEX', 'CCW INDEX', and 'START SPINDLE'.


The following shows what the screen will look like with two tools assigned but none of them active. Default Tool 0 is set active and only shows on the Table of Tools screen.




Setting Tools Active

Physically install the first tool you will be using in the program. For this example physically install the 100mm Probe into the spindle. Press the Set Active button below the Probe #. The Tool Change Form will Open. This is to verify your Vertical Tool Length and Probe Diameter. Select OK and then OK again on the spindle warning page.

IMPORTANT: The Tool Diameter on this page is used for the Probe. This must be set to the actual Diameter of the probe when probing cylinders. The Tool Diameter is NOT used for Boring Bars, End Mills etc... in the Rottler Bore program.



The Currently Active tool in a program will be highlighted in Pink on the Set Zero page.




If you attempt to run the Probing Cycle with the Tool # active the machine will automatically move to the Tool Change clearance position and open the Tool Change Window so you can change the tool and vice versa.

Mill Mode 3 Axis

Setting Zeros

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis will need to have a zero point set for the machine to operate from.



Horizontal Zero

For this example we are going to set the Horizontal Zero approximately 1/4" from the right hand side of the work piece.

In/Out Zero


For this example we are going to set the In/Out Zero at the center line of the work piece.

Vertical Zero

For this example the Vertical Zero will be at the deck height of the work piece.

Example

Install the Milling cutterhead you will be using into the machine. Move the In/Out axis and center the work piece under the spindle. Press the In/Out Zero button here. Move the Horizontal Axis to that the cutter is overhanging the work piece about 1/4". Bring the Vertical Axis down until the cutter is just above the work piece. At this time it should look similar to the drawing below.



Set the Spindle RPM and Feed rate on this screen.

Start the spindle. Press the Vert .001 button to put the handwheel in .001 per detent. Slowly move the spindle downward until you can hear or see the cutter just touch the block. Press your Vertical Zero button here. Press the Right travel button to feed the spindle off of the work piece. When the cutter has cleared the work piece press the Right travel button again to stop the feeding. Press the Horizontal Zero button here.

Your zero position for all axis have now been set.

Mill Operation

IMPORTANT: Do not move the machine In/Out with the Wedge on. The Wedge comes on automatically when the Mill program is entered. If you need to move the machine In/Out to center on the work Piece use the turn Wedge On/Off button at the bottom of the page to do so. Make sure the Wedge is back on when you start the cycle.

This screen is used to set certain parameters the F103/4/5A will use to run the automatic cycle.

The screenshot shows the 'Rottler Block Boring' control interface. At the top, it displays 'Program: 350 Chevy' and 'Mode: Mill Deck'. There are two green buttons: 'Continuous DTG' and 'Feedrate override'. Below these are numerical values for Z (0.000), X (1.00), Y (0.000), and A (0.000). The main interface is divided into several sections:

- CHANGE TOOL:** A large green button.
- PROGRAM SELECT:** A vertical column of buttons for X-, X+, Y+, Z+, Y-, Z-, CW, and CCW.
- STOP MACHINE:** A large red button at the bottom left.
- Set Zeros:** A section with 'End' and 'Horizontal End' (-10.0000) with a 'SET' button. Other fields include 'Amount per Pass' (0.0040), 'Vertical Start' (0.0000) with 'Copy Highest' button, 'Vertical End' (-0.0100) with 'Copy Lowest' button, 'Additional Depth' (0.0000), 'Coolant', and 'Y Offset options'.
- Operation:** A blue button.
- Left Deck Probe:** A blue button.
- Right Deck Probe:** A blue button.
- Rough Settings:** Includes 'Rough Feed Rate' (0.0030) and 'Rough Spindle RPM' (400.00).
- Overlap Mill Settings:** Includes 'Max Workpiece Width' (0.0000) and 'Cutter Diameter' (0.0000).
- Finish Cut Settings:** Includes 'Finish Amount' (0.0020), 'Finish Feed Rate' (0.0030), and 'Finish Spindle RPM' (400.00).
- Y Offset:** A field with the value 0.0000.
- START AUTO CYCLE:** A green button at the bottom right.
- WEDGE ON:** A blue button at the bottom right.

End

Horizontal End

This displays the current end stop value. To enter a new value press the display and a pop-up numerical key pad will appear. Press the desired end stop value and then ENTER. This is the distance from where the Horizontal Zero was set. You can move the fly cutter manually to the end of the cut and press the SET button. This will automatically put the Horizontal End value in for you.

Amount Per Pass

This is the amount of material removed from the work piece on each pass of the cutterhead.

Vertical Start

This is the Vertical Position the machine will start cutting at. This value is usually Zero which is usually the starting Deck Height.

Vertical End

This is the Vertical Position the machine will stop cutting at. It is the Total amount of material you want to remove in the Milling process.

Copy Lowest Copy Highest

These buttons will be discussed in the Mill Probing section of this Chapter.

Rough Settings

These values are used when taking multiple passes on a work piece. These values can be set high to remove material quickly. The finish on the work piece does not matter in these settings. There will be a final pass that will apply the finish to the work piece.

Rough Feed Rate

Enter the desired Roughing Feed Rate;

Rough Spindle RPM

Enter the Desired Roughing Spindle RPM.

Finish Cut Settings

These values will be used for the last pass the machine will make on the work piece. These will determine the finish left on the work piece.

Finish Amount

Enter the amount to be removed on the last pass.


Finish Feed Rate

Enter the desired Finish Feed Rate.

Finish RPM

Enter the desired Finish Spindle RPM.

NOTE: You do not need to have evenly divisible numbers in these sections. The computer will do the math to remove the correct amount each time and for the final pass to be at the amount you set.



Start Auto Cycle

Pressing this button will start the machines automatic cycle. The cycle to be run is determined by the setting on this page. If you only require one pass to be made, do not enter any values into the Rough Setting, only the Finish Cut Settings.

Mill Mode 4th Axis

Setting Zeros

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis will need to have a zero point set for the machine to operate from.



Horizontal Zero

For this example we are going to set the Horizontal Zero approximately ¼" from the right hand side of the work piece.

In/Out Zero

For this example we are going to set the In/Out Zero at the center line of the work piece.


Vertical Zero

For this example the Vertical Zero will be at the deck height of the work piece.

CAUTION When setting the vertical zero it is important to check the deck height on both banks of the block before starting a cycle. It is possible that the right bank may be higher than the left bank where the vertical zero was set. This would cause a crash when the block rotated and the cycle was started on the right side.

Example:

Install the Milling cutterhead you will be using into the machine. Move the In/Out axis and center the work piece under the spindle. Press the In/Out Zero button here. Move the Horizontal Axis to that the cutter is overhanging the work piece about $\frac{1}{4}$ ". Bring the Vertical Axis down until the cutter is just above the work piece. At this time it should look similar to the drawing below.



Set the Spindle RPM and Feed rate on this screen.

Start the spindle. Press the Vert .001 button to put the handwheel in .001 per detent. Slowly move the spindle downward until you can hear or see the cutter just touch the block. Press your Vertical Zero button here. Press the Right travel button to feed the spindle off of the work piece. When the cutter has cleared the work piece press the Right travel button again to stop the feeding. Press the Horizontal Zero here.

Your zero position for all axis have now been set.

Mill Operation

IMPORTANT: Do not move the machine In/Out with the Wedge on. The Wedge comes on automatically when the Mill program is entered. If you need to move the machine In/Out to center on the work Piece use the turn Wedge On/Off button at the bottom of the page to do so. Make sure the Wedge is back on when you start the cycle.

This screen is used to set certain parameters the F103/4/5A will use to run the automatic cycle.

The screenshot shows the 'Rottler Block Boring' control interface. At the top, it displays 'Program: 350 Chevy' and 'Mode: Mill Deck'. There are two green buttons: 'Continuous DTG' and 'Feedrate override'. Below these are numerical values for Z (0.000), X (1.00), Y (0.0000), and A (0.000). The main interface is divided into several sections:

- CHANGE TOOL:** A large green button.
- PROGRAM SELECT:** A vertical column of buttons for X-, X+, Y+, Z+, Y-, Z-, CW, CCW, A-, and A+.
- E-STOP IN:** A large red button at the bottom left.
- Set Zeros:** A section with 'End' and 'Horizontal End' (set to -10.0000) with a 'SET' button.
- Operation:** A section with 'Amount per Pass' (0.0040), 'Vertical Start' (0.0000) with 'Copy Highest' and 'Copy Lowest' buttons, 'Vertical End' (-0.0100) with 'Copy Lowest' button, and 'Additional Depth' (0.0000).
- Left Deck Probe:** A section with 'Rough Settings' (Rough Feed Rate: 0.0030, Rough Spindle RPM: 400.00) and 'Overlap Mill Settings' (Max Workpiece Width: 0.0000, Cutter Diameter: 0.0000).
- Right Deck Probe:** A section with 'Finish Cut Settings' (Finish Amount: 0.0020, Finish Feed Rate: 0.0030, Finish Spindle RPM: 400.00).
- Y Offset options:** A section with 'Y Offset' (0.0000).
- START AUTO CYCLE:** A large green button at the bottom right.
- WEDGE ON:** A large blue button at the bottom right.

End

Horizontal End

This displays the current end stop value. To enter a new value press the display and a pop-up numerical key pad will appear. Press the desired end stop value and then ENTER. This is the distance from where the Horizontal Zero was set. You can move the fly cutter manually to the end of the cut and press the SET button. This will automatically put the Horizontal End value in for you.

Amount Per Pass

This is the amount of material removed from the work piece on each pass of the cutterhead.

Vertical Start

This is the Vertical Position the machine will start cutting at. This value is usually Zero which is usually the starting Deck Height.

Vertical End

This is the Vertical Position the machine will stop cutting at. It is the Total amount of material you want to remove in the Milling process.

Copy Lowest Copy Highest

These buttons will be discussed in the Mill Probing section of this Chapter.

4th Axis Angles**Left Bank Angle**

Enter the angle of the Left Deck. This is the angle of the block in reference to the Cam and Crank bore being lined up Vertically.

Right Bank Angle

Enter the angle of the Right Deck. This is the angle of the block in reference to the Cam and Crank bore being lined up Vertically.

Rollover Vertical Clearance

Enter the value the Fly Cutter will have to move up vertically to clear the block when it rolls over from bank to bank.

In/Out Offset

This is a value that can be entered to center the fly cutter in the middle of the deck. You In/Out center on the Left bank will not be the center of the In/out on the Right bank. Enter the value the In/Out will need to be moved to center on the Right Bank when it rolls over.

Rough Settings

These values are used when taking multiple passes on a work piece. These values can be set high to remove material quickly. The finish on the work piece does not matter in these settings. There will be a Final pass that will apply the finish to the work piece.

Rough Feed Rate

Enter the desired Roughing Feed Rate;

Rough Spindle RPM

Enter the Desired Roughing Spindle RPM.

Finish Cut Settings

These values will be used for the last pass the machine will make on the work piece. These will determine the finish left on the work piece.

Finish Amount

Enter the amount to be removed on the last pass.


Finish Feed Rate

Enter the desired Finish Feed Rate.

Finish RPM

Enter the desired Finish Spindle RPM.

NOTE: *You do not need to have evenly divisible numbers in these sections. The computer will do the math to remove the correct amount each time and for the final pass to be at the amount you set.*




Cut Left and Cut Right

Pressing these buttons will cause the machine to run an automatic cycle (per the parameter defined in the Operations page) on the associated bank.

Start Auto Cycle

Pressing this button will start the machines automatic cycle. The cycle to be run is determined by the setting on this page. If you only require one pass to be made, do not enter any values into the Rough Setting, only the Finish Cut Settings.



Overlap Mill Setting

These settings will cause the mill head to do a zig zag pattern on whatever you are milling. It is important to note that when using this function that the wedge will not be engaged, and will warn you that it is off.


Milling Using Automatic Deck Probing

The Rottler Milling program is set up to Automatically Probe the Deck height of a block and then Mill it to a set Deck Height. This can be done on a 3 or 4 axis machine.

Table of Tools for Milling

You MUST use the Table of Tools if you want to Automatically Probe the deck height and cut it to a set height.

Once done the Table of Tools Should look similar to the below picture.



The 100mm Probe is Tool 1. The 10" Fly Cutter is Tool 2.


Go to Program Select, then select the block you are working with and then Mill Mode.

Install the Probe physically into the spindle. Rotate the 4th axis to Zero degrees. Indicate the Middle flat on the head stock to be sure it is zero all the way across. There should be a number stamped into the headstock. This is the distance from the Flat to the center of the Crank. Bring the probe down until it just touches the middle flat.

Open the Table of Tools and double click on Tool1 100 mm Probe. Enter the Measured diameter of your Probe. This is not used in the Milling Program but needs to be entered accurately for Probing in the Bore mode.

On the open window select Get Length. This will open another Window. There will be a value, that you cannot edit, in the "Z Location from Zero" this is the distance the Vertical Axis is from home when the Probe touches the Middle flat.

In the Data box for "Z Touch off Height" enter the number that is stamped on the Head Stock. This is the distance from the flat to the center line of the Crank.



Select OK on both windows. This will put the Total tool length into the Table of Tools.


The Vertical Digital Read Out will now consider the center of the Crank bore to be the Vertical Zero position.

When the Probe tip or Cutting insert touches the Deck the Vertical DRO will be reading out the distance from the center of the Crank bore (Actual Deck Height).

Assigning Tools

From the Set Zero Tab, select Probe#. This will open the Tools Select Form. Select Tool 1, 100 mm Probe and click OK.

Select the Tool#. This will open The Tool Select Form. Select Tool 2, 10 inch Fly Cutter and click OK. The tools to be used have now been assigned to the program.



Setting Tools Active

To set a Tool Active (tool to be used) Press the Set Active button below that tool. Set the Probe Active. This will bring up the Tool Change Form. Here you can verify the information for the tool. Select OK. Select OK on the Spindle warning form if it appears.

The Probe# will now be highlighted in Pink, this indicates that the tool is active (being used). If you were to open the Table of Tools at this point, Tool 1 will be highlighted in Red. This also indicates that Tool 1 is active.



Building a Program Using Table of Tools

Enter all the values that were described in 3 and 4 Axis Milling earlier in the chapter.


Physically install the probe into the spindle and set active. Bring the probe down until it just touches the Deck. Look at the value in the Vertical DRO. This is the current deck height at position. Enter that numeric value into the Vertical Start. This gives the Probe a value to start probing the deck at.

Left Deck Probe

Enter the positions you want the Probe to probe here. You can physically move the probe to the locations on the bank you want to probe and hit the set button also.

Right Deck Probe

Roll the block over to the Right Bank. Enter the positions you want the Probe to probe here. You can physically move the probe to the locations on the bank you want to probe and hit the set button also.



Auto Probing

Press the Start Probing button. The machine will first probe each programmed location on the left bank and record the height. The spindle will move to Vertical Clearance height and the block will roll over to the right bank and probe the programmed locations and record them. The block will then roll back over to the Left bank and the spindle will move to the first Left location and stop.

Auto Milling

Go to the Operations Tab.

Vertical Start

Press Copy Highest next to Vertical Start. This will copy the Highest Probed point of either bank. This is the Height at which the Start Auto Cycle would start the first cutting pass.

Vertical End

Press Copy Highest next to Vertical Start. This will copy the Highest Probed point of either bank. This is the height at which the Start Auto Cycle would end the Final Pass. You would use this value if you just wanted to clean the deck up to the lowest point. If you want to cut the Deck Height to a certain value you would manually enter that value into the Vertical End Data Box.

Cut Left or Cut Right

Pressing either of these buttons will Start the Auto Cycle for only the associated bank. That bank will be cut to the set parameters and the machine will stop.

Start Auto Cycle


Pressing this button will start the Auto Cycle for Both Banks. First the Left bank will be cut to the set parameters. The spindle will go to the Clearance Height and Roll over to the Right bank and cut it to the set parameters. The Spindle will again go to the Clearance Height and roll over to the Left bank. The machine will go idle at this point.

Lifter Bore Mode 3 Axis

Lifter Bore programs are built the same as described in the Bore Mode 3 Axis. Only the differences will be discussed in this section.

In / Out Zero

The In/Out zero position for Lifters is the center line of the Cam Bore. An easy way to find the center of the cam line is to use the electronic probe. The following is an example of this procedure. Install the probe into the holder and the holder into the spindle. Bring the probe down until it is in the approximate center of the cam Bar Vertically. Press the Vertical Zero button now (this is only a temporary Vertical Zero position). Using the In/Out handwheel bring the probe up to the Cam Bar until it lights. Press the In/Out zero button here. Move the spindle up enough to clear the Cam Bar, move the probe to the other side of the Cam Bar. Bring the vertical down to the zero position. Hand wheel the probe into the Cam Bar until the light comes on. Note the In/Out position reading. Divide this reading by two. Bring the spindle up until it can clear the Cam Bar. Use the In/Out handwheel and move the In/Out position until it matches the divided number. This is the center line of the Cam Bar. Press the IN/Out Zero button now. The In/Out zero position has been set. The following illustration visual shows the above description.



Start Boring Height

Pay particular attention when setting this height, there are often protrusions in the casting that will not allow the End Mill to travel unobstructed all the way to the start of the lifter bore. It is safest to set the Start Boring Height above the Deck.

Lifter Bore Angle

Rottler has specific Lifter Bore spacers that are installed on the Cam bar to set the correct angle for lifter boring when using the Performance Fixture.

Lifter Bore 4th Axis

Lifter Bore programs are built the same as described in the Bore Mode 4th Axis. Only the differences will be discussed in this section.

Start Boring Height


Pay particular attention when setting this height, there are often protrusions in the casting that will not allow the End Mill to travel unobstructed all the way to the start of the lifter bore. It is safest to set the Start Boring Height above the Deck.

Lifter Bore Angle

The angle for each bank is located on the associated Locations page. Press the angle numerical value and a pop-up will open so you can type in the Lifter Bore angle.


Calculate In/Out

This button is located next to the In/Out Locations for each Bank. You must first have the Correct angle entered into the Angle data box. Then press the Calculate In/Out button. A window will open where you enter the center to center distance of the Cam to Crank bores. The In/Out locations will automatically be filled in.




Right Angle Drive Installation


Move the Rotate the inner spindle to position the keyway toward the left, in line with the outer spindle keyway notch. Press the tool release switch to compress the drawbar.



Rotate the RAD driveshaft so the drive key is pointing to the front or rear.



Carefully insert the RAD driveshaft into the inner spindle and lift the unit upward as far as it will go. Rotate the RAD output shaft until the driveshaft key is lined up with the inner spindle keyway. This will be visible through a small window on the left side of the RAD hub. At this point, the RAD will not fall out, so holding it in place is not required.




There are two adjustable keys on the RAD mounting hub that need to be lined up with the keyway notches of the outer spindle. It is not possible to see that these are aligned, so it is a little bit of trial and error when installing the unit. If the unit has never been installed on this particular machine, it would be best to temporarily remove these keys during the initial installation.

Before rotating the tool engage the drawbar to finish installing the unit, using a small shim under the inner spindle drive key in case it is not perfectly aligned to prevent bending of the key. A small flat screwdriver works well.

NOTE: Verify that the RAD hub is against the bottom face of the outer spindle. If not, the inner, or outer keys, are not lined up, repeat the prior procedure until it is correct.

At this point, the RAD must be aligned so that the hub face is 90° to the travel of the X axis. With an indicator touching the output face of the RAD, move the Y axis back and forth to see the amount of error.

There are two (2) adjusting set screws and an adjustment block on the RAD hub. The two set screws push against the adjustment block to turn the head left or right. The adjusting block is keyed to the outer spindle. The two screws mounting the adjusting block to the hub need to be slightly loose.



Start turning the set screw that will rotate the RAD in the direction you need to go. The set screws will rotate the unit counter clockwise or clockwise. The set screw will move the key on the adjusting block until it hits the keyway in the outer spindle. As you are turning one set screw you will need to keep the opposite set screw backed off, it will stop.

Final alignment results should be less than $.0005"$ ($.025\text{mm}$), or as close as possible.



Tighten the two hub clamping bolts located at the rear of the unit. Tighten to 30 ft. lbs. (41 N m) Recheck Alignment and re-adjust if necessary.

Line Bore Mode


Select the Line Bore button from the Main Menu. This will bring up the Line Bore Mode with the Set Zeros tab shown.

NOTE: Run the right angle drive for at least 15 minutes before boring due to drive growth. Colder climates may need to run the head longer.

Mounting and Aligning the 90 Degree Head

Mount the 90 degree head onto the spindle and tighten the mount bolt. Use the following instructions to align the head.

Mount a .001" or .0001" dial indicator to the machine table or block. The 90 degree head has two machined surfaces that can easily be used to align the head. The two surfaces and indicator positions are shown below.



Put some pressure on the indicator. Using the In/Out handwheel move the indicator from one side to the other noting the amount of difference. Keep the indicator on that side of the head and rotate it half of the noted distance. Repeat this procedure until there is less than .0005" variance.

Tighten the four mounting bolts for the head and check the surface again to be sure it did not shift when tightening the head.

Setting Zeros


The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis (except the Spindle rotation) will need to have a zero point set for the machine to operate from.

Horizontal Zero

The Horizontal should be set about .050" from the front of the first main to be bored, making sure that that position will allow the head to travel up without interference. Bring the head down and roughly center it in front of the first main. It does not need to be perfectly centered to set the horizontal zero. Press the Horizontal Zero button at this location.


In/Out and Vertical Zero

Locate the supplied Last Word indicator and small magnetic base. Mount on cutterhead as shown below.



Using the Horizontal handwheel move the indicator inside the main bore, making sure the indicator is not touching the main bore at this point. You will be indicating both sides and the bottom of the saddle, generally the cap is not used to indicate from.

Physically move the indicator and mag base on the cutterhead until there is about .010" pressure on it. Start rotating the spindle CW and CCW watching the indicator. As there is too much or too little pressure on the indicator, use the In/Out and Vertical handwheel to adjust the spindle in the bore until all three points are equal. Press the In/Out and Vertical zero buttons at this point.



The Vertical stops have now been set. You are finished with the Program Vertical Stops screen, select the next Tab to the Right.

Line Bore Options

When you create a line bore program you will be given option to allow Positive Horizontal values. Only check this if you need to bore in the +X, only used in special applications.

Set Zeros	Vertical Stops	Bore Locations
BORE PROFILE		Dwell Options
Block Clearance	<input type="text" value="8.0000"/> <input type="button" value="SET"/>	Dwell RPMS <input type="text" value="60.00"/>
Clearance Retract Angle	<input type="text" value="0.00"/>	Dwell Revolutions <input type="text" value="0.0000"/>
RAD Options		
Ratio	<input type="text" value="2.0000"/>	

Block Clearance

This stop is set at a positive value that will allow the 90 degree head to retract, in the Z-axis, and move over the top of the caps to the next main bore unobstructed. In the case that there is not enough clearance to go over the caps, "Clearance Retract Angle" can also be used.

Clearance Retract Angle

When "Block Clearance" is set to zero, the Z axis will move straight up. If set to 90, (degrees) the Y axis will move in, or out to go around the caps because they can't go over the top. The amount specified by the "Block Clearance" value +, or -, will determine the length, and direction the Y axis to clear the caps.

Any angle can be entered here, for example is 45 (degrees) is entered, Y-axis will move at a 45° & Z-axis will move up, simultaneously, to clear the caps.

Dwell RPMS

This is used when boring to a "step", maybe where an oil seal would be installed. RPM can be changed when it reaches the end of the "Bore Length" value to smooth out the finish of the step area.

Dwell Revolutions

Value entered will determine how many times the spindle rotates at the "Dwell RPM's" to give a satisfactory finish of the bore step

RAD options/Ratio

This is the gear ratio of the Right Angle Drive you are using. Many Rottler drives are 2:1 so there should be a 2.000 here.

Programming Vertical Stops

To build a program you must set the axis stop. The stops that are used in the Line bore mode are X,Y,Z.

The screenshot shows the 'Vertical Stops' programming screen in the Rottler Block Boring software. The interface includes a top status bar with 'Program: 350 Chevy' and 'Mode: Line Bore'. A 'LogMeIn - Remote Session' window is open. The main control area has several tabs: 'Set Zeros', 'Vertical Stops', and 'Bore Locations'. The 'Vertical Stops' tab is active, showing a table for programming five vertical stops (MOVE1 to MOVE5) for X, Y, and Z axes. The table includes fields for 'Set Temp Comp', 'Bore Length', and 'Deviation from MainLine'. Below the table are buttons for 'SET1' through 'SET5' and 'BORE1' through 'BORE5'. A 'HANDWHEEL' section is visible at the bottom left, and a 'GRAPH PROBED VALUES' section is at the bottom right, with buttons for 'START PROBING' and 'START AUTO CYCLE'.

	MOVE1	MOVE2	MOVE3	MOVE4	MOVE5
X	0.0000	-5.0000	-10.0000	-15.0000	-19.5000
Y	0.0000	0.0000	0.0000	0.0000	0.0000
Z	0.0000	0.0000	0.0000	0.0000	0.0000
Bore Length	-1.0000	-1.0000	-1.0000	-1.0000	-2.5000

Programming X Stop

The Horizontal Zero was set .050" before the first Main Bore, so the first Horizontal stop will be 00.000. Measure the distance between each main and enter it into the corresponding stop number.

Programming Y Stop (optional)

The in-out Zero is usually set and left to 0 when in Line Bore. In the rare case it is necessary to correct for misalignment on the y-axis, or a special offset type bore..

Bore Z Stop Centerline

The first vertical stop is on the main bore centerline. The vertical zero was set on the bore centerline. Therefore this stop will always be zero. This field should be used to account for minor variations in the block, .0005 -.005.

Programming Bore Length

Measure the length of each Main Bore and enter that value into the corresponding length box Deviation from main line.

Graph Probed Values

Used to give a visual picture of the actual main bore before and after

Running the Auto Cycle

You will need to set a Feed Rate and Spindle RPM on the Set Zeros screen to run an auto cycle. The spindle will move up the Block Clearance distance as entered on the “Vertical Stops “ page, move to the horizontal bore location, then will then move down to the zero position, spindle will start and feed to the “Bottom of Bore” length, retract horizontally out of the bore, go back up to “Block Clearance, move horizontally over to the next bore etc.

If you press the MOVE buttons or the Cycle Start button the machine will not move the In/Out axis to the zero position. You need to move the In/Out axis to the zero position manually before you press Cycle Start.

CAUTION

The machine will go idle at this time. Pressing the “Start Auto Cycle” button will cause the entire cycle to run.

After a program has been completed the machine will move the spindle over to the first Main Bore at the clearance distance.

Thrust Cutting

Refer to Line Bore in this section for mounting the block and aligning the 90 degree head.

Note: It is important to read through the entire Thrust Bearing Cutting section before entering any values or starting the Auto Cycle. You will better understand how the program operates and how the values affect the operation of the Auto Cycle.

The Thrust Cutting program can cut a single or double thrust face using circular interpolation.

Select the Thrust Bearing Cutting button from the Main Menu. This will bring up the Thrust Bearing Cutting Bore Mode with the Set Zeros tab shown.



Setting Zeros

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis (except the Spindle rotation) will need to have a zero point set for the machine to operate from.

Horizontal Zero

To set the Horizontal Zero, bring the cutter in using the Horizontal Hand Wheel until it just touches off the current thrust face. Press the Horizontal Zero Button here. The computer will use this zero point when cutting the depth of the thrust face.

Follow the procedure for setting zeros in the Line Bore Mode section of this chapter. Set the Horizontal zero on the Main Bearing that is to have the Thrust cut.

After the zeros have been set select the nest tab to the right, Dimensions.

Dimensions & Auto Cycle

There are several values that need to be set on this screen for the program to operate properly. Below is illustration and a description of each of these values.

The screenshot shows the 'Rottler Block Boring' control interface. At the top, it displays 'Program: Chevy 350' and 'Mode: Thrust Cutting'. Below this are three tabs: 'CHANGE TOOL', 'Set Zeros', and 'Program'. The 'Program' tab is active, showing three panels: 'Thrust Diameters', 'Clearances', and 'Dimensions'. The 'Thrust Diameters' panel has fields for 'Outside' (3.0000), 'Inside' (2.8000), and 'Cutter' (0.1000). The 'Clearances' panel has fields for 'Z' (5.0000), 'X' (0.1000), and 'Feed Through Rate' (10.0000). The 'Dimensions' panel has fields for 'Main Width' (1.0000), 'Insert Width' (0.2500), 'Left Depth of Cut' (0.0010), and 'Right Depth of Cut' (0.0010). On the left side, there is a 'PROGRAM SELECT' panel with buttons for X-, X+, Y+, Z+, Y-, Z-, CW, CCW, A-, and A+. At the bottom left is a red 'STOP MACHINE' button. On the right side, there are three green buttons: 'CUT LEFT SIDE', 'CUT RIGHT SIDE', and 'CUT BOTH SIDES'. At the top right, there are 'Continuous DTG' (0.000) and 'Feedrate override' (1.00) buttons, and a table with values for Z, X, Y, and A.

Continuous DTG	0.000	Z	0.0000	Y	0.0000
Feedrate override	1.00	X	0.0000	A	0.000

Thrust Dimensions

Outside

This is the Outside dimension of the thrust face to be machined.

Inside

This is the Inside dimension of the thrust face to be machined.

Cutter

This is the radius, from the center of the 90 degree head to the tip of the insert.

Clearances

Vertical

This is the distance, from zero, the 90 degree head will have to travel up to clear the main caps on the block.

Horizontal

This is the distance, from zero, the 90 degree head will have to travel to clear the main for the next vertical move.

Dimensions

Main Width

Width of the Main.

Insert Width

Width of the Insert.

Left Depth of Cut

Depth of left cut.

Right Depth of Cut

Depth of right cut.

Cut Right Side

If you select Cut Right Side the automatic cycle will cut the thrust face on the right hand side of the Main.

Cut Left Side

If you select Cut left Side the automatic cycle will cut the thrust face on the left hand side of the Main.

Description and Running of the Auto Cycle

You will need to enter the Feed Rate and Spindle RPM the program will run at.

There are no Move to buttons in this program. You MUST be at the zero positions when the Auto Cycle is started.

Start Auto Cycle


When you are at the zero positions press the Auto Cycle, the spindle will start at the programmed RPM. The vertical feed will start at the programmed rate in an upward direction until the correct Outside diameter is reached. The circular interpolation will start at this point and go 360 degrees. It will then continue the circular interpolation back towards the center of the Main to clear the cutting tool from the thrust face. When the cutterhead is back at the center point (zero positions) of the Main, all motion will stop. The cutterhead will then rapid travel to the left taking the main width and the cutter diameter into account to reach the correct depth on the second thrust face. The same circular interpolation process will then be repeated for the second face. The cutterhead will then retract horizontally to the clearance distance then vertically to the block clearance distance.

When the program is running the "Start Auto Cycle" button will change to "Press to Pause". If this button is pressed the machine will pause the program right where it is. At this point the screens are locked out from changing anything. The button will change to "Press to Resume". If you want to resume press the button and the program will continue from that point on. If you do not wish to continue press the "Stop" button. This will put the machine back in idle mode and changes can be made to the program.

Backing Up and Restoring Block Profiles

This section will explain how to back up and restore the operator created block profiles for DM controlled machines for archival purposes or to transfer to a different machine.


First step is to open your file browser and locate the RottlerWPF file on the C disk drive.




The next step is to plug in a flash drive to an open USB port




The following pop up box will appear on your screen.




Click on the Open folder to view files option and the following screen will appear. This is the contents of the flash drive you just plugged in.



Next resize and arrange both file browsers so that they are side by side.




Block profiles are backed up each time the machine is run with the current profiles being shown in the RottlerWPF folder. All that needs to be done to back up the current profile is to simply drag it from the RottlerWPF folder to the flash drive folder. A copy of the file will be placed on the flash drive.




Backup is now complete. Close both file browser windows and remove the flash drive.

To restore or add block profiles go through the first 5 steps explained previously.


Highlight the block profiles file in the flash drive and drag it into the RottlerWPF folder on the local hard drive.



You will get a pop up window about there being a file of the same name in the destination folder. Click on the Copy and Replace option.



The archived block profiles will now be installed.



Close both browser windows and remove the flash drive. The restore process is now complete.

MAINTENANCE

Contents

Quick Reference Lubrication Chart: F103/4/5A	6-1
Quick Reference Preventative Maintenance Chart: F103/4/5A.....	6-1
Grease Cross Reference Chart	6-2
Maintenance.....	6-6
Lubrication	6-6
Outer Spindle	6-6
Upper Belt Housing	6-6
Oil Reservoir System	6-7
Inner Spindle Bearings	6-7
Vertical Ballscrew Bearings.....	6-7
Priming Spindle Base Oil Lines	6-8
Lubrication Locations	6-9
Right Angle Drive Lubrication Information	6-11
Air Line Diagram.....	6-12
F103/4/5A Wiring Diagram	6-13
ELO Alignment.....	6-14
Magnescale Indicator Set Up.....	6-16
Spindle Drive Belt Replacement / Adjustment.....	6-17
Outer Spindle Bushing Adjustment.....	6-22
Upper Bushing Adjustment.....	6-23
Inner Spindle Adjustment	6-24
F103/4/5A Upper Housing Disassembly	6-28
F103/4/5A Inner Spindle Removal	6-31
Inner Spindle Angular Contact Bearing Replacement	6-31
Spindle Sweep	6-33
Horizontal Gibs	6-34

Adjusting Y-Axis Gibs	6-36
Adjustment Procedure	6-37
Backlash Setting .NET Software	6-38
Spindle Belt Adjustment	6-47
Top and Side Rail Adjustment	6-48
Mill Tilt Adjustment Procedure	6-49
Checking Wear on Column Turcite Pads.....	6-51
Digital Micrometer setting instructions	6-53
To set or edit micrometer	6-54
Probe “On-Center” Adjustment.....	6-58
Replacing the Motherboard Battery.....	6-62
Ballscrew Assemblies Reference	6-65
Alignment Definitions for Angular Bearings and Belleville Washers	6-65
Bearing Alignment	6-65
Belleville Washer Alignment	6-65
Z-Axis Lower Bearing and Belleville Washer Stacking Order	6-66
Z-Axis Lower Bearing and Belleville Washer Section View.....	6-67
Z-Axis Upper Belleville Washer Stacking Order	6-68
Z-Axis Upper Belleville Washer Section View	6-68
X-Axis Drive Side Bearing Stacking Order.....	6-69
X-Axis Drive Side Bearing Section View.....	6-69
X-Axis Idle Side Bearing Stacking Order	6-70
X-Axis Idle Side Bearing Section View.....	6-70
Y-Axis Bearing Stacking Order	6-71
Y-Axis Bearing Section View.....	6-71
Inner Spindle Upper Section Belleville Washer Stacking Order	6-72
Inner Spindle Upper Section Belleville Washer Section View	6-72
Inner Spindle Lower Section Bearing Stacking Order	6-73
Inner Spindle Lower Section Bearing Section View.....	6-74

Quick Reference Lubrication Chart: F103/4/5A

Refer to the maintenance section in the manual for lubrication location points and instruction.

Assembly	Frequency	Lube Operation	Recommended Lubricant	Date Serviced
Outer Spindle	8 Hours	Wipe with oil	ISO VG 68 Way Oil	
	1000 Hours	Soak felt wiper with oil		
Oil Reservoir System	8 Hours	Check upper oil lines are full	ISO VG 68 Way Oil	
	175 Hours	Fill reservoir with oil if needed		
Upper Vertical Ballscrew Pillow Block Bearing	175 Hours	Grease	NLGI 2 White Lithium Grease	
Lower Vertical Ballscrew Bearing Pack	175 Hours	Grease	NLGI 2 White Lithium Grease	
Rear Y Axis Bearing Housing Grease Fitting	175 Hours	Grease	NLGI 2 White Lithium Grease	
Column Feed Gear Housing	1000 Hours	Fill with oil	GL-5 or MT-1 80W-90 Gear Oil	

Quick Reference Preventative Maintenance Chart: F103/4/5A

Refer to the procedures in the maintenance section of the manual to make or check these adjustments. Not all of the items listed in the table below have adjustment. The information should be recorded and the amount of wear tracked so the part can be replaced before down time on the machine occurs.

Procedure	Frequency	Date Serviced/Comments
Spindle Sweep Adjustment	150 Hours	
Outer Spindle Bushing Adjustment	500 Hours	
Spindle Tilt Measurement	500 Hours	
Inner Spindle Bearing Adjustment	1000 Hours	
Horizontal Gib(s) Adjustment	1000 Hours	
X,Y,Z Auto Mode Backlash Adjustment	1000 Hours	
X,Y,Z Handwheel Backlash Adjustment	1000 Hours	
Electrical Enclosure Air Filter Replacement	1000 Hours	
Machine Level Adjustment	1000 Hours	
Spindle Drive Belt Adjustment	1000 Hours	
Vertical Drive Belt Adjustment	1000 Hours	
Horizontal Ballscrew Inspection	2000 Hours	
Spindle Wear Measurement	2000 Hours	
Horizontal Way Wear Measurement	2000 Hours	

Grease Cross Reference Chart

DO AND LUB SYMBOLS	APPLICATION FIELD	Agip	api	ARAL	ARCO	barelli	bellini	BERGOLINE	BP	BRYTOL INDUSTRIALS	Castrol	Chevron
AM 48	LUBRICANT, LOADS	INSULA 85 ACER 90	API MF 48 API CF 32 API CF 48 API CF 68 API MF 150 API CF 180	ARAL DURAL 48 08 ARAL DURAL 48 18 ARAL VITAM 48 08 ARAL VITAM 48 18 ARAL DURAL 48 150 ARAL DECOL 70 150	GLASCO 48 RUBLENE 32 RUBLENE 68 RUBLENE 150 PENNANT M. 150 PENNANT M. 300 PENNANT M. 400	MVN 68 MTKIDS 32 MTKIDS 68 MTKIDS 150 G.E.P. 150 G.E.P. 300 G.E.P. 460	TRASMISSION 68 SPRINTER AS 32 SPRINTER AS 68 SPRINTER AS 150 RED FM 150 RED FM 300 RED FM 460	ACCA 68 BERGOLINE 32 PARAMETER 5 32 BERGOLINE 68 PARAMETER 5 68 BERGOLINE 150 PARAMETER 5 150	CS 68 ENERGOL CS 32 ENERGOL CS 52 ENERGOL CS 150 ENERGOL DRAP 90 ENERGOL DRAP 20 ENERGOL DRAP 40	CM 68 CMC 32 CMC 68 CMC 150 DENTOL EP 150 DENTOL EP 300 DENTOL EP 400	MAGNA 68 MAGNA 32 PERFECTO T32 MAGNA 68 PERFECTO T88 MAGNA 150 ALPHA SP 150 ALPHA SP 320 ALPHA SP 460	CIRCULATING OIL 68 CIRCULATING OIL 46 GOT OIL 46 CIRCULATING OIL 68 GOT OIL 68 CIRCULATING OIL 150 GOT OIL 150 M. GEAR COMPOUND 150 M. GEAR COMPOUND 300 M. GEAR COMPOUND 460 MECHANISMS 15
FM 6	SPINDLES, BEARINGS AND COUPLED CLUTCHES	OSD 16 OSD 16 OSD 15	API DS 10 API CS 32	ARAL DURAL SR 5 ARAL DURAL SR 10 ARAL DURAL SR 32	DURO OIL 10 DURO OIL 10 DURO OIL 32	VELO 6 A 16 VELO 6 A 16 TIARO 32	SPRINTER ADV 5 SPRINTER ADV 10 SPRINTER ADV 32	BERGOLINE 5 ENERGOL 10 BERGOLINE 32	ENERGOL HP 5 ENERGOL HP 10 ENERGOL HP 22	AFOS 5 MOTROL 10 MOTROL 22	MAGNA AB 5 HYSPIN AWS 10 HYSPIN AWS 22	MECHANISMS 15
G 32		EXDIA 32	API MX 32	TRUSLIDE 32	TRUSLIDE 32	TIARO BK 32	WAY 32	ENGINE K 32	ENERGOL GHL 32	VITAK 32 AS 32	MAGNA CD 32	VISTAC OIL 32K
G 46	GLIDES	EXDIA 68	API MX 68	ARAL DEGANT B 68	TRUSLIDE 68	M.P. 68	WAY 68	ENGINE K 68	MACOLRAT 68 ENERGOL GHL 68	VITAK 68 AS 68	MAGNA ED 68 MAGNA BD 1 68	VISTAC OIL 68K
G 220		EXDIA 220	API MX 220	ARAL DEGANT B 220	TRUSLIDE 220	M.P. 220	WAY 220	ENGINE K 220	MACOLRAT 220 ENERGOL GHL 220	VITAK 220 AS 220	MAGNA CF 220 MAGNA CF 3 220	VISTAC OIL 220K
HM 32		OSD 32	API CS 32	ARAL VITAM 48 32	DURO OIL 48 32	TIARO 32	SPRINTER ADV 32	PARAMETER 5 32 PARAMETER 5 48 PARAMETER 5 68 PARAMETER 5 150	ENERGOL HP 32 ENERGOL HP 48 ENERGOL HP 68 ENERGOL HP 150	AFOS 32 HYDRO 32 AFOS 48 HYDRO 48 AFOS 68 HYDRO 68	HYSPIN AWS 32 HYSPIN AWS 46 HYSPIN AWS 68 HYSPIN AWS 150	MECHANISMS 32 MECHANISMS 46 MECHANISMS 68 MECHANISMS 150
HM 46	HYDROSTATIC SYSTEMS	OSD 46	API CS 46	ARAL VITAM 48 46	DURO OIL 48 46	TIARO 46	SPRINTER ADV 46	PARAMETER 5 46	ENERGOL HP 46	AFOS 46 HYDRO 46	HYSPIN AWS 46	MECHANISMS 46
HM 68		OSD 68	API CS 68	ARAL VITAM 48 68	DURO OIL 48 68	TIARO 68	SPRINTER ADV 68	PARAMETER 5 68	ENERGOL HP 68	AFOS 68 HYDRO 68	HYSPIN AWS 68	MECHANISMS 68
MG 32	HYDRAULIC SYSTEMS AND GUIDES	EXDIA 32	API CS 32 EP	TRUSLIDE 00F	TRUSLIDE 00F	TIARO BK 32	WAY 32 WAYCUT N 32	ENGINE K 32	ENERGOL GHL 32	VITAK 00F	MAGNA DC 32	VISTAC OIL 32K
MG 68		EXDIA 68	API CS 48 EP	ARAL DEGANT B 08	TRUSLIDE 68	TIARO BK 68	WAY 68 WAYCUT N 68	ENGINE K 68	ENERGOL GHL 68	VITAK 68	MAGNA AX 68	VISTAC OIL 68K
G 32		GR 100 EP 1	API GREASE PGK 1	ARAL ARUBUS HL 1	LUTHOLINE HENGAR 1	LITRO EP 1	GREASE U EP 1	RULTEN 100 EP 1	GREASE LTX 1 GREASE LTX EP	BRV GREASE LT 1 BRV GREASE LTX EP	SPHEREOL APT 1 SPHEREOL EP 1	DURALITH GREASE EP 1
G 46	MULTI FUNCTIONING GREASES	GR 100 EP 2	API GREASE PGK 2	ARAL ARUBUS HL 2	LUTHOLINE HENGAR 2	LITRO EP 2	GREASE U EP 2	RULTEN 100 HS EP 2	GREASE LTX 2 GREASE LTX EP	BRV GREASE LT 2 BRV GREASE LTX EP	SPHEREOL APT 2 SPHEREOL EP 2	DURALITH GREASE EP 2
G 220		GR 100 EP 3	API GREASE PGK 3	ARAL ARUBUS HL 3	LUTHOLINE HENGAR 3	PUBIT 1	GREASE U EP 3	RULTEN 100 HS EP 3	GREASE LTX 3 GREASE LTX EP	BRV GREASE LT 3 BRV GREASE LTX EP	SPHEREOL APT 3 SPHEREOL EP 3	DURALITH GREASE EP 3

ISO AND UNI SYMBOLS	APPLICATION FIELD	COMLUBE	elf	ESSO	EURAL	FINA	FUCHS	IGLA	ITALIANA PETROLI	KLOBER LUBRICATION	LEVENIT	LUBRA
AN 68	LUBRIFICAT. LOSS	LG AN 68	MOVIXA 68	NURAY 68	EPAL 68	ARIAN 68	RENOLIN 68	BEARING 68	IP ARIOLA OIL 68	CRUCOLAN 68	BETA 52/68	INDUSTRIAL 68
CB 32	GEARS MODERATELY CHARGED	OLEOL HH CB 32	POLYTELIS 32	TERESSO 32 NUTO 32	BRIGHT 32	SOLINA 32	RENOLIN 32	FILETE V 32 PRESTAN 32	IP HERMEA OIL 32 IP HYDRUS OIL 32	CRUCOLAN 32	BETA 30/32	OLNEO 32
CB 68		OLEOL HH CB 68	POLYTELIS 68	TERESSO 68 NUTO 68	BRIGHT 68	SOLINA 68	RENOLIN 68	FILETE V 68 PRESTAN 68	IP HERMEA OIL 68 IP HYDRUS OIL 68	CRUCOLAN 68	BETA 52/68	OLNEO 68
CB 150		OLEOL HH CB 150	POLYTELIS 150	NUTO 150	BRIGHT 150	SOLINA 150	RENOLIN 150	RENOLIN 150	FILETE V 150 PRESTAN 150	IP HERMEA OIL 150 IP HYDRUS OIL 150	CRUCOLAN 150	BETA 120/150
CC 150	GEARS VERY CHARGED	OLGEAR EP CC 150	REDUCTELF SP 150	SPARTAN EP 150	ELTON EP 150	GIRAN 150	RENOLIN MR 1	FILETE V 5	IP MELLANA OIL 150	LAMORA 150	DELTA EP 118/150	DACTA EP 150
CC 320		OLGEAR EP CC 320	REDUCTELF SP 320	SPARTAN EP 320	ELTON EP 320	GIRAN 320	RENOLIN MR 3	FILETE V 10	IP MELLANA OIL 320	LAMORA 320	DELTA EP 230/320	DACTA EP 320
CC 460		OLGEAR EP CC 460	REDUCTELF SP 460	SPARTAN EP 460	ELTON EP 460	GIRAN 460	RENOLIN MR 5	FILETE V 22	IP MELLANA OIL 460	LAMORA 460	DELTA EP 320/460	DACTA EP 460
FD 5	SPINDLES, BEARINGS AND COUPLED CLUTCHES	OLEOL HM FD 5	SPINELF 5	NUTO H 5	NEDEL 5	HYDRAN 10	RENOLIN 1	NOOROP V 32	IP HYDRUS OIL 05	CRUCOLAN 5	VELOX 13/05	OLEODIN 5 OLNEO HLP 5
FD 10		OLEOL HM FD 10	SPINELF 10	SPINESSO 10	NEDEL 10	HYDRAN 10	RENOLIN MR 3	FILETE V 10	IP HYDRUS OIL 10	CRUCOLAN 10	VELOX 15/10	OLEODIN 10 OLNEO HLP 10
FD 22		OLEOL HM FD 22	SPINELF 22	SPINESSO 22	NEDEL 22	HYDRAN 22	HYDRAN 22	RENOLIN MR 5	FILETE V 22	IP HYDRUS OIL 22	CRUCOLAN 22	VELOX 20/15
G 32	GUIDES	WAY LUBE EP G 32	MOGLIA 32	FEBIS K 32	ARIF T 32	HYDRAN G 32	RENOLIN 1	NOOROP V 68	IP BANTIA OIL HG 32	LAMORA SUPER POL ADD 32	ALPHA 29/32	SLEDOL 32
G 68		WAY LUBE EP G 68	MOGLIA 68	FEBIS K 68	ARIF T 68	HYDRAN G 68	RENOLIN 2	RENEP 2	IP BANTIA OIL HG 32	LAMORA SUPER POL ADD 68	ALPHA 52/68	SLEDOL 68
G 220		WAY LUBE EP G 220	MOGLIA 220	FEBIS K 220	ARIF T 220	HYDRAN G 220	HYDRAN G 220	RENOLIN 5	NOOROP V 220	IP BANTIA OIL G 220	LAMORA SUPER POL ADD 220	ALPHA 150/220
HM 32	HYDROSTATIC SYSTEMS	OLEOL HM 32	ELFOLNA 32	NUTO H 32 NUTO HP 32	HYDER 32	HYDRAN 32	RENOLIN B 32	FILETE V 32	IP HYDRUS OIL X 32	LAMORA 32	HYDROLUBE 30/32	OLEODIN 32 OLNEO HLP 32
HM 46		OLEOL HM 46	ELFOLNA 46	NUTO H 46 NUTO HP 46	HYDER 46	HYDRAN 46	RENOLIN B 46	FILETE V 46	IP HYDRUS OIL X 46	LAMORA 46	HYDROLUBE 40/46	OLEODIN 46 OLNEO HLP 46
HM 68		OLEOL HM 68	ELFOLNA 68	NUTO H 68 NUTO HP 68	HYDER 68	HYDRAN 68	RENOLIN B 68	FILETE V 68	IP HYDRUS OIL X 68	LAMORA 68	HYDROLUBE 50/68	OLEODIN 68 OLNEO HLP 68
HG 32	HYDRAULIC SYSTEMS AND GUIDES	OLEOL HG 32	HYGLISS 32	FEBIS K 32	TERCAL 32	HYDRAN G 32	RENOLIN 1	FILETE VE 32	IP BANTIA OIL HG 32	LAMORA 32	HYDROLUBE EP 30/32	SLEDOL GC 32
HG 68		OLEOL HG 68	HYGLISS 68	FEBIS K 68	TERCAL 68	HYDRAN G 68	RENOLIN 3	FILETE VE 68	IP BANTIA OIL HG 68	LAMORA 68	HYDROLUBE EP 50/68	SLEDOL GC 68
G 32		LHITGREASE XM 1	ROLEXA 1 EPEXA 1	BEACON EP 1	LITNER EP 1	MARSON EPL 1	RENOLIT 1	VEGA 1	IP ATHESIA GR 1 IP ATHESIA GREP 1	CENTOPLEX 1 EP CENTOPLEX 1 EP	LITGREASE EP 1	ROLLER EP 1
G 68	MULTI FUNCTIONING GREASES	LHITGREASE XM 2	ROLEXA 2 EPEXA 2	BEACON 2 ESSO GP GREASE	LITNER EP 2	MARSON EPL 2	RENOLIT 2 RENOLIT FEP 2	VEGA 2	IP ATHESIA GR 2 IP ATHESIA GREP 2	CENTOPLEX 2 EP CENTOPLEX 2 EP	LITGREASE EP 2	ROLLER EP 2
G 220		LHITGREASE XM 3	ROLEXA 3	BEACON 3	LITNER EP 3	MARSON EPL 3	RENOLIT 3 RENOLIT FEP 3	VEGA 3	IP ATHESIA GR 3 IP ATHESIA GREP 3	CENTOPLEX 3 EP CENTOPLEX 3 EP	LITGREASE EP 3	ROLLER EP 3

ISO AND UNI SYMBOLS	APPLICATION FIELD	Shell	ROLOIL	REINACH	Q8	ASTROL CAVTEX	Persian oil	eliotecnica	Mobil	Shell	SAFOL	SPRING OIL
AN 68	LUBRIFICAT. LOSS	TECNOL 68	MILPAR 68	VERDI 68	CASTOR 68	REGULUS 32 LAMBISHHY 32	VITROL 68	MILPAR 68	RUBREX 400	MACHINERY 68	SINLUBE 68	NURAX 68
CB 32	GEARS	VITROL 32	TURBO 32	VERDI 32	REGULUS 68 LAMBISHHY 68	REGULUS 68 LAMBISHHY 68	VITROL 68	TURBO 68	MOBIL VACTRA OIL No. 1	TELEDINAX 32	SINLUBE GR 32	ENGINE SPECIAL 32
CB 68	MODERATELY CHARGED	VITROL 68	TURBO 68	VERDI 68	REGULUS 150	REGULUS 150	VITROL 150	TURBO 150	MOBIL VACTRA OIL HEAVY MEDIUM	TELEDINAX 68	SINLUBE GR 68	ENGINE SPECIAL 68
CB 150		VITROL 150	TURBO 150	VERDI 150	REGULUS 400	REGULUS 400	VITROL 150	TURBO 150	MOBIL VACTRA OIL EXTRA HEAVY	TELEDINAX 150	SINLUBE GR 150	ENGINE SPECIAL 150
CC 150	GEARS VERY CHARGED	REDOIL EP 150	ROTO EP 150	GOYA 150	TAURUS WRP 150	TAURUS WRP 150	REDOIL EP 150	ROTO EP 150	MOBIL GEAR 629	OMALA OIL 150	SINLUBE GRS 150	GEAR 150/EP
CC 320		REDOIL EP 320	ROTO EP 320	GOYA 320	TAURUS WRP 320	TAURUS WRP 320	REDOIL EP 320	ROTO EP 320	MOBIL GEAR 632	OMALA OIL 200	SINLUBE GRS 320	GEAR 320/EP
CC 460		REDOIL EP 460	ROTO EP 460	GOYA 460	TAURUS WRP 400	TAURUS WRP 400	REDOIL EP 460	ROTO EP 460	MOBIL GEAR 634	OMALA OIL 460	SINLUBE GRS 460	GEAR 460/EP
FD 5	SPINDLES BEARINGS AND COUPLED CLUTCHES	IDROL 10	VELOX 5	ORION 5	ORION 5	ORION 5	IDROL 10	VELOX 5	MOBIL VELOCITE OIL No. 4	TELLUS OIL C5	SINLUBE 5	FUSING HD 10
FD 10		IDROL 10	VELOX 10	ORION 10	ORION 10	ORION 10	IDROL 10	VELOX 10	MOBIL VELOCITE OIL DTE 21	TELLUS OIL C10	SINLUBE 10	FUSING HD 10
FD 22		IDROL 22	VELOX 22	SIRIUS H 22	SIRIUS H 22	SIRIUS H 22	IDROL 22	VELOX 22	MOBIL VELOCITE OIL DTE 22	TELLUS OIL C22	SINLUBE 22	FUSING HD 22
G 32		ARCOIL S 32	LUBEX K 32	GEMINI CS 32	GEMINI CS 32	GEMINI CS 32	ARCOIL S 32	LUBEX K 32	MOBIL VACTRA OIL No. 103	TONNA OIL T 32	SINLUBE SL 32	SLIDE 32/K
G 68	GUIDES	ARCOIL S 68	LUBEX K 68	GEMINI SW 68	GEMINI SW 68	GEMINI SW 68	ARCOIL S 68	LUBEX K 68	MOBIL VACTRA OIL No. 2	TONNA OIL T 68	SINLUBE SL 68	SLIDE 68/K
G 220		ARCOIL S 220	LUBEX K 220	GEMINI SW 220	GEMINI SW 220	GEMINI SW 220	ARCOIL S 220	LUBEX K 220	MOBIL VACTRA OIL No. 4	TONNA OIL T 220	SINLUBE SL 220	SLIDE 220/K
HM 32	HYDROSTATIC SYSTEMS	IDROL 32	MOVVO H 32	SIRIUS H 32	SIRIUS H 32	SIRIUS H 32	IDROL 32	MOVVO H 32	MOBIL DTE 24	TELLUS OIL 32	SINYDRO 32	ENGINE SPECIAL 32
HM 46		IDROL 46	MOVVO H 46	SIRIUS H 46	SIRIUS H 46	SIRIUS H 46	IDROL 46	MOVVO H 46	MOBIL DTE 25	HYDRAULIC OIL 32	SINYDRO 46	ENGINE SPECIAL 46
HM 68		IDROL 68	MOVVO H 68	SIRIUS H 68	SIRIUS H 68	SIRIUS H 68	IDROL 68	MOVVO H 68	MOBIL DTE 26	HYDRAULIC OIL 46	SINYDRO 68	ENGINE SPECIAL 68
HG 32	HYDRAULIC SYSTEMS AND GUIDES	ARCOIL S 32	LUBEX K 32	GEMINI CS 32	GEMINI CS 32	GEMINI CS 32	ARCOIL S 32	LUBEX K 32	MOBIL VAQUOLINE OIL 1405	TONNA OIL T 32	SINLUBE SL 32	SLIDE 32/K
HG 68		ARCOIL S 68	LUBEX K 68	GEMINI CS 68	GEMINI CS 68	GEMINI CS 68	ARCOIL S 68	LUBEX K 68	MOBIL VAQUOLINE OIL 1409	TONNA OIL T 68	SINLUBE SL 68	SLIDE 68/K
G 32	MULTI FUNCTIONING GREASES	LT GREASE 1	LITEK EP 1	REMBRANDT EP 1	LIBRA GREASE 1	LIBRA GREASE 1	LT GREASE 1	LITEK EP 1	MOBILPLEX 46	A'WINA EP GREASE SUPER GREASE EP1	G EP 1	UNIVERSAL EP1
G 68		LT GREASE 2	LITEK EP 2	REMBRANDT EP 2	LIBRA GREASE 2	LIBRA GREASE 2	LT GREASE 2	LITEK EP 2	MOBILPLEX 47	A'WINA GREASE R2 SUPER GREASE R2	G EP 2	UNIVERSAL EP2 SERVICE2
G 220		LT GREASE 3	LITEK EP 3	REMBRANDT EP 3	LIBRA GREASE 3	LIBRA GREASE 3	LT GREASE 3	LITEK EP 3	MOBILPLEX 48	A'WINA GREASE R3 SUPER GREASE R3	G EP 3	SERVICE3


ISO AND UNI SYMBOLS	APPLICATION FIELD	SYNBOCO	TAMOIL	TEMNEX	★	TOTAL	Vabtritol	VALVOLINE	Vanguard	VASCOL	WEBER	WZADOil
AN 68	LUBRIFCATION LOSS	HYDRAULIC N 68	TAMLUBE OIL 68	VERTEX 68	OMNIS 68 ALCAID OIL 60	CORTIS 68	METIX 68	CIR 68	KOMOL ST 68	SIGNAL TR 68 (5)	WEBER WESCOM 68	ENGINE 68
CB 32	GEARS	PACEMAKER ROD 3	INDUSTRIAL OIL 32	CONTEX 32	OMNIS 32 RANCO OIL HD 32	CORTIS 32 AZOLLA ZS 32	METRA 32	CIR 32	KOMOL ST 32	SIGNAL VU 32 (3)	WEBER WA 32	ENGINE RE 32
CB 68	MODERATELY CHARGED	PACEMAKER ROD 5	INDUSTRIAL OIL 68	CONTEX 68	OMNIS 68 RANCO OIL HD 68	CORTIS 68 AZOLLA ZS 68	METRA 68	CIR 68	KOMOL ST 68	SIGNAL VU 68 (5)	WEBER WA 68	ENGINE RE 68
CB 150		PACEMAKER ROD 12	INDUSTRIAL OIL 150	CONTEX 150	OMNIS 150 RANCO OIL HD 150	CORTIS 150 AZOLLA ZS 150	METRA 150	CIR 150	KOMOL ST 150	SIGNAL VU 150 (10)	WEBER WA 150	ENGINE RE 150
CC 150	GEARS VERY CHARGED	PACEMAKER ROD 12	CHATTERFLUR 150	FACTOR 150	MEROPA 150	CARTER EP 150	GEARLUBE EP 150	GEAR EP 150	GEARING EP 150	SIGNAL V.U.EP 150 (70)	WEBER FARGO EP 150	ENGINE E P 150
CC 320		PACEMAKER ROD 24	CHATTERFLUR 320	FACTOR 320	MEROPA 320	CARTER EP 320	GEARLUBE EP 320	GEAR EP 320	GEARING EP 320	SIGNAL V.U.EP 320 (22)	WEBER FARGO EP 320	ENGINE E P 320
CC 460		PACEMAKER ROD 32	CHATTERFLUR 460	FACTOR 460	MEROPA 460	CARTER EP 460	GEARLUBE EP 460	GEAR EP 460	GEARING EP 460	SIGNAL V.U.EP 460 (27)	WEBER FARGO EP 460	ENGINE E P 460
FD 5	SPINDLES, BEARINGS AND COUPLED CLUTCHES			ECTON 5	300 OIL 5		RINOL 5	ETC 5	KOMOL SVR 5	SIGNAL ELUROS 5 (12)	WEBER W.L. 10	ENGINE HY SY 05B
FD 10				ECTON 10	SPRINTEX OIL 10	AZOLLA ZS 15	RINOL 10	ETC 10	KOMOL SVR 10	SIGNAL CO 10 (1)	WEBER W.L. 15	ENGINE HY SY 10B
FD 22				ECTON 22	SPRINTEX OIL 22	AZOLLA ZS 15	RINOL 22	ETC 22	KOMOL SVR 22	SIGNAL CO 22 (2)	WEBER W.L. 22	ENGINE HY SY 22B
G 32		PACEMAKER ROD 3	TAMWAY OIL 32	BARTON 11		DROSERA MS 32	METRA K 32	GES 32	C.O. SPECIAL 32	SIGNAL V.U.U 32 (3)	WEBER WAY 32	ENGINE HD T 02
G 68		PACEMAKER 55	TAMWAY OIL 68	BARTON 20	WAYLUBRICANT 68	DROSERA MS 68	METRA K 68	GES 68	STOL 68	SIGNAL V.U.SG 68 (5)	WEBER WAY 68	ENGINE HD T 08
G 220		PACEMAKER 80	TAMWAY OIL 220	BARTON 44	WAYLUBRICANT 220	DROSERA MS 220	METRA K 220	GES 220	STOL 220	SIGNAL V.U.SG 220 (12)	WEBER WAY 220	ENGINE HD T 20
HM 32		PACEMAKER 32	HYDRAULIC OIL 32	ECTON 32	RANCO OIL HD 32	AZOLLA ZS 32	GAMMA X 32	HYDRAULIC H P 32	HYDRAULIC 32	SIGNAL CO 32 (3)	WEBER WL 32	ENGINE HY SY 32B
HM 46	HYDROSTATIC SYSTEMS	PACEMAKER 46	HYDRAULIC OIL 46	ECTON 46	RANCO OIL HD 46	AZOLLA ZS 46	GAMMA X 46	HYDRAULIC H P 46	HYDRAULIC 46	SIGNAL CO 46 (4)	WEBER WL 46	ENGINE HY SY 46B
HM 68		PACEMAKER 68	HYDRAULIC OIL 68	ECTON 68	RANCO OIL HD 68	AZOLLA ZS 68	GAMMA X 68	HYDRAULIC H P 68	HYDRAULIC 68	SIGNAL CO 68 (5)	WEBER WL 68	ENGINE HY SY 68B
HG 32	HYDRAULIC SYSTEMS AND GUIDES	PACEMAKER ROD 3	TAMWAY OIL 32	BARTON 11	CLEARTEX D RANCO OIL HD 32	DROSERA MS 32	METRA X 32	GES 32	C.O. SPECIAL 32	SIGNAL V.U.U 32 (3)	WEBER WESSTOCK 32	ENGINE HOT 32A
HG 68		PACEMAKER 55	TAMWAY OIL 68	BARTON 18	CLEARTEX F RANCO OIL HD 68	DROSERA MS 68	METRA X 68	GES 68	C.O. SPECIAL 68	SIGNAL V.U.U 68 (5)	WEBER WESSTOCK 68	ENGINE HOT 68A
G 32		SINT GREASE EP 1	TAMUTHGREASE 1EP	GRASSO C-1 SPECK GRASSO MR 100	MULTIFAK EP 1 MARIFAK 1	MULTIS EP 1 MULTIS 1	CSMPA 1 GREASE CS-EP 1 GREASE	L 1 EP GREASE	LIKO 1 LIKO EP 1	SIGNAL FOLSTER EP 1	WEBERGREASE EP 1	GOLD 200 F1 GOLD 200 EP 1
G 68	MULTI FUNCTIONING GREASES	SINT GREASE EP 2	TAMUTHGREASE 2	GRASSO C-2 SPECK GRASSO MR 100	MULTIFAK EP 2 MULTIFAK MP 2	MULTIS EP 2 MULTIS 2	CSMPA 2 GREASE CS-EP 2 GREASE	L 2 EP GREASE	LIKO 2 LIKO EP 2	SIGNAL FOLSTER EP 2	WEBERGREASE EP 2	GOLD 200 F2 GOLD 200 EP 2
G 220		SINT GREASE EP 3	TAMUTHGREASE 3	GRASSO C-3 SPECK GRASSO MR 100	MULTIFAK HD 3 MARIFAK HD 3	MULTIS EP 3 MULTIS 3	CSMPA 3 GREASE CS-EP 3 GREASE	L 3 EP GREASE	LIKO 3 LIKO EP 3	SIGNAL FOLSTER EP 3	WEBERGREASE EP 3	GOLD 200 F3 GOLD 200 EP 3

Maintenance

Lubrication

Refer to images following these written instructions:

Below are the directions that explain how and where to add oil to the different systems:

 Do not overfill any of the lubrication points, serious electrical damage may result.

Outer Spindle

The Outer Spindle is hard chromed and is supported in tapered, cast iron spindle bushings. The Outer Spindle supports the Inner Spindle, bearings, seals etc... and maintains the boring rigidity.


Every 8 hours:

The Outer Spindle needs to be moved down to the lower limit, wiped clean, and then lightly coated with a ISO VG 68 Way Oil. This is very important, if the spindle is allowed to operate dirty the cast iron dust will act as an abrasive on the spindle chrome. This will cause the spindle to wear prematurely. The outer spindle is a very expensive item to replace.

Every 1000 Hours:

Open the sheet metal cover from the front of the spindle unit. There is a large nut where the outer spindle passes through the top of the spindle base. Using a spanner wrench or punch carefully remove the upper nut.

Note: *Do not adjust the nut below the felt wiper (see the mechanical section for correct adjustment of this nut).*



Slide the felt wiper back into place and tighten the Upper Nut back down.

Upper Belt Housing

No lubrication is necessary in the Upper Belt Housing.

Oil Reservoir System

Every 8 hours check the oil supply lines to the upper spindle to be sure they are full of oil.

IMPORTANT The oil reservoir system is located inside the lower portion of the column. This system lubricates the following:


Ways
 Inner Spindle Bearings (Upper and Lower)
 Horizontal Ballscrew
 Outer Spindle

Every 175 Hours:

The oil level of the reservoir should be checked, and filled with **WAY OIL ISO VG 68**.

When the oil reservoir is low or empty on the F103/4/5A machine, the control will “LOW OIL” and will not run until the reservoir has been filled.

The oil system may require priming if the reservoir has been run empty. You can do this automatically. Pull up the IO screen under Setup Electronics tab, select the Oiler section, and check the box to turn the oiler on.



Inner Spindle Bearings

The Inner Spindle Bearings are lubricated from the oil reservoir system. It is normal for a small amount of this oil to seep through the spindle bearings and onto the cutterhead.

Vertical Ballscrew Bearings

The Upper Pillow Block bearing is located on the top plate just below the driven sprocket. The lower bearing set is located at the bottom of the ballscrew in the spindle base.

Every 175 Hours:


These bearings should be greased with NLGI 2 White Lithium Grease.

Priming Spindle Base Oil Lines


1. After the spindle base has been placed on the column the oil lines must be purged of air.
2. Remove the oil lines located on the spindle base guide rails.




3. Energize the IO bit for the oiler on the computer and wait for oil to flow out of the line.
4. Reattach oil lines.



Lubrication Locations



Lubrication Locations cont:




Right Angle Drive Lubrication Information

All right angle drives require lubrication at the point where the pinion drive intersects with the drive gear. This is generally in the area where the cutterhead is attached, except for the units that have belt drive. There will be a small pipe plug that is removed to check oil level and add oil if needed. See illustration below for general locations.


With the drive mounted on the machine spindle the oil level should be even with the bottom of the pipe plug threads.

All Rottler Right Angle Drives are filled with Union 76 Turbine Oil 68 prior to shipment. Use this or an equivalent ISO VG68 oil if the need to add or change oil arises.


When adding oil, fill until oil starts to run out of fill hole. Allow excess oil to drain, then coat pipe plug threads with anti-seize compound and replace it.




ELO Alignment



Find the small arrow in the lower right hand side of your screen.
Click on the ELO icon in the lower right, by the clock. Then click on Align.
Touch the center on each of the targets.





When this screen appears touch around the screen to make sure the arrow follows your finger. If it is good click the green check mark. If not click the blue arrow to do the alignment again.

Magnescale Indicator Set Up

--Turn off power to Magnescale by unplugging the connector on the back of the unit. Or having someone else shut off the power while you stay in front of the unit.

-- Plug it back in while you are holding down the reset button. You will see either "mm" or "in"

-- While the still holding the reset button down, press the mode button and both the "mm" or "in" will start blinking, you are now in edit mode.

-- You can now release the reset button, use the up arrow to switch between "mm" and "in".

hit the set button to lock in the selection

Setting Up Sensor Stroke Depth.

Press and hold set and mode until options menu starts blinking. Push mode once to switch to rSLP and then press up arrow to set +.0005.



-- Push set once, and then mode ONE time, then rSL should be blinking

-- Press and hold set and mode until options menu starts blinking. Push mode once to switch to rSL and then press up arrow to set +.0002.




-- Push set once, and then mode button.



-- should be set to rEF > OFF

-- Push mode button once.



-- Should be set to E_St > St

-- Push mode button once. You should be back to the main readout screen


--Depress the plunger it should go from zero to max of .2000-2500


Spindle Drive Belt Replacement / Adjustment

CAUTION Turn off power to machine before proceeding with this procedure.


The spindle drive belt is located in the upper spindle housing.

Remove the spindle door and covers.







Lower spindle down onto a piece of wood to prevent the motor from falling.




Remove the counter weight cable end from the upper housing.




Remove Z-Axis motor, mount plate, and bracket.




Remove drawbar bracket assembly and front housing cover plate.




Remove rear housing cover plate.



Loosen motor mount bolts and belt tension adjusting bolt.



Remove and replace bolt.



When the new belt is in place use the adjusting bolt to set the belt tension. Proper tension is when there is 5/16" of deflection when 2-4 lbs. of force is applied between the 2 pulleys.

Outer Spindle Bushing Adjustment

The Lower Spindle Bushing will be adjusted in this demonstration.


1. Start the Rottler Software.
2. Move the spindle to its full downward position.



Retainer – O-Ring and felt are underneath

3. Loosen the four 10-24 bolts in the Retainer and pull out the O-Ring and Felt.
4. Loosen set screw at top of Bushing Carrier.
5. Take a punch and tighten Lower Bushing Nut with palm of hand. Raise spindle 5” and repeat. This helps set the bushing in the bushing carrier.

(WARNING: Do not tighten Spindle bushing retaining nut when spindle is at the top 3” of travel. Excessive wear and premature failure could result.)



6. Once the Retaining Nut will not tighten any more, a couple soft taps with a punch and a hammer to tighten it is all that is necessary to finish procedure.
7. Re-Install Felt, O-Ring, then Retainer in that order. Tighten down (4) 10-24 bolts.
8. Tighten Set Screw in Bushing Carrier.

Upper Bushing Adjustment

9. Repeat steps 3 and 4.
10. Take a punch and tighten Lower Bushing Nut with palm of hand. This time Lower spindle 5" and repeat.

(WARNING: Do not tighten Spindle bushing retaining nut when spindle is at the top 3" of travel. Excessive wear and premature failure could result.)

Once the Retaining Nut will not tighten any more, a couple soft taps with a punch and a hammer to tighten it is all that is necessary to finish procedure.

Re-Install Felt, O-Ring, then Retainer in that order. Tighten down (4) 10-24 bolts.

Tighten Set Screw in Bushing Carrier.


Note: It is recommended to sweep in your spindle after this maintenance procedure.

Inner Spindle Adjustment


**WARNING**

FOLLOW ALL SAFETY PROCEDURES LISTED IN THE SAFETY SECTION OF THIS MANUAL BEFORE STARTING THIS PROCEDURE


Open the spindle base door.




Install surfacing cutterhead or boring cutterhead with long tool holder onto spindle.




Locate opening in the belt housing.



Insert a rod into one of the drilled holes of the adjustment nut. This is used to lock the adjustment nut in place so that the nut won't turn while inner spindle is turned.





Grab hold of the cutterhead and turn it one turn clockwise to loosen the inner spindle adjustment.



Now turn the cutterhead counterclockwise. You will feel an increase of resistance as the spring load of the inner spindle increases. Continue to tighten until there is a sudden increase in effort to turn the cutterhead. At this point the inner spindle washers are fully compressed.

⚠ CAUTION *IMPORTANT: DO NOT OVER TIGHTEN, SEVERE BEARING DAMAGE WILL OCCUR AND REPLACEMENT WILL BE NECESSARY*



Now turn the cutterhead clockwise until you feel the detent ball on the adjusting nut lock into place. The inner spindle is now adjusted. Remove the rod from the adjustment nut and close the spindle cover door.

F103/4/5A Upper Housing Disassembly

Travel the machine to the right Home position.

Remove the spindle base door and right side cover.

Place a board across the spindle base directly below the spindle motor (6790K or 6790U). Lower the spindle until the motor just touches the board.



Disconnect all power and air to the machine before continuing, severe bodily injury may occur.

Remove the four (4) bolts securing the motor the belt housing. Remove the two (2) bolts that secure the cable carrier (6314K) to the upper housing. Remove the oil and air lines from the upper housing.

Note: It is not necessary to disconnect the spindle motor wiring.

Rotate the vertical ballscrew by hand until it is about eight (8) inches from the top plate.

Place a board, of proper length, between the bottom of the upper housing and the top of the spindle base to prevent it from falling.

Remove the two bolts that secure the centering gear housing (6168H) to the belt housing. Work the centering housing up off the centering shaft. Tie it up to the top plate.

IMPORTANT!!: Do not attempt to move the vertical under power when the centering housing is not bolted to the belt housing or the upper plate. Severe damage will result to the centering shaft!!

Remove the Clevis Pin (7210B) from the draw bar actuator bracket (6174B). Lift the actuator arm (6173B), move the arm and cylinder off to the side. Remove the air cylinder (6204A), clevis pin (6189A) and mount bracket (6188C) from the side of the belt housing. Remove the two (2) bolts that attach the draw bar actuator bracket (6174B) to the to belt housing cover.

Remove the counter weight cable (6453 F or 6453G) from the upper housing by loosening the lock nut and unscrewing the cable nut.

Note: When reassembling, be sure not to thread the cable nut in too far as it may come in contact with the driven pulley.


Remove the eight (8) screws holding the inner spindle end cap (6180A). Unscrew these bolts slowly around the diameter of the end cap as they are under spring pressure from the draw bar. Remove the cap by pulling straight up.


Note: When reinstalling, the end cap must be aligned concentric to the draw bar.

Remove the three (3) screws that secure the vertical ballscrew nut to the belt housing. Holding the nut with one hand, turn the ballscrew with the other to move it up and out of the way so the belt housing lid can be removed.

Remove the bolts securing the belt housing covers. The covers are pinned to the belt housing. Use a soft face mallet to carefully remove the covers.

From this position you can remove and/or replace pulleys and belts.





F103/4/5A Inner Spindle Removal

Prior to following these instruction, perform the steps in Upper Housing Disassembly.

IMPORTANT: When removing bearings, bellevilles and spacers, not the direction they come off for correct reassembly.

The driven pulley and inner spindle adjustment nut must be in place before continuing. Remove the LEFT HAND THREAD throwback ring (6305D) from the bottom of the outer spindle.

Note: If the driven pulley and inner spindle adjustment nut are not in place the inner spindle will be able to fall out of the outer spindle.

While supporting the inner spindle from the bottom, remove the inner spindle adjustment nut and driven pulley from the top.

The inner spindle is now free to be removed from the bottom. This spindle is precision fit into the outer spindle, it may be necessary to tap the top of the inner spindle with a soft face mallet to get the spindle to drop out.

Note: Be sure of the thrust direction of the bearings on reassembly.

Reassemble in the reverse order.

Inner Spindle Angular Contact Bearing Replacement

Prior to following these instruction, perform the steps in Upper Housing Disassembly and Inner Spindle Removal.

Loosen the three (3) Allen head set screws on the shoelock nut (6116F).
Loosen the shoelock nut and slide off of the top of the spindle.

Note: Be very careful not to damage the threads when sliding nuts, bearings and sleeves off the top of the inner spindle. These are very fine threads used for the inner spindle adjustment nut.

Remove the top bearing by tapping lightly and evenly on both sides of the bearing. After the bearing is moved slightly off of the spacer set (6172E) tap the inner race.

Note: Tapping on the outer race can cause it to roll off of the bearings. Generally after removing the bearings from the inner spindle they are not suitable for re-use.

Remove the spacer set.

Remove the two lower bearings (6116E) set of three (3) the same way as the top bearing.

Stand the spindle on end so that the bearing pack is nearest the floor.

Make sure inner spindle is free of all dirt and debris.

Lightly coat the lower bearing pack area with a light weight #10 oil.

If you have a bearing heater available to you, it is the preferred method of bearing installation. If not, follow the instructions below.

Slide the two (2) lower bearings onto the inner spindle with the correct bearing thrust direction until they stop. Use a small brass punch to lightly tap each side of the bearing on the inner race until both bearings are seated at the bottom of the spindle.

Install the spacer set.


Install the top bearing using the same procedure as the lower bearings until it is seated against the spacer set.

Install the shoelock nut and tighten with a spanner wrench until the inner races of the bearings and spacer set are fully seated together.

Tighten the three (3) set screws on the shoelock nut.

Place the inner spindle in a vise near the bearing pack and lock the vise.

Indicate the bearing set to within .0005" all the way around. Adjust the spacer set by tapping the high side lightly with a brass drift.



Spindle Sweep

The outer spindle must be swept into the main bed of the machine to achieve accurate bores.

Remove all fixturing from the machine bed, clean and stone if needed.

Install a boring cutterhead into the machine.

Install the sweep are into the cutterhead.

Bring the machine down until you have about .005" pressure on the indicator.

CAUTION Disconnect all power and air to the machine before continuing, severe bodily injury may occur.


Turn the sweep arm to the 9 O'clock position. Zero the indicator here.

Loosen the 6 socket head cap screws on the lower spindle hub. You do not want them all the way loose, just snug.

Use the four (4) set screws in the spindle base to move the spindle until the indicator reads within .0005" with a full 360 degree sweep of the indicator.


Note: *You do not want the right hand side of the spindle to be more positive than the left, it will interfere with the automatic tilt of the machine when in Mill mode.*

Once the spindle is swept in tighten the six (6) socket head cap screws and double check that the sweep did not move.



Horizontal Gibs

The Horizontal gibs are located under the main column, on the back side of the front way. These gibs keep the column from “cocking” when the direction of travel is changed. This adjustment becomes more critical when line boring. If the gibs are too loose the column will turn slightly side ways when traveling. This will cause the alignment of the right angle drive to be off. The cutterhead will then cut heavier on one side of the bore.



To adjust:

Loosen the Gib bolts (two on each side)

Loosen the Lock Nut on the set screw.

Tighten the set screw as much as possible using only the correct size Allen Wrench. This will pull the Front Way bearing up against the front way while pressing the Gib up against the back of the Front Way.

Loosen the Set Screw.

Tighten the set screw up until you can feel it contact the Gib.

Lock the Lock nut.

Run the machine back and forth to let the gibs adjust to adjust in.

Tighten the Gib bolts. Torque to 5 ft. lbs. or 60 in. lbs.

If the machine will not travel full speed or the handwheel movement is erratic the gibs may be too tight. Re-adjust leaving the Set Screw a little bit looser than the previous adjustment.

Another way to check for correct adjustment is to attach a magnetic base dial indicator (.0001 resolution) to the column with the indicator tip contacting the machine way surface.



Now using the handwheel in .010" per click mode, move the column back and forth, about two turns on the handwheel in each direction at a rapid rate.


Note the amount of movement on the dial indicator.

The acceptable amount of movement on the dial indicator is between .0002"-.0005".


Adjust as necessary. This procedure must be performed at both, the right, and left, sides of the column.

Adjusting Y-Axis Gibs

The Y-Axis adjusting gibs are located at the top of the machine column that the spindle base is mounted on. There are gibs located on the top and side rails on the left side of the column. Two are located on the top rail and two are located on the side rail.



On the right side of the column there are gibs located on the top rail.



Adjustment Procedure

1. On the left side rail loosen the jam nuts.
2. Tighten the set screws until they bottom out and can't be turned further.
3. Loosen each set screw 1/8 turn.
4. Tighten jam nuts.
5. On both top rails loosen jam nuts.
6. Tighten the set screws until they bottom out and can't be turned further.
7. Loosen each set screw 3/4 turn.
8. Tighten jam nuts.


Backlash Setting .NET Software

The Screens depicted below are for setting Backlash compensation values only. DO NOT use any other information on these screens to change information on the machine.


Turn off “Overshoot Backlash Setup”

Note: Only the F70-90 and 100 machines use the overshoot feature.

Go to Setup Software>Addins>Overshoot Backlash Setup



The Following screen will appear.



1. Record the existing X and Y “Overshoot Amount”. Generally .250
2. Use the “On Screen Keyboard”, or plug in the full size keyboard, and change the amounts to 0.00, and click on OK. Close the “Setup” screen.

3. Go to Setup Electronics>Control

Program Selected: Part Program DTG: 0.000 Vert 0.0000 In/Out 0.0000

Mode Selected: End Rail Feedrate override 1.00 Horiz 0.0000 4th 0.000

The screenshot shows the machine's control interface. On the left is a 'PROGRAM SELECT' panel with buttons for LEFT, RIGHT, IN, UP, OUT, DOWN, CW, and CCW, and a red 'STOP MACHINE' button. In the center, a 'Control Options' dialog box is open, displaying a table of link numbers and a 'Debug Programming Links' checkbox. On the right, the 'Setup Electronics' menu is open, showing 'Control' as the selected mode. Below the menu is a tree view of machine components.

ControlOptionsForm	LinkNumber
X	0
Y	1
Z	2
Handwheel	-1
S	3
A	-1
Outputs	6
Inputs	5


Setup Software Setup Electronics Help

Mode Select

- Control
- Coordinated Motion
- IO

- Cylinder Bore
 - General Bore
 - Circular Interpolate Counter Bore
- Line Bore
 - Line Bore
- Mill
 - Mill Cycle
 - End Rail
- Connecting Rod
 - Connecting Rod
- Thrust Cutting
 - Thrust Cutting

4. On the “Control Options” screen, double click the X to bring up the “X Options” screen.



Now minimize the screen.

5. Repeat step 5 for the Y and Z axis.
6. Close the “Control Options” screen.

7. Select a program (block), then select any cylinder bore mode.

The screenshot displays the Rottler Block Boring control interface. At the top, it shows 'Program Selected: test' and 'Mode Selected: General Bore'. The DTG (Dial Test Indicator) is set to 0.000, with 'Vert' and 'In/Out' also at 0.0000. The Feedrate override is 1.00, with 'Horiz' and '4th' also at 0.0000. The interface is divided into several sections:

- PROGRAM SELECT:** A vertical column of buttons including LEFT, RIGHT, IN, UP, OUT, DOWN, CW, CCW, and a large red STOP MACHINE button.
- Set Zeros:** A section with yellow buttons for Zeros, VERTICAL, HORIZONTAL, IN/OUT, and SPINDLE. The 'Actual Position' for VERTICAL, HORIZONTAL, and IN/OUT is 0.0000, and for SPINDLE it is 0.00.
- Vertical Stops:** A section with a 'Handwheel' column containing buttons for .010, .001, and .0001, and a 'Move To' column with buttons for Tool #, Probe #, and Set Active.
- Locations:** A section with buttons for 10x, Coarse, and Fine, and a 'Move To' button for Probe #.
- Machine Status:** A section showing Spindle Load (0.0%), Feed Rate (0.0020), and Spindle RPM (400).
- Control Buttons:** A section with buttons for MOVE TO ZEROS, CW INDEX, CCW INDEX, and START SPINDLE.


Notes:

***The photos shown are demonstrating the X axis (horizontal) backlash adjustment. The Y and Z axis are adjusted following the same steps.

***The direction of machine travel to put the initial load on the dial indicator, are as follows: X (horizontal), from the right toward the left.

Y (in/out), from back toward the front. Z (vertical) from top toward the bottom.

A Dial Indicator with 1.0" to 1.5" of travel should be used for several reasons.




If the axis is overshooting or coming to position slowly you will be able to see it with a dial indicator. With Digital indicator you will only see the end position. The Magnascale indicator should be used to dial or tram in. The automatic moves of the machine can "Shock" the sensitive plunger of the Magnascale.

8. Attach the magnetic base and dial indicator to a stationary stand, parallel, or engine block fixed to the machine bed.



9. Bring the spindle of the machine in position to put a slight load on the Plunger, about .020".

10. Set "Vertical, Horizontal, In/Out" zero.



11. Set all vertical stops to "zero".



12. Move the machine spindle away from the Plunger a few inches, and press "Move to" and then 0 and Enter from the pop up keypad for the axis that is being measured..

Program Selected: Part Program DTG: 0.000 Vert 0.0000 In/Out 0.0000

Mode Selected: General Bore Feedrate override 1.00 Horiz 0.0000 4th 0.000

Set Zeros **Vertical Stops** **Left Locations** **Right Locations**

CalcInput

7	8	9	/	B
4	5	6	*	C
1	2	3	-	=
0	+/-	.	+	CLOSE

0.0 **ENTER**

Handwheel **Move To**

.010	.001	.0001	MoveTo	Tool #: -1
.010	.001	.0001	MoveTo	Set Active
.010	.001	.0001	MoveTo	
10x	Coarse	Fine	MoveTo	Probe #: -1
				Set Active

Spindle Load NaN%

Feed Rate 0.0020

Spindle RPM 400

STOP MACHINE **PROBE AUTO CENTER**

MOVE TO ZEROS


CW INDEX **CCW INDEX**

START SPINDLE

13. Repeat the movement to verify the machine will repeatedly position itself at zero.
14. Now, use the "Move To" button and then -.200 to move the spindle -.200" in the opposite direction.
15. Press "Move to" and then 0 and Enter from the pop up keypad for the axis that is being measured.

If the machine did not position itself to bring the digital readout to zero, a backlash compensation adjustment is needed.

16. To adjust, maximize the “Axis X Options” screen. Go to Backlash Setting>Backlash.



17. Use the “On Screen Keyboard”, or plug in the full size keyboard to enter the amount of correction in the Backlash area. After entering a value, click “Apply”, for the new setting to take effect.

18. Repeat steps 13 through 17 and adjust as necessary until the machine positions itself to “Zero” on the digital readout from both directions.


Handwheel Backlash is measured in a similar way to Backlash but the axes is moved by the Handwheel – the Move To buttons are NOT used.

19. Set up the Dial Indicator as described in #8 and #9.

20. Touch the .001” Handwheel button and move the axis to away. Turn the handwheel at a **constant speed** and move the axis back until the control panel displays zero. If the axis travels past zero, start again - move back again and turn the Handwheel at **constant speed** until the axis stops on zero on the machine display. Check that the Dial Indicator is zero, if not, move away and back again until both the machine control and Dial Indicator both read zero.

21. Now move the axis in the opposite direction and be sure to stop about .020” less that total plunger travel before compressing the plunger all the way. Now move the axis back by turning the Handwheel at a **constant speed** until the machine display reads zero. Check the reading on the Dial Indicator.

22. Use the “On Screen Keyboard”, or plug in the full size keyboard to enter the amount of correction into Handwheel Backlash. Press Apply when you are done.



23. Follow steps 9 through 22 for the Y and Z axis.
24. When finished, re-enter the “Overshoot Backlash Amounts”, as recorded in step 2 and click OK and close the window.

Spindle Belt Adjustment

The spindle belt should not require adjustment very often, but if required use the following instructions.


Open the Spindle Base shroud.

Loosen the four Motor mounting bolts on the spindle motor.

Tighten or loosen the Tension adjustment bolt on the rear of the belt housing until 5 pounds of pressure causes the spindle belt to deflect 1/4".


If the spindle motor is run at high speed and a high pitched whining is heard from the belt housing area the belt adjustment is probably too tight.

If you can visually see the belt jumping around while running the belt is too loose.



Top and Side Rail Adjustment

1. Loosen jam nuts on side rail adjustment screws
2. Tighten adjustment screws until they bottom out
3. Back adjustment screws out 1/8 of a turn
4. Tighten jam nuts



5. Loosen jam nuts on top rail adjustment screws
6. Tighten adjustment screws until they bottom out
7. Back adjustment screws out 3/4 of a turn
8. Tighten jam nuts



Mill Tilt Adjustment Procedure

1. Position the Y axis in the middle of its travel. Using a 5/32" hex key, loosen the locking set screw through the access hole in the right side guide rail



2. Put the machine in "Mill Cycle" mode, with the wedge turned off. Attach an indicator as shown in the following photo, and set to zero position.




3. Using a 3/16" hex key, turn the adjustment screw in or out to increase, or decrease, the amount of mill tilt. Turn the screw CCW to increase, or turn CW to decrease the amount as shown in the photo at step #2. After each adjustment, turn the "Wedge On", to check the amount. Set to .002" - .004" (.05mm - .1mm) of lift with the wedge turned on. Turn the wedge off to readjust, and then turn the wedge on to check the amount.
4. When finished, tighten the locking set screw as shown in the photo in step #1.
5. Repeat the procedure for the rear wedge.




6. After adjusting the rear wedge, re-check the front, to make sure it did not change.

Checking Wear on Column Turcite Pads


Remove bolts holding way covers to column.



Slide way covers away from column to gain access to column way.
Remove wipers from Turcite pads.



Measure height of Turcite pads using either feeler gauge or dial indicator method.



Pads will have to be replaced or shimmed if height difference between the 4 pads exceeds .005".


Digital Micrometer setting instructions


Turn the thimble until the '0' line on the thimble lines up with the vertical line nearest the spindle lock ring.



Determine which cutter head bore range the micrometer is going to be used on. (example; 2.9 – 6.0)
We want to initially set the micrometer to the minimum bore diameter of this cutterhead.

NOTE: MICROMETER CAN NOT BE PROGRAMMED IF THE LETTERS INC APPEAR IN THE DISPLAY. To get rid of INC, quickly press the in/mm/ABS button.



To set or edit micrometer

Press and hold the set/on button and the + or – button at the same time. “Set” will flash in the display. This places the micrometer in edit mode. (CAUTION: use a pencil tip or something similar to gently push the small round buttons - they are quite small and a bit delicate.)

Press and hold the + or – buttons to change the display number to the minimum bore diameter determined earlier (example; 2.9). Caution: Pushing the + or – buttons and holding in place will cause the numbers to scroll automatically. The numbers will count slowly at first and once 0.010” has been counted off the scrolling speed will pick dramatically.

After you have reached the desired number in the display, press the set/on button twice quickly to exit the edit mode. “Set” should no longer be flashing in the display. The micrometer is now ready for use.

CAUTION: AFTER MICROMETER SET-UP IS COMPLETE, DO NOT PUSH SET/ON BUTTON AGAIN. PUSHING THE SET/ON BUTTON DURING USE WILL RETURN THE DISPLAY TO THE ORIGINAL MINIMUM BORE DIAMETER. THE ONLY TIME YOU SHOULD USE THE SET/ON BUTTON AGAIN IS TO- A. To shut micrometer off at which time you push and hold the button or B. to turn micrometer display back on at which time you push button one time. The display will then show the last reading before micrometer was shut off.

CAUTION: DO NOT BACK THE THIMBLE ALL THE WAY OUT TO THE END OF IT’S TRAVEL. ONCE THE THIMBLE IS BACKED ALL THE WAY OUT, IT WILL NO LONGER ROTATE PROPERLY AND THE DIGITAL HEAD WILL NEED TO BE REPLACED.


Micrometer is calibrated in inch mode. If metric is desired, press and hold in/mm/ABS button until mode changes to metric (approximately 3-4 seconds). A quick press of the in/mm/ABS button will put micrometer in ABS mode: 0.000, with another quick press returning it to initial setting.

Set up the cutter head and bore a set up hole. Measure the bore accurately. Set the digital display to this bore dimension and then -

Loosen the set screw holding the large diameter anvil. Slide the anvil back out of the way.



Place the tool holder used to bore the hole into the micrometer frame. Slide the location nub on the back of the tool holder gently up against the end of the digital micrometer shaft.



Slide the large diameter anvil up until it touches the end of the cutting tip of the tool holder. Tighten the set screw.



Back the digital micrometer shaft off, then bring it up to touch the tool holder and recheck that the numbers in the display are the same as the numbers previously shown.



The micrometer is now set up for use with this cutter head.

Note: this procedure must be repeated to set the micrometer to a different cutter head. The micrometer can only be set to one cutter head at a time.

To shut off micrometer press and hold set/on button until screen goes blank or let micrometer set until display disappears.

With initial setting of micrometer it is recommended that you use the procedure detailed below in the event you think you have size problems.



Procedure:

The short vertical lines that cross the horizontal scale on the micrometer sleeve are reference marks. Set the zero on the micrometer thimble even with the first vertical line and note the size shown in the digital display. Record this size for future reference. Now follow the same procedure for each line and record the sizes. At any time you feel your micrometer is reading incorrectly, you can quickly refer to the recorded size of the line closest to the range you are using and check that the micrometer is still accurate.






Probe “On-Center” Adjustment



This covers setup and calibration of the probe, so it will accurately position your machine.

- Verify that the four adjusting screws and two locking screws are installed in the probe tool holder.
- Assemble probe on either CAT 40 Shank or Rottler Taper
- With the machine breaker that supplies power to the probe receiver turned off;
- Install batteries in the probe WITH stylus deflected.


Probe LED check will run.

- Release stylus after battery check this will put you in edit mode.
- First will be Switch off method, you want this at **purple, purple, yellow** (Radio On). If it is not, deflect and release stylus quickly to change the mode.
- Hold the stylus deflected until the colors change to move to the next setting.
- You should be at Switch Off method; it should be **red, red, yellow** (134 seconds). If it is not, deflect and release stylus quickly to change the mode.
- Hold the stylus deflected until the colors change to move to the next setting.
- You should be at Enhanced trigger filter; it should be **green, green, green** (on). If it is not, deflect and release stylus quickly to change the mode.
- Hold the stylus deflected until the colors change again to move to the next setting.
- You should be at Acquisition mode, **light blue, light blue, light blue**.
- Turn on machine and quickly deflect and release the stylus. This must be done within 10 seconds of turning on the power breaker to the probe. If you are watching the RMI-Q (located ON the machine) you will see the right light turn **red, yellow, red, yellow, red, yellow** is shows the partnership has been acquired.
- Go into the software and do a probe auto center and hit start probe to verify that it works correctly.

Key to the symbols	
	LED short flash
	LED long flash
	Deflect the stylus for less than 4 seconds to move to the next menu option.
	Deflect the stylus for more than 4 seconds to move to the next menu.
	To exit, leave the stylus untouched for more than 20 seconds.




Switch on method, next page




Changing the probe settings (continued)

Note: After the RMI has been acquired, the RMP40 will only show Acquisition mode off.

See RMP40 - RMI partnership.



If the Probe does not turn off after 137 seconds you will need to make sure that the RMI-Q switches are shown in the following positions:




During normal use, the difference between the touch position and the reported position does not change, but it is important that the probe is calibrated in the following circumstances:

- when a probe system is to be used for the first time;
- when a new stylus is fitted to the probe;
- when it is suspected that the stylus has become distorted or that the probe has crashed;
- at regular intervals to compensate for mechanical changes of your machine tool;
- if repeatability of relocation of the probe shank is poor. In this case, the probe may need to be recalibrated each time it is selected.

It is good practice to set the tip of the stylus on center, because this reduces the effect of any variation in spindle and tool orientation. A small amount of run-out is acceptable, and can be compensated for as part of the normal calibration process.

- calibrating either in a bored hole of know size, a ring gauge, or on a datum sphere.


Mounting the probe on a shank



- Dial the probe stylus into center using a .0001" indicator to within .0005" the tighter tolerance you hold the more accurate the machine will be. You must use an indicator that takes very little pressure to get a reading. Excessive pressure on the stylus will deflect the probe and you will not be able to dial it in correctly.
- Go to the Main/Block Model screen and select the Table of Tools. You may only have a Default Tool #0 listed.
- Press Add Tool. This will bring up a dialog box. Change the name from default tool to probe style that you are installing i.e. 50mm stylus, 100mm stylus. Set the diameter to .2360" this is default probe tip on a 50mm, 100mm, and 17.5mm.
- Install a block, or parallels onto the machine and secure it solidly to the machine table.
- Place the Ring Gauge onto the top of the block, use Probe Auto Center to find center zero your X and Y axis here. Make sure you use a ring gauge or a hole of a known diameter. This will set the correct probe timing.
- Adjust the probed diameter by going to the IO under Setup Electronics and changing the Probe MS. You will need to increase or decrease the MS of the probe to achieve correct Probe Diameter.
- Repeat until the correct diameter is displayed.
- Probe Auto Center the ring gauge, without moving X or Y, remove the probe up in Z and Install the cutter head. Put a magnet base with the Last Word indicator on the cutter head and sweep the cylinder/ring gauge.
- The variation in X and Y Should be less than .0005.
- If not add compensation to ProbeOffset under > Setup Eletronics-Addins-ProbeSetup

Replacing the Motherboard Battery

If computer fails to boot up and you get a CMOS error message on the screen, then the battery on the computer motherboard has failed and needs to be replaced.



The following is the procedure for replacing the motherboard battery.

Turn off the power on the electrical enclosure and remove the enclosure cover.



Locate the computer and check to see that the power light is not on. If it is on turn off the power switch.
Note: On some machines it may be necessary to unbolt the computer from the enclosure in order to gain access to the cover screws.

Remove the 6 screws indicated by the arrows from the cover.


Remove the cover.




Locate the battery on the motherboard.



Push the battery retention clip away from the battery. When the clip is released the battery will pop up.



Remove the battery and place new battery in the battery holder.



Using your finger tip push down on the battery until the retention clip is in its lock position.



Replace computer cover and make sure that power switch on the computer is on.
Replace the enclosure cover and switch power back on.


Ballscrew Assemblies Reference

Alignment Definitions for Angular Bearings and Belleville Washers

Bearing Alignment



VIEW OPEN END UP



VIEW CLOSED END UP

Belleville Washer Alignment




VIEW CUP UP




VIEW CUP DOWN

Z-Axis Lower Bearing and Belleville Washer Stacking Order





Z-Axis Lower Bearing and Belleville Washer Section View



Z-Axis Upper Belleville Washer Stacking Order


Install 1st washer with cup side facing out, then alternate next 3 washers.

Z-Axis Upper Belleville Washer Section View




X-Axis Drive Side Bearing Stacking Order

Install 1st and 2nd bearings with open side facing in. Install 3rd and 4th bearings with open end facing out.

**X-Axis Drive Side Bearing Section View**


3rd and 4th bearings
are installed with the
open end facing out




1st and 2nd bearings
are install with the open
end facing in

X-Axis Idle Side Bearing Stacking Order

Install both bearings with open side facing out.




X-Axis Idle Side Bearing Section View




**Both bearings are installed
with open end facing out**

Y-Axis Bearing Stacking Order

Install 1st bearing with open end toward ballscrew shoulder. Install 2nd and 3rd bearings with closed end toward 1st bearing.




Y-Axis Bearing Section View




Inner Spindle Upper Section Belleville Washer Stacking Order


6113 Belleville washers are stacked in an alternating pattern with the bottom washer installed cup face up. (see illustration on right side)



Inner Spindle Upper Section Belleville Washer Section View



Inner Spindle Lower Section Bearing Stacking Order




Install 3rd bearing with the closed side down.

Install inner and outer spacer assembly with beveled end facing up.

Install 2nd bearing with the open side down.

Install 1st bearing with the open side down.

Inner Spindle Lower Section Bearing Section View



TROUBLESHOOTING

Problem:

Icon on screen does not move to area touched.

Solution:


Follow the procedure below to recalibrate the touchscreen.

1. Get to the Alignment screen.
 1. If an Elo icon is available in the tool tray at the lower right side of the desktop, click it, then click Align.
 2. Otherwise, go to the Windows Control Panel, double-click Elo Touchscreen and click the Align button on the General tab.
 1. If Windows XP and no Elo icon, click the "Switch to Classic View" button on the left
 2. If Windows 7 and no Elo icon, look for "View by: Category" text toward the upper right; click it and select "Small icons"
2. Touch and release the upper left target; the target should jump to the lower right.
3. Touch and release the lower right target; the target should jump to the upper right.
4. Touch and release the upper right target; a check screen should appear.
5. Touch and release the green check mark; the check screen should disappear.
6. The cursor should now jump to the point of touch.
7. If the Elo Control Panel is open, close it and the Windows Control Panel.

Chatter Problems

If you are having chatter problems when you are boring you should do the following steps;

1. Replace the insert, Make sure you use Rottler RT321 inserts it is strongly advised.
2. Clean the inside of the bore head. Oil will build up if you leave the boring head in the machine overnight or have the oiler turned up. You will need to clean any oil off of the counterweight (11), also clean the cavity that the counterweight sits in. This is done by removing the bolts (15). This procedure is the same with other Rottler cutter heads. See the optional equipment parts catalogue for breakdowns of the cutter heads.
3. Check Inner Spindle Adjustment, see maintenance section.
4. Check outer spindle adjustment/bushings, see maintenance section.
5. Newer models we recommend the use of the SSV system, if you are having chatter issues.
6. Counter balance cable pressure; verify that it is in service and unbroken. See maintenance section.



MACHINE PARTS


Contents

Machine Parts	8-1
Front Sheet Metal	8-1
Rear Left Sheet Metal	8-2
Right Rear Sheet Metal	8-3
Air Control Door	8-4
Air Control Solenoid Pack	8-5
Oiler Door	8-6
Electrical Wiring Diagram	8-7
Electrical Enclosure Assembly F103/4/5A Series	8-8
Enclosure Outside Parts	8-8
Enclosure Inside Parts	8-9
Enclosure Panel	8-10
DIN Rail Components	8-11
650-1-27X Computer Enclosure Assembly	8-12
Computer Components	8-13
Spindle Base, Right Side	8-14
Spindle Base, Left Side	8-15
Counterbalance Cylinder Pop Off Valve Assembly Parts	8-16
Motor Housing Parts	8-17
Z-Axis Motor Parts	8-18
Counter Balance Pulley Parts	8-19
Spindle Motor Housing Parts Outside	8-20
HSK Upper Spindle Housing Parts	8-21
Spindle Motor Housing Parts Inside	8-22
Upper Spindle & Ballscrew Parts	8-23
Lower Spindle & Ballscrew Parts	8-25

Inner Spindle Lower Section Parts	8-27
HSK Drawbar Upper Section Parts	8-28
Y-Axis Drive Parts.....	8-29
Column and Spindle Base Retainers.....	8-30
Column Base Parts.....	8-31
Pendant Swing Arm.....	8-32
Pendent Swing Arm Assembly Parts List.....	8-33
Pendant Components	8-34
Main Base Parts.....	8-35
X-Axis Assembly: Drive End Parts.....	8-36
X-Axis Assembly: Idle End	8-37
Chip Shield Assembly.....	8-38
Front Cover and Lights	8-39
Oil Line Diagram	8-40
Air Line Diagram.....	8-41


Machine Parts

Front Sheet Metal




ITEM	PART #	DESCRIPTION
1	9213F	COVER, DOOR-TOWER
2	6320M	CLAMP, SPINDLE COVER
3	9222B	FRONT PLATE, SPINDLE BASE
4	9222C	LIGHT MOUNT-COVER, SPINDLE BASE
5	9213D	COVER, RIGHT SIDE- TOWER

Rear Left Sheet Metal




ITEM	PART #	DESCRIPTION
1	9213B	COVER, LEFT SIDE REAR -TOWER
2	9213A	REAR COVER, TOWER
3	9213C	COVER, LOWER REAR SPINDLE BASE
4	6320J	HINGE, SPINDLE COVER
5	9213F	COVER, DOOR-TOWER
6	9223A	CHIP DEFLECTOR
7	6584K	PANEL, SHIELD

Right Rear Sheet Metal




ITEM	PART #	DESCRIPTION
1	9223A	CHIP DEFLECTOR
2	6584K	PANEL, SHIELD
3	9114	WAY COVER SET
4	6351Q	BOX,ELECTRICAL SUPPLY HOOKUP
5	9114	WAY COVER SET
6	10015G	BOX ASSEMBLY, CABLE CARRIER MOUNT


Air Control Door

ITEM	PART #	DESCRIPTION
1	9030E	DOOR LATCH ,COLUMN AND AIR ACCESS
2	502-37-71N	STRAIN RELIEF
3	502-37-71H	FILTER REGULATOR ASSEMBLY
4	6340P	HINGE, AIR ACCESS DOOR
5	502-11-8	GAUGE, PRESSURE
6	9205	SIDE COVER, AIR CONTROL

Air Control Solenoid Pack




Oiler Door




ITEM	PART #	DESCRIPTION
1	9030E	DOOR LATCH ,COLUMN AND AIR ACCESS
2	9205A	SIDE COVER, OILER CONTROL -COLUMN
3	6349B	FEEDER,FLO-OILER
4	514-4-17V	FITTING 1/8 NPT X 1/4 POLY-90 DEGREE
5	6363	OILER, WAYS AND BALLSCREW

Electrical Wiring Diagram




Electrical Enclosure Assembly F103/4/5A Series

Enclosure Outside Parts




ITEM	PART #	DESCRIPTION
1	9030H	FILTER HOUSING, REAR ELECTRICAL ENCLOSURE
2	650-1-29G	HANDLE, TOUCH PANEL SG80 REAR ENCLOSURE
3	9035E	DOOR LATCH -ELECTRICAL ENCLOSURE
4	9030A	DOOR,ELECTRICAL ENCLOSURE
5	9033C	TOP SIDE PANEL FOR ELECTRICAL ENCLOSURE
6	6358	CONNECTOR,STRAIGHT-1"
7	700-4	CONNECTOR, STRAIN RELIEF
8	502-2-23C	STRAIGHT CONDUIT FITTING
9	9023P	SPINDLE WIRING TRACK BRACKET
10	7192	FAN, ELECTRONIC ENCLOSURE
11	9023Z	SPINDLE AMP HEAT SINK
12	9033A	RIGHT SIDE PANEL FOR ELECTRICAL ENCLOSURE
13	9030P	AIR FILTER, REAR ELECTRICAL ENCLOSURE

Enclosure Inside Parts




ITEM	PART #	DESCRIPTION
1	9030F	DRIVE COVER - ELECTRICAL ENCLOSURE
2	9033B	LEFT SIDE PANEL FOR ELECTRICAL ENCLOSURE
3	6554L	DUCT, WIRING (1 1/2" X 2")- ELECTRONIC ENCLOSURE
4	650-7-1C	POWER SUPPLY, COMPUTER ASSEMBLY
5	9033D	BOTTOM SIDE PANEL FOR ELECTRICAL ENCLOSURE
6	9038E	RESISTOR,BRAKING
7	9035H	CIRCUIT BREAKER-60 AMP-MAIN POWER
8	9023L	SPINDLE AMP DRIVE COVER
9	9030G	COVER-ELECTRICAL COMPONENTS

Enclosure Panel




ITEM	PART #	DESCRIPTION
1	9035	ALUMINUM PANEL-REAR ENCLOSURE
2	9034	DM 30 AMP AXIS DRIVE
3	9034G	OUTPUT BOARD- DM SERIAL CONTROL SYSTEMS
4	9035T	DM 75 AMP SPINDLE DRIVE WITHOUT BRAKE
5	9034F	INPUT BOARD- DM SERIAL CONTROL SYSTEMS
6	6486P	200 WATT, 10 OHM CHARGE RESISTOR
7	9030T	BRACKET, SWITCH-ELECTRICAL ENCLOSURE
8	9034E	POWER BOARD-70 AMP, THREE PHASE, DM SERIAL CONTROL SYSTEMS
9	9035N	DM 300 AMP SPINDLE DRIVE
10	9023Q	CONTACTOR-90 AMP SPINDLE AMP
11	6496J	TERMINAL, GROUNDING-ELECTRONIC ENCLOSURE

DIN Rail Components




ITEM	PART #	DESCRIPTION
1	504-35-3F	DIN RAIL
2	504-35-3M	CAP, DIN RAIL
3	504-35-3K	POWER SUPPLY, 24 VOLT DC
4	9038C	100 WATT, 12 VDC POWER SUPPLY
5	504-35-3Q	BREAKER, CIRCUIT 3 AMP, 2 POLE
6	504-35-3U	BREAKER, CIRCUIT 7 AMP, 2 POLE
7	6462J	BREAKER, CIRCUIT 50 AMP 3 POLE

650-1-27X Computer Enclosure Assembly




Item	Part Number	Description	Item QTY
1	650-1-27Y	Computer Case, Front	1
2	650-1-27Z	Case, Computer, Side	1

Computer Components




ITEM	PART #	DESCRIPTION
1	650-1-27Y	FRAME,COMPUTER CASE--SOLD IN ASSY #650-1-27X
2	650-7-1C	400W POWER SUPPLY
3	650-7-1A	MOTHER BOARD
4	650-7-1F	HARD DRIVE
5	650-7-2F	8GB DDR4 RAM
6	9035D	PCI E CARD - 16 LINK
7	650-1-27Z	COVER,COMPUTER CASE-SOLD IN ASSY #650-1-27X

Spindle Base, Right Side


ITEM	PART #	DESCRIPTION
1	9208	TOP PLATE-TOWER
2	9215J	Z-AXIS MOTOR (WITH BRAKE)
3	9217	COUNTER BALANCE CYLINDER
4	9231C	WIRING TRACK-SPINDLE
5	10015G	BOX ASSEMBLY, CABLE CARRIER MOUNT
6	9215G	MOTOR, SPINDLE - BISS ENCODER
7	9208B	SUPPORT BAR, TOP PLATE
8	10013F	RIGHT SIDE COVER, LOWER-SPINDLE BASE

Spindle Base, Left Side




ITEM	PART #	DESCRIPTION
1	9216	HOUSING,UPPER SPINDLE DRIVE
2	9207A	TOWER
3	10013E	LEFT SIDE COVER, LOWER-SPINDLE BASE
4	9206B	BASE,SPINDLE
5	9206D	COUNTERWEIGHT
6	10015E	COVER, CABLE CARRIER MOUNT
7	9213	COVER,BOX-SPINDLE BASE
8	9231C	WIRING TRACK-SPINDLE

Counterbalance Cylinder Pop Off Valve Assembly Parts




Pop Off Valve Assembly Parts		
Item #	Part #	Description
1	514-4-18C	FITTING, BRASS 3/8 TO 1/4
2	6449	VALVE,RELIEF-COUNTERWEIGHT
3	502-11-17W	TEE, 1/4 FPT X 1/4 MPT
4	502-11-17L	ADAPTER, 1/4 TO 1/8" MALE PIPE FITTING
5	517-7-58	CHECK VALVE
6	514-4-17W	FITTING, 1/4 X 1/8 MPT
7	502-11-17K	NIPPLE, CLOSE, 1/4 MPT X 1

Motor Housing Parts




MOTOR HOUSING PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1		SHCS 3/8 16 X 3	4
2	6760J	Mounting Bracket	1
3		FHCS 5/16 18 X 3/4	2
4	6760K	Inner Linear Guide	1
5	6760L	Outer Linear Guide	1
6		SSS Cup Point 3/4 16 X 2	1
7		NyLok Nut 3/8 16	
8		Roll Pin 5/16 X 1 1/2	2
9	6037C	Belleville Spring	4
10	6037D	Stop Collar	1

Z-Axis Motor Parts




Z-AXIS MOTOR PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	9208C	Bearing Support	1
2	6759F	Bearing Block	1
3	9001M	Motor Coupler Assembly	1

Counter Balance Pulley Parts




ITEM	PART #	DESCRIPTION
1	9217B	SUPPORT BRACKET, UPPER CABLE CYLINDER
2	11017G	BRACKET, DUAL PULLEY COUNTER BALANCE
3	9230	PULLEY, CABLE CYLINDER
4	650-3-66R	SHOULDER SCREW
5	9217C	CABLE GUIDE, COUNTERWEIGHT CABLE

Spindle Motor Housing Parts Outside




SPINDLE MOTOR HOUSING OUTSIDE PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	9216C	Rear Cover	1
2	9216B	Front Cover	1
3	7210B	Clevis Pin	1
4	6174B	Support Bracket	1
5	6173B	Actuator Arm	1
6	6189B	Clevis Pin	2
7	6205	Clevis	1
8		1/2 20 Jam Nut	1
9	6204A	Cylinder	1
10	514-4-17Z	90° 1/8 Tube Fitting	2
11	6188C	Cylinder Bracket	1

HSK Upper Spindle Housing Parts



ITEM	PART #	DESCRIPTION
1	10042B	CYLINDER, DRAWBAR RELEASE
2	9216C	COVER, REAR-UPPER HOUSING
3	9216H	COVER, FRONT UPPER HOUSING
4	10042C	SPACER, DRAWBAR RELEASE CYLINDER


Spindle Motor Housing Parts Inside



SPINDLE MOTOR HOUSING INSIDE PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1		Hex Bolt 3/8 16 X 2 3/4	1
2		3/8 Flat Washer	1
3	9216A	Motor Mount Plate	1
4		Drive Key	1
5	9215B	Drive Sprocket	1
6	9215N	Belt	1
7	9209	Ballscrew and Ball Nut Assy	1
8	9215M	Driven Sprocket	1
9	514-4-18	90° 1/8 Tube Fitting	1

Upper Spindle & Ballscrew Parts


* See Maintenance Section for correct installation procedure



UPPER SPINDLE & BALLSCREW PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	9218A	Spindle Nut	1
2	9218	Index Bushing	1
3	6186	Lock Key	1
4	6180A	Cap	1
5	9028	DRAWBAR--SOLD IN ASSY 9028B ONLY	1
6	6167N	INNER SPINDLE ASSY (SOLD IN ASSY #6167G ONLY)	1
7	6123F	Spacer	1
8	6115A	Bearing	2
9	6113	BELLEVILLE SPRING	4
10	514-4-18	90° 1/8 Tubing Fitting	1
11	6090B	Drive Key	1
12	6037D	Collar Spacer	1
13	6037C	BELLEVILLE SPRING	4


Lower Spindle & Ballscrew Parts

* See Maintenance section for correct installation procedure




LOWER SPINDLE & BALLSCREW PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	6247A	Wiper Retainer	2
3	6249	Oiler Felt	2
4	6223	Spindle Nut	2
5	6225A	Bearing Carrier	2
7	6248	Wiper	1
8	6052	Oil Seal	1
9	6107	Shoulder Ring	2
10	6032E	Thrust Bearing Retainer	1
11	6063	Bearing	4
12	6037A	Belleville Spring	6
13	502-10-18	Lock Washer	1
14	6049C	Keyed Washer	1
15	502-10-17	Nut Lock	1

Inner Spindle Lower Section Parts



INNER SPINDLE LOWER SECTION PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	6116F	NUT,BEARING-LOWER INNER SPINDLE	1
2	6116E	BEARING,PRECISION- SPINDLE (SET OF 3)	1
3	6172D	SPACER,PRECISION BEARING OUTER SPINDLE SOLD IN	1
4	6172C	ASSY#6172E	
5	6167G	SPINDLE, INNER ASSY-PRECISION BEARING STYLE	1
6	6305D	NUT,THROW BACK RING	1

HSK Drawbar Upper Section Parts




F105AH

ITEM	PART #	DESCRIPTION
1	9233	SPINDLE ASSEMBLY, INNER
2	10041B	NUT, HSK DRAWBAR TOP
3	10041	BELLEVILLE SPRING, DRAWBAR
4	9233C	SHAFT, DRAWBAR


Y-Axis Drive Parts

* See Maintenance section of manual for correct installation procedure



Y-AXIS ASSEMBLY PARTS			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	6481	Motor
2	4	MF-30	Socket Head Cap Screw
3	1	9001M	Coupler Assembly
4	1	504-34-53	Oil Seal
5	1	504-34-54	Lock Nut
6	3	6778D	Bearing
7	1	11008A	Direct Drive Motor Housing
8	1	MF-191A	Grease Fitting
9	1	100-82-2	Brass Tip Set Screw
10	1	504-34-15A	Thrust Nut
11	1	9201A	Ball Screw
12	1	7245E	Snap Ring
13	1	6778D	Bearing
14	1	9001A	Ball Screw Support

Column and Spindle Base Retainers



COLUMN & SPINDLE BASE RETAINERS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1 & 6	9202B	Column Gib Bar Top	2
2	9202A	Left Gib Bar	1
3	6140A	Left Bearing Way	1
4	6141A	Right Bearing Way	1
5	9202	Right Gib Bar	1

Column Base Parts

Assembly Image and Parts List are unavailable at this time.

Please visit the service tab of our web page www.rottlermfg.com and Send a Service Request. Or contact the Rottler Factory Service at service@rottlermfg.com for assistance.


You may also call Rottler at 1-800-452-0534 or 1-253-872-7050

Please ensure you have the Machine Model and Serial Number available when contacting Rottler for Service


Pendent Swing Arm Assembly Parts List

Pendant Swing Arm Assembly			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	6201L	Swing Arm Support
2	1	6200B	Swing arm
3	1	6200J	Plug
4	2	6200L	Tubing Plug, Slotted
5	1	6201H	Hinge Block
6	1	6197B	Swivel
7	1	6198b	Swivel Housing
8	1	6358	1" Straight Sealtight Fitting
9	2	502-3-17	Washer
10	1	6385E	Support Plate
11	2	Mf-44	Socket Head Cap screw 1/2 - 13 UNC - 1 1/2
12	2	Washer	
13	2	Mf-41A	Socket Head Cap screw 1/2 - 13 UNC - 3 1/2
14	2	MF-188	Nylock Nut
15	2	6201J	Hexagon Socket Head Shoulder Screw
16	3	MF-204	Pin - Hardened Ground Machine Dowel
17	2	MF-71	Hexagon Socket Set Screw - Cup Point
18	1	Pendant Assembly	
19	2	Mf-98	Socket Button Head Cap Screw 3/8 - 16 x 3/4
20	2	Mf-31	Socket Head Cap screw 3/8 - 16 UNC - 1
21	4	100-28-32	Thrust Washer

Pendant Components




ITEM	PART #	DESCRIPTION
1	6198Q	ENCLOSURE,PENDANT CONTROL
2	6198S	FACEPLATE WITH KEYBOARD TRAY
3	650-1-28X	TOUCH PANEL-15" WITH USB PORT
4	6389B	PLATE,LEGEND-EMERGENCY STOP PUSHBUTTON
5	6389D	PUSHBUTTON,EMERGENCY STOP
6	6428	WHEEL,HAND-MANUAL FEED
7	650-1-2G	HANDLE, TOUCH PANEL
8	502-12-7M	DIGITAL RUN OUT INDICATOR

Main Base Parts

MAIN BASE PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	9219B	Cable Carrier	2
2	9114	Way Cover Set	2
3 & 7	9011A	Left Way Cover Support	2
4 & 5	9011B	Right Way Cover Support	2
6	6351Q	Electrical Hookup Box	1

X-Axis Assembly: Drive End Parts


✱ See Maintenance section of manual for correct installation procedure




ITEM	PART #	DESCRIPTION
1	9215F	X-AXIS MOTOR
2	MF-39	SOCKET HEAD CAP SCREW 7/16-14 X 1"
3	9113M	COUPLING ASSEMBLY
4	9113F	SEAL
5	9113A	LOCK NUT
6	9113B	LOCK WASHER
7	9113H	BEARING, X-AXIS BALLSCREW
8	9113K	SEAL, BALLSCREW X-AXIS
9	9113J	NUT, BEARING RETAINING
10	9201J	SPACER, SEAL X-AXIS BALLSCREW
11	6073V	DRIVE KEY
12	MF-191A	5/16-32 STRAIGHT LUBE GREASE FITTING
13	MF-248	SOCKET BUTTON HEAD SCREW 1/4-20 X 3/8"
14	9113D	COVER, SUPPORT HOUSING
15	9212C	HOUSING, BALLSCREW DRIVE - X-AXIS
16	100-82-1	SPRING, ADJUSTING PIN

X-Axis Assembly: Idle End

* See Maintenance section of manual for correct installation procedure




X-AXIS IDLE END PARTS			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	9112D	Ball Screw Nut Mount
2	1	6073U	Ball Screw Nut Assembly
3	6	MF-22	Socket Head Cap Screw
4	1	9201G	Ball Screw
5	1	9232	Ball Screw Over Travel Spring
6	1	ME-189	Grease Fitting
7	1	9112F	Ball Screw Support
8	1		Seal
9	2	9113	Bearing
10	1	9113B	Lock Washer
11	1	9113A	Lock Nut
12	1	9113D	Cover
13	4	MF-248	Round Head Cap Screw

Chip Shield Assembly


CHIP SHIELD PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	11031E	Side Brush	2
2	9221A	Side Window	2
3	9221	Chip Shield Housing	1
4	9221B	Front Window	1
5	650-1-29G	Handle	1
6	11031H	Front Brush	1

Front Cover and Lights




ITEM	PART #	DESCRIPTION
1	6457N	BALLAST, CHIP SHIELD LED
2	9222C	LIGHT MOUNT-COVER, SPINDLE BASE
3	6457N	LIGHT, CHIP SHIELD LED
4	10013F	RIGHT SIDE COVER, LOWER-SPINDLE BASE

Oil Line Diagram



Air Line Diagram



This page intentionally left blank

OPTIONS

Optional Equipment

Optional Equipment Catalog and Parts Manual are located on the Manual CD shipped with machine.

MSDS

The Material Data Safety Sheets list shown in this section are the substances and materials that an operator is most likely to come in contact with while using this machine.

Other substances and materials are used in the manufacture, testing, and shipping of this machine. A complete list of the Material Data Safety Sheets of substances and materials used by Rottler Manufacturing during manufacturing, testing, and shipping is located on the Manual CD shipped with the machine. Material Data Safety Sheets are also located on the company web site: <http://www.rottlermfg.com/documentation.php>

1) Mobil Vactra Oil #2



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17 Oct 2008
 Page 1 of 8

MATERIAL SAFETY DATA SHEET

SECTION 1 PRODUCT AND COMPANY IDENTIFICATION

PRODUCT

Product Name: MOBIL VACTRA OIL NO. 2
Product Description: Base Oil and Additives
Product Code: 600494-00, 970716
Intended Use: Lubricant

COMPANY IDENTIFICATION

Supplier: EXXON MOBIL CORPORATION
 3225 GALLOWS RD.
 FAIRFAX, VA. 22037 USA

24 Hour Health Emergency: 609-737-4411
Transportation Emergency Phone: 800-424-9300
ExxonMobil Transportation No.: 281-834-3296
Product Technical Information: 800-662-4525, 800-947-9147
MSDS Internet Address: <http://www.exxon.com>, <http://www.mobil.com>

SECTION 2 COMPOSITION / INFORMATION ON INGREDIENTS

No Reportable Hazardous Substance(s) or Complex Substance(s).

SECTION 3 HAZARDS IDENTIFICATION

This material is not considered to be hazardous according to regulatory guidelines (see (M)SDS Section 15).

POTENTIAL HEALTH EFFECTS

Low order of toxicity. Excessive exposure may result in eye, skin, or respiratory irritation. High-pressure injection under skin may cause serious damage.

NFPA Hazard ID: Health: 0 Flammability: 1 Reactivity: 0
HMIS Hazard ID: Health: 0 Flammability: 1 Reactivity: 0

NOTE: This material should not be used for any other purpose than the intended use in Section 1 without expert advice. Health studies have shown that chemical exposure may cause potential human health risks which may vary from person to person.

SECTION 4 FIRST AID MEASURES

INHALATION

Remove from further exposure. For those providing assistance, avoid exposure to yourself or others. Use adequate respiratory protection. If respiratory irritation, dizziness, nausea, or unconsciousness occurs, seek immediate medical assistance. If breathing has stopped, assist ventilation with a mechanical device or use



Product Name: MOBIL VACTRA OIL NO. 2
Revision Date: 17Oct2008
Page 2 of 8

mouth-to-mouth resuscitation.

SKIN CONTACT

Wash contact areas with soap and water. If product is injected into or under the skin, or into any part of the body, regardless of the appearance of the wound or its size, the individual should be evaluated immediately by a physician as a surgical emergency. Even though initial symptoms from high pressure injection may be minimal or absent, early surgical treatment within the first few hours may significantly reduce the ultimate extent of injury.

EYE CONTACT

Flush thoroughly with water. If irritation occurs, get medical assistance.

INGESTION

First aid is normally not required. Seek medical attention if discomfort occurs.

SECTION 5 FIRE FIGHTING MEASURES

EXTINGUISHING MEDIA

Appropriate Extinguishing Media: Use water fog, foam, dry chemical or carbon dioxide (CO₂) to extinguish flames.

Inappropriate Extinguishing Media: Straight Streams of Water

FIRE FIGHTING

Fire Fighting Instructions: Evacuate area. Prevent runoff from fire control or dilution from entering streams, sewers, or drinking water supply. Firefighters should use standard protective equipment and in enclosed spaces, self-contained breathing apparatus (SCBA). Use water spray to cool fire exposed surfaces and to protect personnel.

Hazardous Combustion Products: Smoke, Fume, Aldehydes, Sulfur oxides, Incomplete combustion products, Oxides of carbon

FLAMMABILITY PROPERTIES

Flash Point [Method]: >205C (401F) [ASTM D-92]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Autoignition Temperature: N/D

SECTION 6 ACCIDENTAL RELEASE MEASURES

NOTIFICATION PROCEDURES

In the event of a spill or accidental release, notify relevant authorities in accordance with all applicable regulations. US regulations require reporting releases of this material to the environment which exceed the applicable reportable quantity or oil spills which could reach any waterway including intermittent dry creeks. The National Response Center can be reached at (800)424-8802.

SPILL MANAGEMENT



Product Name: MOBIL VACTRA OIL NO. 2
Revision Date: 17Oct2008
Page 3 of 8

Land Spill: Stop leak if you can do it without risk. Recover by pumping or with suitable absorbent.

Water Spill: Stop leak if you can do it without risk. Confine the spill immediately with booms. Warn other shipping. Remove from the surface by skimming or with suitable absorbents. Seek the advice of a specialist before using dispersants.

Water spill and land spill recommendations are based on the most likely spill scenario for this material; however, geographic conditions, wind, temperature, (and in the case of a water spill) wave and current direction and speed may greatly influence the appropriate action to be taken. For this reason, local experts should be consulted. Note: Local regulations may prescribe or limit action to be taken.

ENVIRONMENTAL PRECAUTIONS

Large Spills: Dike far ahead of liquid spill for later recovery and disposal. Prevent entry into waterways, sewers, basements or confined areas.

SECTION 7 HANDLING AND STORAGE

HANDLING

Prevent small spills and leakage to avoid slip hazard.

Static Accumulator: This material is a static accumulator.

STORAGE

Do not store in open or unlabelled containers. Keep away from incompatible materials.

SECTION 8 EXPOSURE CONTROLS / PERSONAL PROTECTION

Exposure limits/standards for materials that can be formed when handling this product: When mists / aerosols can occur, the following are recommended: 5 mg/m³ - ACGIH TLV, 10 mg/m³ - ACGIH STEL, 5 mg/m³ - OSHA PEL.

NOTE: Limits/standards shown for guidance only. Follow applicable regulations.

ENGINEERING CONTROLS

The level of protection and types of controls necessary will vary depending upon potential exposure conditions. Control measures to consider:
No special requirements under ordinary conditions of use and with adequate ventilation.

PERSONAL PROTECTION

Personal protective equipment selections vary based on potential exposure conditions such as applications, handling practices, concentration and ventilation. Information on the selection of protective equipment for use with this material, as provided below, is based upon intended, normal usage.

Respiratory Protection: If engineering controls do not maintain airborne contaminant concentrations at a level which is adequate to protect worker health, an approved respirator may be appropriate. Respirator



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17 Oct 2008
 Page 4 of 8

selection, use, and maintenance must be in accordance with regulatory requirements, if applicable. Types of respirators to be considered for this material include:

No special requirements under ordinary conditions of use and with adequate ventilation.

For high airborne concentrations, use an approved supplied-air respirator, operated in positive pressure mode. Supplied air respirators with an escape bottle may be appropriate when oxygen levels are inadequate, gas/vapor warning properties are poor, or if air purifying filter capacity/rating may be exceeded.

Hand Protection: Any specific glove information provided is based on published literature and glove manufacturer data. Glove suitability and breakthrough time will differ depending on the specific use conditions. Contact the glove manufacturer for specific advice on glove selection and breakthrough times for your use conditions. Inspect and replace worn or damaged gloves. The types of gloves to be considered for this material include:

No protection is ordinarily required under normal conditions of use.

Eye Protection: If contact is likely, safety glasses with side shields are recommended.

Skin and Body Protection: Any specific clothing information provided is based on published literature or manufacturer data. The types of clothing to be considered for this material include:

No skin protection is ordinarily required under normal conditions of use. In accordance with good industrial hygiene practices, precautions should be taken to avoid skin contact.

Specific Hygiene Measures: Always observe good personal hygiene measures, such as washing after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants. Discard contaminated clothing and footwear that cannot be cleaned. Practice good housekeeping.

ENVIRONMENTAL CONTROLS

See Sections 6, 7, 12, 13.

SECTION 9

PHYSICAL AND CHEMICAL PROPERTIES

Typical physical and chemical properties are given below. Consult the Supplier in Section 1 for additional data.

GENERAL INFORMATION

Physical State: Liquid
Color: Brown
Odor: Characteristic
Odor Threshold: N/D

IMPORTANT HEALTH, SAFETY, AND ENVIRONMENTAL INFORMATION

Relative Density (at 15 C): 0.883
Flash Point [Method]: >205C (401F) [ASTM D-92]
Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0
Autoignition Temperature: N/D
Boiling Point / Range: N/D
Vapor Density (Air = 1): > 2 at 101 kPa
Vapor Pressure: <0.013 kPa (0.1 mm Hg) at 20 C
Evaporation Rate (n-butyl acetate = 1): N/D
pH: N/A



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17Oct2008
 Page 5 of 8

Log Pow (n-Octanol/Water Partition Coefficient): >3.5
Solubility in Water: Negligible
Viscosity: 68 cSt (68 mm²/sec) at 40 C | 8.6 cSt (8.6 mm²/sec) at 100C
Oxidizing Properties: See Sections 3, 15, 16.

OTHER INFORMATION

Freezing Point: N/D
Melting Point: N/A
Pour Point: -6°C (21°F)
DMSO Extract (mineral oil only), IP-346: <3 %wt

SECTION 10 STABILITY AND REACTIVITY

STABILITY: Material is stable under normal conditions.

CONDITIONS TO AVOID: Excessive heat. High energy sources of ignition.

MATERIALS TO AVOID: Strong oxidizers

HAZARDOUS DECOMPOSITION PRODUCTS: Material does not decompose at ambient temperatures.

HAZARDOUS POLYMERIZATION: Will not occur.

SECTION 11 TOXICOLOGICAL INFORMATION

ACUTE TOXICITY

Route of Exposure	Conclusion / Remarks
Inhalation	
Toxicity (Rat): LC50 > 5000 mg/m ³	Minimally Toxic. Based on test data for structurally similar materials.
Irritation: No end point data.	Negligible hazard at ambient/normal handling temperatures. Based on assessment of the components.
Ingestion	
Toxicity (Rat): LD50 > 5000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Skin	
Toxicity (Rabbit): LD50 > 5000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Irritation (Rabbit): Data available.	Negligible irritation to skin at ambient temperatures. Based on test data for structurally similar materials.
Eye	
Irritation (Rabbit): Data available.	May cause mild, short-lasting discomfort to eyes. Based on test data for structurally similar materials.

CHRONIC/OTHER EFFECTS

Contains:

Base oil severely refined: Not carcinogenic in animal studies. Representative material passes IP-346, Modified Ames test, and/or other screening tests. Dermal and inhalation studies showed minimal effects; lung non-specific infiltration of immune cells, oil deposition and minimal granuloma formation. Not sensitizing in test animals.



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17 Oct 2008
 Page 6 of 8

Additional information is available by request.

The following ingredients are cited on the lists below: None.

	--REGULATORY LISTS SEARCHED--		
1 = NTP CARC	3 = IARC 1		5 = IARC 2B
2 = NTP SUS	4 = IARC 2A		6 = OSHA CARC

SECTION 12 ECOLOGICAL INFORMATION

The information given is based on data available for the material, the components of the material, and similar materials.

ECOTOXICITY

Material -- Not expected to be harmful to aquatic organisms.

MOBILITY

Base oil component -- Low solubility and floats and is expected to migrate from water to the land. Expected to partition to sediment and wastewater solids.

PERSISTENCE AND DEGRADABILITY

Biodegradation:

Base oil component -- Expected to be inherently biodegradable

BIOACCUMULATION POTENTIAL

Base oil component -- Has the potential to bioaccumulate, however metabolism or physical properties may reduce the bioconcentration or limit bioavailability.

SECTION 13 DISPOSAL CONSIDERATIONS

Disposal recommendations based on material as supplied. Disposal must be in accordance with current applicable laws and regulations, and material characteristics at time of disposal.

DISPOSAL RECOMMENDATIONS

Product is suitable for burning in an enclosed controlled burner for fuel value or disposal by supervised incineration at very high temperatures to prevent formation of undesirable combustion products.

REGULATORY DISPOSAL INFORMATION

RCRA Information: The unused product, in our opinion, is not specifically listed by the EPA as a hazardous waste (40 CFR, Part 261D), nor is it formulated to contain materials which are listed as hazardous waste. It does not exhibit the hazardous characteristics of ignitability, corrosivity or reactivity and is not formulated with contaminants as determined by the Toxicity Characteristic Leaching Procedure (TCLP). However, used product may be regulated.

Empty Container Warning Empty Container Warning (where applicable): Empty containers may contain residue and can be dangerous. Do not attempt to refill or clean containers without proper instructions. Empty drums should be



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17Oct2008
 Page 7 of 8

completely drained and safely stored until appropriately reconditioned or disposed. Empty containers should be taken for recycling, recovery, or disposal through suitably qualified or licensed contractor and in accordance with governmental regulations. DO NOT PRESSURISE, CUT, WELD, BRAZE, SOLDER, DRILL, GRIND, OR EXPOSE SUCH CONTAINERS TO HEAT, FLAME, SPARKS, STATIC ELECTRICITY, OR OTHER SOURCES OF IGNITION. THEY MAY EXPLODE AND CAUSE INJURY OR DEATH.

SECTION 14 TRANSPORT INFORMATION

LAND (DOT) : Not Regulated for Land Transport

LAND (TDG) : Not Regulated for Land Transport

SEA (IMDG) : Not Regulated for Sea Transport according to IMDG-Code

AIR (IATA) : Not Regulated for Air Transport

SECTION 15 REGULATORY INFORMATION

OSHA HAZARD COMMUNICATION STANDARD: When used for its intended purposes, this material is not classified as hazardous in accordance with OSHA 29 CFR 1910.1200.

NATIONAL CHEMICAL INVENTORY LISTING: AICS, IECSC, DSL, EINECS, ENCS, KECI, PICCS, TSCA

EPCRA: This material contains no extremely hazardous substances.

SARA (311/312) REPORTABLE HAZARD CATEGORIES: None.

SARA (313) TOXIC RELEASE INVENTORY: This material contains no chemicals subject to the supplier notification requirements of the SARA 313 Toxic Release Program.

The Following Ingredients are Cited on the Lists Below: None.

--REGULATORY LISTS SEARCHED--

1 = ACGIH ALL	6 = TSCA 5a2	11 = CA P65 REPRO	16 = MN RTK
2 = ACGIH A1	7 = TSCA 5e	12 = CA RTK	17 = NJ RTK
3 = ACGIH A2	8 = TSCA 6	13 = IL RTK	18 = PA RTK
4 = OSHA Z	9 = TSCA 12b	14 = LA RTK	19 = RI RTK
5 = TSCA 4	10 = CA P65 CARC	15 = MI 293	

Code key: CARC=Carcinogen; REPRO=Reproductive

SECTION 16 OTHER INFORMATION

N/D = Not determined, N/A = Not applicable

THIS SAFETY DATA SHEET CONTAINS THE FOLLOWING REVISIONS:



Product Name: MOBIL VACTRA OIL NO. 2
Revision Date: 17 Oct 2008
Page 8 of 8

No revision information is available.

The information and recommendations contained herein are, to the best of ExxonMobil's knowledge and belief, accurate and reliable as of the date issued. You can contact ExxonMobil to insure that this document is the most current available from ExxonMobil. The information and recommendations are offered for the user's consideration and examination. It is the user's responsibility to satisfy itself that the product is suitable for the intended use. If buyer repackages this product, it is the user's responsibility to insure proper health, safety and other necessary information is included with and/or on the container. Appropriate warnings and safe-handling procedures should be provided to handlers and users. Alteration of this document is strictly prohibited. Except to the extent required by law, republication or retransmission of this document, in whole or in part, is not permitted. The term, "ExxonMobil" is used for convenience, and may include any one or more of ExxonMobil Chemical Company, Exxon Mobil Corporation, or any affiliates in which they directly or indirectly hold any interest.

Internal Use Only

MHC: 0B,0B,0,0,0,0

PPEC: A

DGN: 2007221XUS (1014962)

Copyright 2002 Exxon Mobil Corporation, All rights reserved