



F80DM SERIES

**MULTI-PURPOSE CNC
MACHINING CENTERS**

MACHINE SERIAL NUMBER

OPERATIONS AND MAINTENANCE
MANUAL



MANUFACTURED BY:

ROTTLER MANUFACTURING COMPANY
8029 South 200th Street
Kent Washington 98032
USA

Phone: (253) 872-7050

Fax: (253) 395-0230

Website: <http://www.rottlermfg.com>

MANUAL SECTIONS

INTRODUCTION

INSTALLATION

SAFETY

CONTROL DEFINITIONS

OPERATING INSTRUCTIONS

MAINTENANCE

TROUBLESHOOTING

MACHINE PARTS

OPTIONS

MSDS

ORDERING PROCEDURE

Contact your regional Rottler sales rep for assistance in ordering optional equipment, replacement parts, or tooling.

If you are unable to contact your regional Rottler sales rep, call the factory at 253-872-7050 and ask to speak to the parts sales specialist.

Have the following information handy to expedite the ordering process:


1. Your name, business name, and contact number
2. Customer number
3. If you don't have a customer number, your billing address
4. Shipping address if different from billing address
5. Machine model and serial number
6. Part number and description of what you want to order
7. Preferred method of shipment
8. You may also contact us via e-mail with the above information. Send e-mail requests to:
parts@rottlermfg.com

In some cases you may be requested to send a photo of the part you are ordering if it is a replacement part, or doesn't appear in the database.

If you are unsure which part you need to order, contact our service department and ask to speak to one of our service consultants. They will assist you in determining which part you require.

THERE IS A MINIMUM ORDER OF \$25.00

INTRODUCTION



READ THE SAFETY CHAPTER BEFORE INSTALLING MACHINE. THOROUGHLY UNDERSTAND ALL SAFETY ISSUES BEFORE OPERATING MACHINE.

ATTENTION OWNER/BUSINESS MANAGER

To validate the warranty on your new Rottler machine, please be sure to sign and complete the “Installation Report” located in the Installation Chapter of this manual.

We suggest that the new user of the F80DM read the CONTROL DEFINITIONS to get an idea how the machine operates.

The Operating Instructions chapter should be read in order to familiarize the user with the actual button pushing sequences required to carry out a job. These chapters in the manual should be considered an introduction. As the operators of the F80DM series machines gain experience with using the different functions of the machine, complicated setups and programs will make more sense.

The rest of the manual contains information and part number reference on fixtures, cutting tools, and machine maintenance. The operator should read and become familiar with these areas as well.

Description

The model F80DM machine is a precision, single point boring, and high-speed surfacing unit. The machine can be equipped with tooling and accessories for surfacing and re-boring most American passenger car and truck engines, In-lines, as well as 90 and 60 degree V-types.

F80DM machines can be easily tooled, to machine a wide range of engines, including European and Asian engines, also, the machine can be easily adapted to perform other boring and surfacing operations.

The machine is designed, to maintain alignment of cylinder bores, and cylinder head, deck surfaces to the pan rails and main bearing bore locations, as was done in the original factory machining. This overcomes the many inaccuracies and out-of-alignment problems associated with clamping portable boring bars to the cylinder head surface of blocks.

Convenient controls, fast block clamping, precise 3 axis CNC positioning and clamping, means considerable savings in floor to floor time, and operator involvement.

Change over or resetting time required to set up V-type or in-line engines is a minimum, making this machine highly suited to the jobber shop where engines cannot be run through in model lots.

All feeds and rapid travels are power operated and controlled from the control panel.

Disclaimer

The F80DM Manual (henceforth to be referred to as the "Manual") is proprietary to Rottler Manufacturing LLC. ("Rottler Manufacturing") and no ownership rights are hereby transferred. No part of the Manual shall be used, reproduced, translated, converted, adapted, stored in a retrieval system, communicated or transmitted by any means, for any commercial purpose, including without limitation, sale, resale, license, rental or lease, without the prior express written consent of Rottler Manufacturing.

Rottler Manufacturing does not make any representations, warranties or guarantees, express or implied, as to the accuracy or completeness of the Manual. Users must be aware that updates and amendments will be made from time to time to the Manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither Rottler Manufacturing nor any of its directors, officers, employees or agents shall not be liable in any manner whatsoever to any person for any loss, damage, injury, liability, cost or expense of any nature, including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of the Manual.

Limited Warranty

Rottler Manufacturing Company Model F80DM parts and equipment is warranted as to materials and workmanship. This limited warranty remains in effect for one year from the date of delivery, provided the machine is owned and operated by the original purchaser and is operated and maintained as per the instructions in the manual.

Tools proven to be defective within the warranty period will be repaired or replaced at the factory's option.

The products are warranted upon delivery to conform to their published specifications and to be free from defects in material and workmanship under normal use for a period of one year from shipment. Should a product not be as warranted, Rottler sole obligation shall be, at its option, to repair, correct or replace the product or to refund the amounts paid for the Product upon its return to a location designated by Rottler. No warranty shall extend to rapid wear Products (including tooling) or to Products which have been subject to misuse (including any use contrary to Rottler instructions), neglect, accident (including during shipment), improper handling or installation, or subject to any modification, repair or service not certified by Rottler. Rottler shall not be liable for any consequential, direct or indirect damages or for any other injury or loss. Buyer waives any right, beyond the foregoing warranty, to make a claim against Rottler. No warranty is provided for any products not paid in full.

Merchandise cannot be returned to Rottler without prior approval. Customer must contact the Order Department or representative to get approval and to be issued a Return Goods Authorization number (RGR#). Merchandise authorized for return must be returned prepaid. If merchandise is returned with shipping charges collect, the actual amount of these charges may be deducted from any credit which may be due the customer. The RGR # assigned by the Order Department should be written on the shipping label and must appear on a copy of the invoice(s) covering the original shipment. This invoice copy must be included in the box with the parts. Shipment must contain ONLY those items on the RGR as approved for return. Merchandise must be received within 10 days of the date of RGR or the RGR will be canceled. All returned merchandise may be subject to a 20% restocking fee on under \$1,000.00 amount or 10% on any items over \$1,000.00. Parts or tooling over 30 days old are considered as customer property and can only be returned with prior written approval from Rottler Corporation Management and/or Shipping Department.

The issuance of a RGR DOES NOT guarantee credit - it is only authorization for the return of the goods. Credit for return merchandise is at the sole discretion of Rottler. Credit will be issued only after inspection of returned goods.

Tools proven to be defective within the warranty period will be repaired or replaced at the factory's option. We accept no responsibility for defects caused by external damage, wear, abuse, or misuse, nor do we accept any obligation to provide compensation for direct or indirect costs in connection with cases covered by the warranty.

This page intentionally left blank

INSTALLATION

Contents

UPGRADE INSTALLATION REPORT.....	2-2
Air Supply.....	2-8
Power Supply.....	2-9
Grounding.....	2-9

ATTENTION OWNER/BUSINESS MANAGER

To validate the warranty on your new Rottler machine, please be sure to sign the installation report after the installation technician has installed the machine and verified the machine is operating correctly and given the operators operation and maintenance training.

Thank you for your cooperation and the opportunity to be of service to you.

ROTTLER MANUFACTURING

Route to: Service Mgr → Andy → Machine Packet File
 Upgrade Installation Report Rev Draft

UPGRADE INSTALLATION REPORT

ROTTLER MANUFACTURING MUST HAVE THIS REPORT RETURNED TO PROPERLY QUALIFY WARRANTY ON EQUIPMENT

Customer: _____ Address: _____
 City: _____ State: _____ Zip: _____ Phone: _____
 Machine Model: _____ Serial Number: _____ Representative: _____

MACHINE UPGRADE:

The following is the customer's responsibility prior to the arrival of Rottler technician. Please initial each item when it is completed.

⚠ CAUTION *VERY IMPORTANT:* Modern design machines contain electronic low voltage circuitry that provides great advantages and a better machine life. BUT, you must have an excellent, stable, isolated power supply along with an isolated ground. If not, electrical noise problems are likely to interfere with machine operation unexpectedly.

Customer is responsible for providing electricity to machine in a manner that meets the local electrical code requirements.

This machine requires between 208 and 240 Volts AC, Three Phase, 50/60 Hz, isolated power supply. For voltages above 240 or below 208 VAC, a 17kva transformer will be required and is available at Rottler. Please specify voltage when ordering.

_____ Measure the incoming voltage between L1 and L2, L2 and L3, and L1 and L3. Current requirements for this machine is 60 amps. Measure the incoming AC voltage at least twice during installation.

1. L1to L2 _____ VAC, L2 to L3 _____ VAC, L1 to L3 _____ VAC
2. L1to L2 _____ VAC, L2 to L3 _____ VAC, L1 to L3 _____ VAC

_____ Measure each leg of the incoming supply to ground. Sometimes you may find a "high" leg to ground. When this happens make sure the high leg is running to L3. This line goes to the spindle drive only.

L1 to ground _____ VAC L2 to ground _____ VAC L3 to ground _____ VAC

⚠ CAUTION Neutral and machine ground are not the same thing. You should measure an open circuit between Neutral and ground.

⚠ CAUTION IF VOLTAGE IS OUTSIDE THE CORRECT RANGE AT ANY TIME THE MACHINE WILL NOT OPERATE PROPERLY AND MAY BE DAMAGED.

- _____ Air of the proper pressure and capacity connected to the machine. Air supply must be free from oil and water. Oil or water will damage electrical and air components.
- _____ Customer should attempt to have junk work piece available.
- _____ Have the operator read through the operation manual before training begins. This will help him be familiar with the button pushing sequences. Have the operator read through the manual again after training and some of the sequences will make more sense.
- _____ Have Internet connection available for the machine. Either via Ethernet cable or Wireless. The machine comes equipped with a wireless USB adapter.

THE FOLLOWING ITEMS ARE THE TECHNICIANS RESPONSIBILITY:

- _____ Verify incoming power to the machine before turning the machine on. This should be between 208-240 Volts
- _____ Turn the machine on and verify the screen comes on
- _____ Release the e-stop and verify the e-stop is working correctly
- _____ Tune all motors to Rottler specifications
- _____ Set soft limits for each Axis (Verify they are working correctly)
- _____ Verify all air functions are working correctly
- _____ Verify Skype and log me in are installed and set up
- _____ Check the software to confirm the current release is being used
- _____ Set backlash for all Axis following Instruction Bulletin #317

MACHINE START-UP:

⚠ CAUTION When starting the machine for the first time, it may move out of control. Make sure all hands are clear of machine parts. Be ready to press the Emergency Stop button if needed.

MACHINE MOVEMENTS:

- _____ Make sure there is nothing obstructing the full vertical, horizontal or In/Out travel of the machine taking special notice of the rear enclosure, way travel and top of the spindle unit.
- _____ Put the machine in hand wheel mode and verify Vertical operation. Put an indicator on the cutter head and verify .001" movement per detent in course mode and .0001" in fine mode. If the indicator is jumpy the outer spindle adjustment may be too tight. Refer to manual and re-adjust.
- _____ Put the machine in hand wheel mode and verify Horizontal operation. Put an indicator on the cutter head and verify .001" movement per detent in course mode and .0001" in fine mode
- _____ Use the rapid buttons and verify proper vertical, horizontal and In/out travel.
- _____ Check limit switch operation with handwheel before using the power feed.
- _____ Move the machine to its vertical limits to verify proper operation.

- _____ Move the machine to its horizontal limits to verify proper operation.
- _____ Move the machine to its In/Out limits to verify proper operation.
- _____ Start the spindle and verify operation at all speeds.
- _____ Use the spindle creep buttons and verify proper operation.
- _____ Prime the oiling system. (See maintenance section of manual for complete details.)
- _____ Use a precision level and level the machine
- _____ Record Dial Indicator readings:
 - _____ Spindle to Back Table:
 - P1 _____ P2 _____ P3 _____ P4 _____ P5 _____ P6 _____ P7 _____ P8 _____
 - _____ Spindle to Front Table:
 - P1 _____ P2 _____ P3 _____ P4 _____ P5 _____ P6 _____ P7 _____ P8 _____
- _____ Check mill tilt, and lift amounts with Y axis in the middle of travel, and record Amount of tilt
 - _____

The following procedures should be shown to personal involved in machine maintenance.

See maintenance section of manual for complete details.

- _____ Check and adjust X axis gibs
- _____ Adjust outer spindle bushings.
- _____ Adjust inner spindle bearings
- _____ Perform spindle sweep adjustment.
- _____ Verify ALL axis backlash comp is operating properly, adjust if needed. Record actual readings after verification.

	Auto	Handwheel
X-Axis	_____	_____
Y-Axis	_____	_____
Z-Axis	_____	_____

- _____ Install way cover brackets and way covers. Way Cover support brackets should be flush with way surface.

INSTRUCTING THE OPERATOR:



- _____ Explain to the customer and operator that at NO time is there to be any software or hardware other than Windows Auto Update and Rottler installed on this machine. This includes screen savers, anti-virus software, and any hardware device that installs software on the machine. Installation of screen savers and anti-virus software can cause dangerous control problems. Any installation of software or hardware will void the warranty on the machine.

- _____ Explain to the customer and operator that the machine should be hooked up to the Internet anytime it is on. The software on the machine will automatically connect to our server to send back useful information on machine status.
- _____ Explain to the customer and operator that the Auto Update for the Windows Firewall (Security) and Windows Defender (Anti-Virus) is turned on. The computer will automatically download the updates and then install them when the computer is shut down every Friday night.
- _____ Explain to the customer and the operator how to log onto Skype and communicate with Rottler when needed.

⚠ WARNING

- _____ Computer Viruses will cause the machine control system to become unstable. This may cause the machine to make uncontrolled moves which could create a dangerous environment for the machine operator.
- _____ Connect customer supplied Internet to the machine. Verify that the Internet is accessible from the machine.

IMPORTANT

- _____ Refer to Chapter 4, Control Definitions of the Machine Manual, Section: Computer and Controller System Safety. Explain and discuss this section carefully with Owner/Manager/Operator and have them sign off. Failure to do so will result in the machine warranty being ***Null and Void***.

Signature / Title

- _____ Explain to the customer the proper way to turn the machine off when it is not in use. Do not leave the machine on overnight. It is important to close all programs followed by shutting down Windows before turning the main power switch off. Do not turn the main power switch off before shutting down Windows.
- _____ Using the operating manual as a guide explain the function of all buttons.
- _____ Cycle all machine movements and supervise the handling of same by operator.
- _____ Demonstrate the differences of Manual and Auto operation.
- _____ Fully explain the entire Auto Cycle from Centering to Auto Retract.
- _____ Explain machine parameters and error messages. It is very important that the customer does not change parameter settings without first checking with Rottler Manufacturing. If certain parameters are changed the machine may make uncontrolled moves or not operate at all.
- _____ Point out safety features to customer and operator. Do not push any buttons without thinking of safety first.



Do not assume the cutterhead micrometer has been calibrated.

_____ Install a work piece in the machine and perform an undersize test bore to qualify the micrometer setting to the customers measuring tools.

Note adjustments: + _____, - _____.

_____ Explain precision reset of tool in cutterhead.

_____ The following is a checklist to go through every time the machine is started to begin a cut or automatic cycle.

- Work piece secure
- RPM set
- Feed Rate set
- Correct program in use
- Program oriented correctly (vertical zero at correct place) Centering range adequate
- Guards in place
- Cutterhead secure
- Tool holder adjusted to the correct size
- Tool holder locked in place

_____ Proceed to have operator bore block to size.

_____ Demonstrate and explain boring with the electronic hand wheel.

_____ Explain the correct Feed rates and speeds from Cutting Insert Bulletin.

_____ Cutter head change and expected stub bar performance.

_____ Parts ordering, refer the to the operating manual for part numbers and description.

_____ Offset tool bits, calibration of micrometer and anvil setting.

_____ Train on ALL Rottler programs even if they need to be run in the air.

_____ If Rottler CAM was provided to the customer train on any programs supplied by Rottler.

_____ Review Emergency stop procedure with operator per operating manual.

MAINTENANCE SECTION:

- _____ Use the manual as a reference when explaining routine maintenance and lubrication.
- _____ Overload devices, There are no mechanical overload devices on this machine. The machine is protected from overload by the motor controllers. If the system is overloaded the controllers shut the motors off. The controllers can be reset by turning the main power off for at least 1 minute, then turning it back on.
- _____ Explain again the proper Inner and Outer spindle adjustment to the operator.
- _____ Air float adjustment.
- _____ Dampener cleaning.
- _____ Micrometer and anvil thread adjustment.
- _____ Inspection of tool bit hole in tool holders (deformation due to accidental impact).

General remarks on machine performance, adjustments as received and any further organization or parts required to complete the set up:

Instructions given to: _____


Sales / Service Technician: _____ Date: _____

Shop Foreman / Superintendent or Owner: _____ Date: _____

Air Supply

It is very important the air source for the F80DM machine be moisture free. Water and oil in the line will result in early cylinder and valve failure. The factory recommends installing a water trap at the machine.

Attach a 100 PSI air source to the appropriate intake in the small enclosure located on the left rear of the machine near the bottom.



Power Supply

This machine has the following power requirements:

208 to 240 VAC

Three Phase

50 or 60 Hertz

60 amps


See illustration below for correct connection of “measured” incoming power. Connect three phase wiring to the electrical box located on the back of the machine in the lower right hand corner. See illustration below. If a “high leg” exists, this must be at Line 3. All ground wires go to ground block. Important:

Electrically connect in accordance with national and local electrical codes.

Note: For voltages over 240 VAC (380 – 440 VAC) a factory supplied transformer needs to be purchased with the machine.

Grounding

This machine must be connected to a good earth ground rod. A 6 foot, 1/2” diameter, 15 OHM, Copper grounding rod driven into the earth next to the machines is preferred. Not providing a grounding rod could void factory warranty.




SAFETY

Contents

Safety Information	3-1
Safety Instructions for Machine Use	3-1
Electrical Power	3-3
Machine Operator	3-5
Emergency Procedure	3-6
Computer and Controller System Safety	3-6
Electrical Safety Features Of Rottler DM Controlled Machines	3-7

Safety Information

For Your Own Safety Read This Instruction Manual Before Operating This Machine.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

Safety Instructions for Machine Use



This machine is capable of causing severe bodily injury

ONLY A QUALIFIED, EXPERIENCED OPERATOR SHOULD OPERATE THIS MACHINE. NEVER ALLOW UNSUPERVISED OR UNTRAINED PERSONNEL TO OPERATE THE MACHINE. Make sure any instructions you give in regards to machine operation are approved, correct, safe, and clearly understood. Untrained personnel present a hazard to themselves and the machine. Improper operation will void the warranty.

KEEP GUARDS IN PLACE and in proper working order. If equipped with doors, they must be in the closed position when the machine is in operation.



KEEP WORK AREA CLEAN. Cluttered areas and benches invite accidents.

KEEP CHILDREN AND VISITORS AWAY. All children and visitors should be kept a safe distance from work area.

WEAR THE PROPER APPAREL. **DO NOT** wear loose clothing, gloves, rings, bracelets, or other jewelry which may get caught in moving parts. Non-Slip foot wear is recommended. Wear protective hair covering to contain long hair.

ALWAYS USE SAFETY GLASSES. Also use face or dust mask if cutting operation is dusty. Everyday eye glasses only have impact resistant lenses, they are NOT safety glasses.



DO NOT OVER-REACH. Keep proper footing and balance at all times.

USE THE RECOMMENDED ACCESSORIES. Consult the manual for recommended accessories. The use of improper accessories may cause risk of injury.

CHECK DAMAGED PARTS. Before further use of the machine, a guard or other part that is damaged should be checked to determine that it will operate properly and perform its intended function. Check for alignment of moving parts, breakage of parts, mounting, and other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced.

NEVER OPERATE A MACHINE WHEN TIRED, OR UNDER THE INFLUENCE OF DRUGS OR ALCOHOL. Full mental alertness is required at all times when running a machine.

IF AT ANY TIME YOU ARE EXPERIENCING DIFFICULTIES performing the intended operation, stop using the machine! Then contact our service department or ask a qualified expert how the operation should be performed.

DO NOT MODIFY OR ALTER THIS EQUIPMENT in any way. If modifications are deemed necessary, all such requests must be approved and/or handled by Rottler Manufacturing. Unauthorized modifications could cause injury and/or damage to machine and will void the warranty.

SAFETY DECALS SHOULD NEVER BE REMOVED. They are there to convey important safety information and warn of potential hazards.

ALL LOCAL SAFETY CODES AND REGULATIONS should be followed when installing this machine.

ONLY QUALIFIED PERSONAL should perform service on the electrical and control systems.


When boring the machine is capable of throwing metal chips over 10- feet from the cutting area. Always use the guards. Eye protection must be worn at all times by the operator and all other personnel in the area of the machine.




CAUTION No list of safety guidelines can be complete. Every piece of shop environment is different. Always consider safety first, as it applies to your individual working conditions. Use this and other machinery with caution and respect. Failure to follow guidelines could result in serious personal injury, damage to equipment or poor work results.

Electrical Power

THIS MACHINE IS AUTOMATICALLY CONTROLLED AND MAY START AT ANYTIME




All electrical power should be removed from the machine before opening the rear electrical enclosure. It is recommended that the machine have a electrical LOCK-OUT device installed.



Make sure all electrical equipment has the proper electrical overload protection.

In the event of an electrical short, grounding reduces the risk of electric shock by providing a path of least resistance to disperse electric current.

Electrocution or a fire can result if the machine is not grounded correctly. Make sure the ground is connected in accordance with this manual. **DO NOT** operate the machine if it is not grounded.



CAUTION No single list of electrical guidelines can be comprehensive for all shop environments. Operating this machinery may require additional electrical upgrades specific to your shop environment. It is your responsibility to make sure your electrical system comply with all local codes and ordinances.

WARNING This machine operates under computerized control and, as is all computerized equipment, and is susceptible to extraneous electrical impulses internally for externally produced. The machine may make moves out of the operator control at any time. The operator should work in and around the machine with caution at all times.

The operator and nearby personnel should be familiar with the location and operation of the Emergency Stop Button.

Make sure all electrical equipment has the proper overload protection. ***This machine should have a fully isolated power supply*** to prevent damage and uncontrolled movement of the machine. If this machine is on the same power lines that are running to other electrical equipment (grinders, welders, and other AC motors) electrical noise can be induced into this machines electrical system. Electrical noise can cause the controller to see false signals to move. Not supplying a fully isolated supply to the machine may void factory warranty. Refer to the Power supply section located in the Installation section for voltage and


Machine Operator

The operator of this machine should be a skilled machinist craftsman who is well versed in the caution, care, and knowledge required to safely operate metal cutting tools.

If the operator is not a skilled machinist he/she must pay strict attention to the Operating Instructions outlined in this manual, and get instruction from a qualified machinist in both production and operation of this machine.

This machine has the following areas of exposed moving parts that you must train yourself to respect and stay away from when they are in motion:

Cutting Tool Area – Any operation involving hands in the cutter head area, such as inspection or alignment of the cutter head or tools, changing Centering Fingers, tool insertion, and removal, cutter head changes, and size checking etc. requires the machine to be in Neutral.



Machining – Eye protection must be worn during all operations of the machine. Hands must be kept completely away from the cutter head. All chip guards must be in position during machine operations.



CAUTION **Work Loading and Unloading** – Carefully develop handling methods of loading and unloading work pieces so that no injury can result if hoist equipment or lift connection should fail. Periodically check lift components for damage that may cause failure.

CAUTION **Machine Maintenance** – Any machine adjustment, maintenance or parts replacement absolutely requires a complete power disconnection from the machine, *this is an absolute rule.*

Emergency Procedure

Assuming one of the following has occurred: tool bit set completely off size, work piece or spindle base not clamped, spindle is not properly centered, and these mistakes will become obvious the minute the cut starts

PRESS THE EMERGENCY STOP BUTTON (on the front control panel) **IMMEDIATELY!**

Find out what the problem is; return the spindle to its up position without causing more damage. To restart the machine, turn the Emergency Stop Button CW until the button pops out

Be alert to quickly stop the machine in the event of a serious disruption of the boring process either at the top or bottom of the bores.

“REMEMBER” metal cutting tools have the speed and torque to severely injure any part of the human body exposed to them.

Computer and Controller System Safety

The computer and controller are located in the main rear electrical enclosure. This unit is a full computer, running Windows 7 64 Bit operating system. Contact the factory if more information on the computer system is required.

IMPORTANT The computer in this machine has the ability to connect to the World Wide Web via Ethernet or Wireless using a USB wireless (Wi-Fi) adapter. Updating the Rottler software should **ONLY** be done when directed to do so by a Rottler service technician. Updating Rottler Software when not directed by Rottler personnel will result in a non-operational machine.


The machine should be hooked up to the Internet anytime it is on. The software on the machine will automatically connect to our server to send back useful information on machine status.

The Auto Update for the Windows Firewall (Security) and Windows Defender (Anti-Virus) is turned on. The computer will automatically download the updates and then install them when the computer is shut down every Friday night.

Any “IT” personnel should **ALWAYS** get approval from Rottler before doing ANYTHING on the computer.

DANGER This machine is capable of causing severe injury or death. Doing any of the following without Rottler’s direct consent may cause severe injury or death.

WARNING Do not attempt to install USB devices in the PLC ports. These ports have high voltage and any attempt to connect a USB device in these ports will result in destruction of that device. There is also the possibility of damage to the computer system of the machine.



IMPORTANT Downloading any program or changing any Rottler or Computer settings may cause the machine and/or software to become unstable. **DO NOT** install ANY screen saver, Anti-Virus, Spyware or any type of Security software on the computer. This could create a hazardous environment for the operator and personnel around the machine. Performing any of the above will also result in the machine warranty being NULL and VOID.

IMPORTANT **DO NOT** connect any type of external hardware to the computer via USB or any other means. Do not install any type of Device Driver. This could create a hazardous environment for the operator and personnel around the machine. Performing any of the above will also result in the machine warranty being NULL and VOID.

Electrical Safety Features Of Rottler DM Controlled Machines

All Rottler machines that use the DM operational control system are designed to comply with all applicable safety standards. This includes but is not limited to the following systems:

Thermal sensors in all motors and motor controls.

1. Current sensors in all motor control panels.
2. Electrical breakers to prevent voltage surges and spikes from reaching electrical system.
3. Electrical lockout on main electrical enclosure.
4. E-Stop that shuts down all operational systems in an event of an emergency.

All thermal and current limits for motors and motor controls are preset at the factory. In the event that any of those parameters are exceeded during operation of the machine, the machine control system will shut down the machine and a warning of the specific fault will appear on the control screen.

CONTROL DEFINITIONS

Contents

Control Definitions	4-1
Computer and Controller System Safety for DM Controlled Machines.....	4-1
Master Power On/Off Switch	4-2
Initialization Screen:.....	4-3
General Information:	4-3
Home:	4-3
Program Select:	4-3
New:	4-4
Options:	4-4
Delete:	4-4
Mode Select:	4-5
New:	4-5
Std (Standard) Setup:.....	4-7
Options:.....	4-7
Delete:.....	4-7
Cylinder Bore, General Bore 3 Axis (without Tool Changer):.....	4-8
Set Zero Tab:	4-8
Actual Position:	4-8
Velocity Override:	4-8
Zero Buttons:	4-8
Handwheel Buttons:	4-8
Spindle Start:	4-8
CW and CCW Creep:	4-9
Jog Buttons:	4-9
Move to:	4-9
Move To Zeros:.....	4-9
CW and CCW Index:	4-9
Float:	4-9
Neutral:	4-9
Setting Spindle Index:	4-9

Vertical Stops Tab:	4-10
Left and Right Locations Tab:	4-11
Cylinder Bore – Bore Locations	4-11
Blueprint:	4-11
Move Buttons:	4-11
Bore Buttons:	4-12
Set Buttons:	4-12
Copy Values:	4-12
Difference:	4-12
Bore Left and Right:	4-12
Lifter Bore:	4-13
Table Of Tools:	4-13
Table Of Tools General Information:	4-13
Accessing Table Of Tools:	4-14
Add Tool:	4-15
Remove Tool:	4-16
Set Active Tool:	4-16
Setting Tool Offsets:	4-18
Z Location from Zero:	4-19
Z Touch Off Height:	4-19
Add Tool Radius?:	4-19
Applying Table of Tools to Rottler Programs:	4-20
Fixture Select:	4-20

Control Definitions

The purpose of this chapter is to define the function of the buttons throughout the various screens. Certain button functions may not make sense right away in this chapter. As the operator reads through the Operating Instructions chapter of this manual, the function of these buttons will become clear.

Computer and Controller System Safety for DM Controlled Machines

The computer and controller are located in the main rear electrical enclosure. This unit is a full computer, running Windows 7 64 Bit operating system. Contact the factory if more information on the computer system is required.

IMPORTANT: The computer in this machine has the ability to connect to the World Wide Web via Ethernet or Wireless using a USB wireless (Wi-Fi) adapter. Updating the Rottler software should ONLY be done when directed to do so by a Rottler service technician. Updating Rottler Software when not directed by Rottler personnel could result in a non-operational machine.

It is recommended that the machine be hooked up to the Internet anytime it is on. The software on the machine will automatically connect to our server to send back useful information on machine status. It will also record performance parameters that will be used to evaluate any occurrence of a malfunction.

The Auto Update for the Windows Firewall (Security) and Windows Defender (Anti-Virus) is turned on. The computer will automatically download the updates and then install them when the computer is shut down every Friday night.

Any "IT" personnel should ALWAYS get approval from Rottler before doing ANYTHING on the computer.



Downloading ANY program from the Internet or by other means when not directed by Rottler is prohibited and will result in the machine warranty being NULL and VOID.



Downloading any program or changing any Rottler or Computer settings may cause the machine and/or software to become unstable. DO NOT install ANY screen saver, Anti-Virus, Spyware or any type of Security software on the computer. This could create a hazardous environment for the operator and personnel around the machine. Performing any of the above will also result in the machine warranty being NULL and VOID.

Master Power On/Off Switch

This switch is located on the main electrical control enclosure on the right hand side of the machine. The switch must be in the off position before opening the rear enclosure door.

When first applying power to the machine the computer will need to boot up. Be patient, it will take several minutes to complete booting. The Rottler program will not automatically start. Double tap the Rottler_WPF icon on the screen to start Rottler.

When turning the main power to the machine off there is a specific procedure to follow so as not to damage the computer. The computer must shut down its internal systems before main power is removed from it.

Press the “Start” button in the left-hand side of the Start Bar. This will bring up the “Start Menu”. Press the “Shutdown” line at the bottom of the Start Menu. This will bring up a Pop Up menu, make sure that “shut down computer” is selected and press “OK”.

This will shut down the computer. It is now OK to turn Main Power off to the machine.

Initialization Screen:

When the F80DM is powered up the Rottler program will not automatically start. It may take several minutes for the computer to power. Start the Rottler program by double tapping the Rottler_WPF icon on the desktop. Once the program is started, the Rottler Program Select will appear.

NOTE: Do not push any buttons or icons on the screen before the Rottler program starts or an error may be caused on the computer.



General Information:

The Rottler software operates on a Block Model format. You select or create the block you are working with. Then select or create an operation to be performed on that block.

Home:


Pressing this button will cause the machine to move all axis to their home (Machine Origin) position. The vertical will home first to be sure it is clear to move the other axis. The machine **MUST** be homed after it is turned on. This is how the machine gets its reference points to operate.

Program Select:

This is the left section of the screen. This is where you create and select blocks you will be working with.

New:

Pressing this in the Upper level will cause a dialog box to appear. Here is where you name and configure the block i.e number of cylinders and Inline or V Block.



Pressing OK will result in the Block Model being inserted into the left hand side of the screen.

**Options:**

This will bring up the same dialog box as described above if any of the information needs to be changed.

Delete:

This will delete whatever block program is selected. A dialog box will appear to ask you if you want that program deleted.

Mode Select:

This is the right section of the screen. This is where you create or select operations to be performed on the selected Block. This area will be blank when you first create a block.

You can create only certain modes you will use on a block or use a standard set up that inserts all modes available. You can also create a new mode and rename if for a specific use.

New:

Pressing this button will bring up a dialog box with Rottler standard operations.



Select the operation you want to create and then press OK. This will place a general Bore operation under the Cylinder bore mode in the right hand section.



To enter General Bore mode highlight it and then press Select. This will take you to the operation screens that will be described later.

Std (Standard) Setup:

Pressing this button will insert all the Rottler operations into the right hand section automatically.



Use the slide bar on the right hand side to scroll through all the operations.

Options:

Press this button to bring up a dialog box to allow positive numbers to be entered in the horizontal stops. Most all programs are from left to right, the farther right you go the larger the negative number. However if a different zero point is used a positive number may be needed. For example, if you zero on the first cylinder on the left bank of a block and then "roll it over" the first cylinder is farther to the right than the zero position. Which would be a positive number.

Delete:


This will delete the selected Mode. It will ask you if you want this mode deleted before deleting it.

NOTE: Once the control definition for a particular button has been discussed it will not be repeated in the different modes of operation. Only new buttons or buttons with a different function will be discussed in different modes.

Cylinder Bore, General Bore 3 Axis (without Tool Changer):

Each buttons function will be described in this section. In the different MODES, the same buttons will not be described again.

Set Zero Tab:



Actual Position:

These are a numerical display showing the actual distance the axis are away from where they have been zeroed.

Velocity Override:

The Velocity override is displayed in the upper left of the Actual Position display. The default is 100% of the programmed Feed Rate. When operating... turning the handwheel Counter Clockwise will override the axis rapid travel and feed rate 100 and 0% when in an automatic cycle.

Zero Buttons:

These buttons will erase the actual position display of their associated axis and reset the displayed value to zero.

Handwheel Buttons:

These buttons will activate their associated axis for use with the handwheel. The left button of each axis will move the machine in .010" per detent, the middle button .010" per detent and the right .0001" per detent of the handwheel. Pressing any of the axis Jog buttons will disengage the handwheel.

Spindle Start:

This button will start the spindle at the RPM that is specified on the Auto Bore Cycle tab. Once the button has been pressed and the spindle is running the button will turn red and read Spindle Stop. Pressing the button again will stop the spindle and cause the button to go back to green.

CW and CCW Creep:

These buttons will cause the spindle to rotate slowly CW or CCW direction. The spindle will continue to rotate as long as the button is pressed. The speed at which the spindle will rotate is set in the Machine Parameters and should not be changed unless instructed to do so by the factory.

Jog Buttons:

These buttons control the rapid travel of the Vertical, Horizontal and In/Out axis. Pressing these buttons will allow you to move the machine through all ranges of its travel unobstructed. If the spindle is turned on these buttons become feed buttons and the machine will feed in whatever direction you have pressed. The rate at which the machine will feed is determined by the value set in the Auto Bore Cycle tab. When in rapid travel, these buttons are momentary contact and you will have to keep them pressed to keep the machine moving. When the spindle is on, they are latching buttons and once they are pressed the travel will continue until they are pressed again.

Move to:

Pressing these buttons will bring up a dialog box for the associated axis. Enter a value that you want the axis to move to and press ENTER. That axis will then move to that position. You can do multiple "Move To" at the same time. One after another.

Move To Zeros:

Pressing this button will cause the vertical to move the zero position first. The in/out and horizontal will move after the vertical has moved to zeros.

CW and CCW Index:

Pressing either of these buttons will cause the spindle to rotate to the index position. Index position is with the tool to the right as you are facing the machine.

Float:

This button operates in bore mode only. It unclamps the spindle base and floats it on a cushion of air. When the Float function is on, none of the powered machine movements operate except the handwheel. Press the FULL CLAMP to clamp the spindle base again.

Neutral:

This button operates in bore mode only. It unclamps the spindle base and partially floats it on a cushion of air. Use this function for precision positioning of the spindle on the In/Out axis. When the Neutral function is on, none of the powered machine movements operate except the handwheel. Press the bore button to clamp the spindle base again.

Important:**Setting Spindle Index:**

Any time the machine has been turned off the spindle index position must be set. Turn the spindle to the index position (tool holder facing to the right at 90 degrees from the operator). Then press the Zero button net to the spindle position read out. This will put a zero value in the display box.

This screen also shows the Spindle Load, programmed Feed Rate and Spindle RPM.


Vertical Stops Tab:

This screen is used to set the Vertical stops the machine will use to bore a cylinder. There are four Vertical stops used on this screen plus two optional Lower Clearance stops.

If the machine is equipped with a probe there are two (2) additional stops, Probe Clearance and Probe Height.

The function of the Vertical stops will be defined in the Operating Instructions chapter in this manual.

To enter any of the Vertical Stops press the Data box next to the Vertical stop you want to enter. A pop-up menu will appear. Press the desired numerical value and then press ENTER. The numerical data will then appear in the data box. You can also move the Vertical physically to the location you want the stop to be at and press the "SET" button next to the Data Box. This will take the current position from the Digital read out and insert it into the associated Data Box.




Left and Right Locations Tab:

This screen is used to set the Horizontal and In/Out stops the machine will use to bore a block. The number of In/Out and horizontal stop on this page will change with the block configuration i.e V6, V8 or inline.

The function of the Horizontal and In/Out stops will be defined in the Operating Instructions chapter of this manual.

To enter any of the Horizontal and In/Out stops press the Data box next to the Horizontal or In/Out stop you want to enter. A pop-up menu will appear. Press the desired numerical value and then press OK. The numerical data will then appear in the data box

Cylinder Bore – Bore Locations



There are three (3) different modes you can operate the machine in on these screens, Blueprint, Indicated and Probing.

Blueprint:

This mode of operation allows you to enter specific values for the bore locations from a blueprint type document.

It is helpful to have the blue print numbers entered on this screen even if you are not going to bore to the blueprint locations on a particular block. They help to set the general area of the bore if you are manually centering (indicating) or probing the block.

Move Buttons:

When pressed, these buttons will move the machine, under power, to the Horizontal and In/Out positions shown in the data boxes below the Move button. The Vertical will move to the Clearance height before it makes the Horizontal or In/Out moves. After it has moved to the Horizontal and In/Out positions the Vertical will move to the Centering Height. After this, all motion stops.

Bore Buttons:

Pressing this button once will cause it to turn yellow. This indicates when the “Bore Left” button is pressed this cylinder will not be bored.

Touching this button again (with a pause in between touches) will turn the button back to green. All green bores will be bored if the “Bore Left” button is pressed. The control will ask you if you sure you want to bore the selected bores.

Double Clicking a Bore button will keep it green and turn all other bore buttons yellow.

Set Buttons:

Once a cylinder has been indicate, pressing the associated Set Button will take the current machine position and place the values in the Data Box associated with that cylinder.

Copy Values:

Pressing this button will bring up another window where you can select to copy the In/Out and Horizontal values from Blueprint, Indicated or Probed screen.

Difference:

Checking this Box will cause a green check mark to be placed in the box. The Data Boxes will then display the difference in values from the blueprint screen to the indicated screen. This is helpful to know how far the cylinders actual location is from blueprint values.

Bore Left and Right:

Pressing this button will cause the entire Left or Right bank to be bored automatically. The Bore buttons that are yellow will not be bored though.

Lifter Bore:

The Lifter Bore Mode and its buttons operate identical to the Bore Mode with a couple of exceptions.

On the Program Vertical Stops screen, lower Clearance Offset is not an option.

After a bore is complete the spindle will not offset .020" for tool clearance unless the "Horizontal Offset after Cycle" box is checked. This is used when a single point boring tool is used for lifter boring.

Table Of Tools:

The Table Of Tools is a very powerful feature in this software. Most of the Rottler programs are designed to be used without interacting with the Table Of Tools.

Only the program specific uses will be described here.

Table Of Tools General Information:

The Table Of Tools is used to set different tool lengths so multiple tools can be used in one program and reference the same vertical zero position.

For Example, if you were to use two boring bars in one program. One boring bar is 8" long and the other is 4" long. There is then a 4" difference in where the cutter of each bar will come into contact with the part to be machined. Using the Table of Tools you can set the 4" difference for one of the boring bars so that both of the cutting tools will come into contact with the material at the same vertical position.

Accessing Table Of Tools:

Select TABLE OF TOOLS from any screen in the upper left hand corner. This will open up the Table Of Tools.

On this screen you will be able to Add, Remove or Set that tool Active (installed in spindle and being used).

Program Selected: Chevy 350 0.000 Vert 0.0000 In/Out 0.0000
 Mode Selected: Rough Through Bore 1.00 Horiz 0.0000 4th 0.00

Tool Number	Tool Name	TC Pocket	Tool Diameter	Tool Length	Type of Tool	Description
0	Default Tool		0.1250	0.0000	Flat End Mill	

PROGRAM SELECT
 FIXTURE SELECT
 TABLE OF TOOLS

LEFT RIGHT
 IN UP
 OUT DOWN
 CW CCW
 4th- 4th+

STOP MACHINE

Add Tool
 Remove Tool
 Set Active Tool


The Table of Tools comes with Tool 0 installed with no offset amount. Tool 0 will remain tool 0 with no offset always. Tool 0 will be set active when you are using programs that do not require tool offsets.

Add Tool:

To add a tool to the Table of Tools press Add Tool. This will open another window. Here you will name the Tool you are adding. Such as 2.9 production Stub. It is important to give an accurate name to the tool. You want the tool easily identifiable by its name. The only other data box the Rottler software uses is the Length Data Box. This will be discussed later. Press OK.



The Added tool will now show in the Table of Tools.




Remove Tool:

Pressing this button will remove the highlighted tool from the Table of Tools.

Set Active Tool:

Pressing this button will set the highlighted tool to an Active Status (tool installed and will be used) Any Vertical offset associated with that tool will be used when a program is run. You can tell which tool is active because it is highlighted in Red. When no offset is required in a program Tool 0, Default Tool should be active.

When setting a tool active another window will open. This is the Tool Change Form. It is basically there to verify the tool information before it is set to an active status. Verify the information and press OK.



This window will open when the machine does an automatic tool change. This will be discussed in Chapter 3 Operating Instructions. After you press OK another window will open. This is a Warning Dialog box to inform the operator of the possibility of the spindle start if the tool change is done in an automatic program. Press OK.



Setting Tool Offsets:

Add all the tools that will need offsets into the table of tools. Leave the Length value at 00.00 when you first enter them.


For this example we will be setting offsets for a 2.9 Production Stub, 100mm Probe and a 10 inch Fly cutter. Add these tools to the table of Tools.

NOTE: Only the Probe will use the Tool Diameter. The Probe will use the Tool Diameter when probing a cylinder, it will not use the Tool Diameter when touch off a surface such as a block deck. Changing this setting will be discussed in later in this Chapter.



To set Tool Offsets you will need a fixed vertical reference point on the machine that does not change such as the head stock of the 4th axis or Performance Fixture.

Install the first tool such as the 2.9 Production Stub with Cutting insert installed. Bring the cutting insert down until it just touches the flat on the head stock of the 4th axis fixture. Go to the TABLE OF TOOLS and double click the 2.9 Production Stub tool. Select Get Length from that window. This will bring up the Tool Length window.



Z Location from Zero:


This is the distance the Vertical Axis is from the home position. NOT where the operator has set the Vertical Zero in the program. This value is set by the computer automatically. In this example the tool just touched the flat at 8.0000.

Z Touch Off Height:

This value is an additional value you want added to the Z location from zero. For example, if you wanted to use the center of the Crankshaft as the vertical reference point, but you are touching the tool off of the flat of that head stock, you would enter the distance from where you are touching off to the center of the Crank (this value is stamped into the headstock by Rottler). The values from Z Location from Zero and Z Touch off Height are added together by the computer to get the Final tool Length value. If you are not referencing another vertical position then this value will remain 00.000.

Add Tool Radius?:

Checking this box will add the Tool Radius to the Final Tool Length. This is not used in the Rottler programs and should remain unchecked for all tools.



Repeat this procedure for each tool. Touch ALL of them off from the same point.

When running a Rottler program the cutting insert for each tool will reference the Vertical Zero the operator set in the program and come into contact with the surface to be machined at the same vertical value.

Applying Table of Tools to Rottler Programs:

The use of the Table of Tools to specific Rottler programs such as Bore and Mill will be defined in Chapter 3 Operating Instructions.

Fixture Select:

This is also a very powerful tool. It is not generally used in the Rottler Programs. It's basic function is to offset a program and table of tools a set distance on each axis (if desired) and run the same program without resetting axis zero points.

For example, if you have to fixtures that are identical but are set at a different location on the table you can set the difference values in the table of fixtures and run the program.

It is recommended this is not used unless you are a very experienced operator.

OPERATING INSTRUCTIONS

Contents

Operating Instructions	5-1
Loading Blocks	5-1
Small Gas and Diesel	5-1
Manual V6/V8 Combination Fixture 502-1-72H	5-1
Boring Application	5-1
Normal Operating Procedure	5-3
Surfacing Application	5-5
Normal Operating Procedure	5-7
Retrofitting 502-1-15C Parallels to V6/V8 Combination Fixture	5-8
Diesel Blocks	5-10
6725 Diesel Fixture	5-10
Small Diesel V Blocks	5-10
Triangle Clamping	5-11
Block Clamp Arm	5-11
Small Diesel In Line Blocks	5-13
Triangle Clamping	5-14
6405F Large V-Block	5-16
Triangle Clamping	5-17
6810 Waukesha 7042, 9390 and CAT 379, 398, 399 Block Line Bore Fixture	5-21
6821 Adjustable, Universal Line Bore Parallel Assembly	5-25
7119V Dual Axis Table Assembly	5-30
Instructions for Small In-Line Blocks	5-31
Mounting Block to Table	5-31
Blocks with Main Caps Removed or Raised Main Bearings	5-31
Blocks with Main Caps Installed	5-32
Typical Head Set Up Procedure	5-33
12" Multi Tooth Milling Head - 6865	5-36
18" Multi Tooth Milling Head 6864	5-36
General Machine Information	5-37

Homing	5-37
Building Programs	5-37
Create a Block Program	5-37
New	5-37
Options	5-38
Creating Operating Modes for a Block Model	5-38
New	5-39
Std (Standard) Setup	5-40
Select	5-40
Options	5-40
Cylinder Bore Mode 2 Axis:	5-41
Setting Zeros:	5-41
Horizontal:	5-41
Vertical Zero:	5-42
Blueprinting:	5-43
Programming Vertical Stops:	5-43
Block Clearance:	5-43
Centering Height:	5-44
Start Boring Height:	5-44
Bottom of the Bore:	5-44
Bore Locations:	5-45
Boring a Block:	5-47
Indicating:	5-47
Vertical Zero:	5-47
Programming Vertical Stops:	5-48
Block Clearance:	5-48
Centering Height:	5-49
Start Boring Height:	5-49
Bottom of the Bore:	5-50

Bore Locations:	5-51
Mill Mode 2 Axis:	5-52
Setting Zeros:	5-52
Horizontal Zero:	5-52
Vertical Zero:	5-52
Mill Operation:	5-54
End:	5-54
Horizontal End	5-54
Amount Per Pass:	5-54
Vertical Start:	5-54
Vertical End:	5-54
Copy Lowest Copy Highest:	5-54
Rough Settings:	5-55
Rough Feed Rate:	5-55
Rough Spindle RPM:	5-55
Finish Cut Settings:	5-55
Finish Amount:	5-55
Finish Feed Rate:	5-55
Finish RPM:	5-55
Start Auto Cycle:	5-55

Operating Instructions

The purpose of this chapter is to explain and then guide the operator from loading a block through running an automatic cycle.


All modes of operation will be discussed in this chapter.

Note: *We recommend, particularly for operators unfamiliar with the boring machine, to practice on a junk block in order to become familiar with the controls and procedures of the boring machine.*

Loading Blocks

Small Gas and Diesel

Manual V6/V8 Combination Fixture 502-1-72H

 Handle the block and fixture with EXTREME care and guidance. A block hoist is REQUIRED. Mishandling of a heavy engine block and fixture may result in the dropping of parts and personal injury.

The Model 502-1-72H manual V6/V8 combination fixture is a fast, simple and universal system to properly and accurately hold most 60 degree V-type engine blocks for either cylinder boring or deck surfacing.

See illustration on the following page.

Boring Application

NOTE: *The block must have the main bearing caps in place and torqued.*


Care must be taken to assure the contact edges of the locator bar are near the cap split line. A pair of 3/8" and 1/2" spacers are provided for blocks with large main bearing bores, to enable the bar to locate near the main bearing split line. (See figure 2)

V-blocks: (blocks with main bearing center lines no more than 1/2" higher than the pan rail plane) are mounted with the 502-3-8B V-block frame in place. Select the 90-degree option placement of the frame to suit block length, or main bearing caps will interfere with frame. Rotate frame 90 degrees by moving its shoulder screws to alternate set of holes.

Y-Blocks: (blocks with main bearing center lines 2-3/8" to 3-1/2" higher than the pan rail plane) are mounted directly on the fixture. Some Y-blocks (GM 60 degree) have too narrow pan rails and some have too low main bearing location which will require the use of the 502-1-15C precision 1-1/4" x 3" parallel set to raise and or support the block. Use the shoulder screw from the V-block frame and hook the parallels over the back of the V-fixture.

This fixture may be easily repositioned on the support parallels (without a block in place) to shift from the 60 degree support surface to the 90 degree support surface or vice versa.

⚠ WARNING Extreme care must be taken by operator whenever handling large blocks. Large blocks may cause fixture to tip when floated too far outward. We recommend leaving hoist attached when moving these blocks. Large blocks should be lifted from the block bank surface.






FIGURE 1

FIGURE 2

Normal Operating Procedure

The normal operation procedure on smaller V-blocks is to first pick up the block. Place the 502-1-82X locator bar through the main bearings and hoist the block into the fixture. Pulling the block towards you, with the locator against the positioners, will prevent jamming in the slot of the guides during the loading and unloading operations. The locator bar is positioned with the word 'UP' that is on the end of the bar facing up and away from the operator. (see figure 1) After the locator bar is engaged in the positioners, pivot block outwards as you lower it. Slide block to the far left (this is the non adjustable position).

Make sure the block is firmly seated in place and not resting on pan-rail burrs or other interference points. Accurate seating can also be a problem with extremely warped, distorted blocks. Another cause of problems is failure to remove main bearing inserts. The locator bar has a relief for blocks with a small main bearing or seal. Rotate locator bar clamps into position & lightly tighten the hand screws, applying even pressure to both. Clamp the block securely with the main base clamp arms.

Warped or distorted blocks may require leveling of the deck surface in the long direction. This is possible with the hand-screw assembly in the left-hand bar positioner. Loosen both clamp hand-screws and slide the locator bar to the far right position. Retighten both clamp hand-screws. Raise or lower the adjusting hand-screw as required. For the non-adjustable position slide locator bar to the far left.

Push fixture back into bore position. There is a guide block (502-1-105) attached to the bottom of the fixture to aid in guiding the fixture along the support ways.

Operate the block clamp arms, bore, and pull fixture back to the load position.

Loosen locator bar hand screws and rotate clamps out of the way. Lift the block, either from the deck surface or with the optional 502-1-95 block handler. Turn the block 180 degrees & reload to duplicate the operation on the other bank.

After turning the engine block 180 degrees the locator bar must be twisted 180 degrees also. Again the word 'UP' must enter into the positioners facing up and away from the operator. (See figure 1).

Figure 1

502-1-82X main bearing locator bar indexes at point A. When bank is reversed and the bar is twisted 180 degrees, point A still indexes the main bearing.

Point C holds the block down. When bank is reversed and the bar is twisted 180 degrees, point B holds the block down.

Figure 2

502-1-82X main bearing locator bar indexes near bearing split line. Point C does not contact the bearing cap but rests on matched spacers that are provided to fit in the bar positioners slot. If there is a means of holding the block down such as block clamp towers, this method may be used in large bores in order to properly index near the bearing split line. If extreme care is used this method may be used to index blocks without bearing caps attached. (Optional clamp down must be provided).

Surfacing Application

NOTE: The block must have the main bearing caps in place and torqued.

Care must be taken to assure the contact edges of the locator bar are near the cap split line. A pair of 3/8" and 1/2" spacers are provided for blocks with large main bearing bores, to enable the bar to locate near the main bearing split line. (See figure 2)

V-blocks:

(blocks with main bearing center lines no more than 1/2" higher than the pan rail plane) are mounted with the 502-3-8B V-block frame in place. Select the 90-degree option placement of the frame to suit block length, or main bearing caps will interfere with frame. Rotate frame 90 degrees by moving its shoulder screws to alternate set of holes.


Y-Blocks:

(blocks with main bearing center lines 2-3/8" to 3-1/2" higher than the pan rail plane) are mounted directly on the fixture. Some Y-blocks (GM 60 degree) have too narrow pan rails and some have too low main bearing location which will require the use of the 502-1-15C precision 1-1/4" x 3" parallel set to raise and or support the block. Use the shoulder screw from the V-block frame and hook the parallels over the back of the V-fixture.

This fixture may be easily repositioned on the support parallels (without a block in place) to shift from the 60 degree support surface to the 90 degree support surface or vice versa.

⚠ WARNING

Extreme care must be taken by operator whenever handling large blocks. Large blocks may cause fixture to tip when floated too far outward. We recommend leaving hoist attached when moving these blocks. Large blocks should be lifted from the block bank surface.



Normal Operating Procedure

The normal operation procedure on smaller V-blocks is to first pick up the block. Place the 502-1-82X locator bar through the main bearings and hoist the block into the fixture. Pulling the block towards you, with the locator against the positioners, will prevent jamming in the slot of the guides during the loading and unloading operations. The locator bar is positioned with the word 'UP' that is on the end of the bar facing up and away from the operator. (see figure 1) After the locator bar is engaged in the positioners, pivot block outwards as you lower it. Slide block to the far left (this is the non adjustable position).

Make sure the block is firmly seated in place and not resting on pan-rail burrs or other interference points. Accurate seating can also be a problem with extremely warped, distorted blocks. Another cause of problems is failure to remove main bearing inserts. The locator bar has a relief for blocks with a small main bearing or seal. Rotate locator bar clamps into position & lightly tighten the hand screws, applying even pressure to both. Clamp the block securely with the main base clamp arms.

Warped or distorted blocks may require leveling of the deck surface in the long direction. This is possible with the hand-screw assembly in the left-hand bar positioner. Loosen both clamp hand-screws and slide the locator bar to the far right position. Retighten both clamp hand-screws. Raise or lower the adjusting hand-screw as required. For the non-adjustable position slide locator bar to the far left.

Push fixture back into surfacing position with the back of the fixture on the Shim Stock. The shim stock is put in place to raise the back side of the block, you can then use the Jacking Screw to raise and lower the front of the block. There is a guide block (502-1-105) attached to the bottom of the fixture to aid in guiding the fixture along the support ways.

Operate the block clamp arms, surface, and pull fixture back to the load position.

Loosen locator bar hand screws and rotate clamps out of the way. Lift the block, either from the deck surface. Turn the block 180 degrees & reload to duplicate the operation on the other bank.

After turning the engine block 180 degrees the locator bar must be twisted 180 degrees also. Again the word 'UP' must enter into the positioners facing up and away from the operator. (See figure 1).

Figure 1

502-1-82X main bearing locator bar indexes at point A. When bank is reversed and the bar is twisted 180 degrees, point A still indexes the main bearing.

Point C holds the block down. When bank is reversed and the bar is twisted 180 degrees, point B holds the block down.

Figure 2


502-1-82X main bearing locator bar indexes near bearing split line. Point C does not contact the bearing cap but rests on matched spacers that are provided to fit in the bar positioners slot. If there is a means of holding the block down such as block clamp towers, this method may be used in large bores in order to properly index near the bearing split line. If extreme care is used this method may be used to index blocks without bearing caps attached. (Optional clamp down must be provided).

Retrofitting 502-1-15C Parallels to V6/V8 Combination Fixture


(Special Applications)

Some engine blocks with large main bores (3-1/8" and larger) cause a problem of the locator bar bottoming out in the bar positioners and/or the V-shaped relief's of the 502-3-8B V-block frame before clamping the block properly. Mounting the 502-1-15C parallel set as shown below in place of the V-block frame will provide proper clearance for clamping. Older style fixtures and parallels can be modified to this configuration using illustrations below.

V-6 blocks with one-piece 'caged' main bearing caps (all caps are connected) can interfere with 502-3-8B V-block frame. The parallel arrangement shown below will allow proper support and clamping of these blocks.



Some V-6 engine blocks (for example Buick V-6) have main bearing bores that are too low in respect to the pan rails. This presents a problem of the locator bar bottoming out in the bar positioners before the block is properly clamped. Positioning the 502-1-15C parallel set as shown below will raise the block enough to provide proper clamping.



Diesel Blocks

6725 Diesel Fixture

Small Diesel V Blocks

On these blocks it will be necessary to install the 6370Z, 10" parallels or 6794E, 8" parallels onto the bed of the machine. These parallels are keyed, place them onto the deck surface and then push them toward the rear of the machine. This will locate them evenly on the middle keyway of the machine bed. Place the two 6553F main bearing supports onto the parallels, these are also keyed and fit into the machined slots on the parallels. This will put the two main bearing supports in line with each other. Tighten all bolts to lock the parallels and main bearing support into place. Select the correct size main bearing locators and install them into the mains of the block..

Note: Make sure there are no burrs or debris in the main bearing bores where they will contact the main bearing locators. This can cause the block not to clamp properly and may cause tipping or rocking of the block.



Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks. These blocks should be lifted from the block bank surface.

Install the main bearing locators into the mains of the engine block. Lower the block so that the locators go into the main bearing support.




The hoist must remain attached to the block until it is firmly clamped into position. The blocks will have a tendency to tip forward until they are properly supported and clamp. When not properly supported and attached to a hoist these blocks will roll forward and out of the fixture. This will cause severe injury or death to operator.


Select the correct jacking screw to reach the block. Place the jacking screws into the jack bodies and place on the parallels in a location they will support the block from rolling forward.


Position the block clamps so the front of the shoe will clamp the block in the middle on both ends. The following illustration shows the correct triangle clamping system that should be used.

You can raise and lower the ends of the block by rotating the Hex nut located on the ends of the main bearing locators.

Triangle Clamping

Adjust the height so the shoes rest on the clamp points. Tighten the clamp leg handles. Actuate the clamp shoes by turning their knobs. Apply pressure to the two clamps as evenly as possible to avoid tipping the block up on one side.

Block Clamp Arm




Small Diesel In Line Blocks

On these blocks it will be necessary to install the 6370Z, 10" parallels onto the bed of the machine. These parallels are keyed, place them onto the deck surface and then push them toward the rear of the machine. This will locate them evenly on the middle keyway of the machine bed. Place the two 6553F main bearing supports onto the parallels, these are also keyed and fit into the machined slots on the parallels. Use the forward machined slots. This will put the two main bearing supports in line with each other, and on centerline of the machine bed.


Position the fixtures at a distance apart equal to the outboard main journals. Tighten all bolts to lock the parallels and main bearing support into place. Select the correct size main bearing locators, and install them into the mains of the block. Notice the locators have a flat area. Installing with the flat side up will allow end to end height adjustment of the block by rotating the locator. Installing with the round side up will position the block so all machining operations are parallel and perpendicular to the main bore centerline. This simply requires leveling the block in the front to rear direction.

Note: Make sure there are no burrs or debris in the main bearing bores where they will contact the main bearing locators. This can cause the block not to clamp properly and may cause tipping or rocking of the block.

 **WARNING** Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks. These blocks should be lifted from the block bank surface.


Lower the block so that the locators go into the main bearing support. A clevis pin is provided to keep the locator in position on the main bearing support.

For in-line blocks, load the block with the heavier side towards the front.

 **DANGER** The hoist must remain attached to the block until it is firmly clamped into position. The blocks will have a tendency to tip until they are properly supported and clamp. When not properly supported and attached to a hoist these blocks will roll forward or backwards and out of the fixture. This will cause severe injury or death to operator.

Select the correct jacking screws to reach the block. Place the jacking screws into the jack bodies and place on the machine bed in a location they will support the block from rolling forwards. Rough level the block using a spirit level.

The following illustration shows the correct triangle clamping system that should be used.


Triangle Clamping

Adjust the height so the shoes rest on the clamp points. Tighten the clamp leg handles. Actuate the clamp shoes by turning their knobs. Apply pressure to the two clamps as evenly as possible to avoid tipping the block up on one side.

Be sure the clamp is below the deck surface if you to resurface the block.



Do not release the hoist or lifting device from the block until the clamping is secure.



6405F Large V-Block

Place the 6405 supports on the machine bed. Make sure there is no debris or burrs on the mating surfaced. The supports should be placed on the machine bed with the two dowels on the bottom of the supports into the middle keyway. Place the supports the same distance apart as the mains you will be using. On long blocks, it is recommended to use main bearing locations inward from the ends, to more equally balance the block and avoid sag. Push the supports back toward the rear of the machine against the dowel pins. This will line the supports up with each other. Tighten the four (4) mounting bolts on each support.

Install the correct size locators into the main bores that will be used.



Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks. These blocks should be lifted from the block bank surface.




The hoist must remain attached to the block until it is firmly clamped into position. The blocks will have a tendency to tip until they are properly supported and clamp. When not properly supported and attached to a hoist these blocks will roll forward or backwards and out of the fixture. This will cause severe injury or death to operator.

The main bearing bores being used, should be on centerline of each support. Set the jacking bodies, with the proper length jack screw installed onto the machine base. These should be located in the general area of the supports. Temporarily secure to the deck with at least one bolt.


Lower the block down onto the supports. Place a level on the deck of the engine block and check the level front to back. Position the jack stands in a location to properly support the block and secure. To level, use the jacking screws to raise or lower the front of the engine block.


Position the block clamps on the machine bed and secure in a location to allow proper clamping.



The following illustration shows the correct triangle clamping system that should be used.

Triangle Clamping

Adjust the height so the shoes rest on the clamp points. Tighten the clamp leg handles. Actuate the clamp shoes by turning their knobs. Apply pressure to the two clamps as evenly as possible to avoid tipping the block up on one side.








6810 Waukesha 7042, 9390 and CAT 379, 398, 399 Block Line Bore Fixture


This fixture is designed to be mounted directly on the bed of an F100 Series machine. Due to the large size of the Waukesha 7042 block, care must be taken when loading and unloading to avoid bumping the block into the column or spindle unit.

⚠ WARNING Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks.


Use the diagram on the following pages when referring to part numbers listed below. This Line Bore fixture consists of a stationary cradle and an adjustable support. The Cradle (6811A) is mounted to the machine bed over the locating pivot key and pin assembly. The locating pivot pin (6819) is pressed into the locating pivot key (6820). This assembly is positioned in the center keyway of the machine bed and the (2) set screws (MF-72) are tightened to lock the key in place. The Cradle is positioned over the pin and mounted to the machine bed. With the mounting bolts installed but not tight this provides a standard pivot point for the Cradle.



The support (6812A) is assembled with the adjusting screw (6754V) and the adjusting block (6814). This assembly is mounted to the machine bed with the lower tab of the adjusting block in the center keyway. ***Be sure to install the special ratchet adjusting wrench prior to setting this assembly on the machine bed***




The adjustable tube (6813) is bolted to the Waukesha Block using the Cam Bearing Cap mounting holes. The adjustable tube has ten (10) holes drilled in it. Four (4) of the holes are used to bolt the adjustable tube to the engine block, the remaining six (6) holes are clearance for the cap alignment dowel pins in the engine block. Since the Cam Bearing Caps are not evenly spaced along the block, the adjustable tube must be mounted on the front end of the block as shown in the following illustration.



The upper and lower leveling pads, bracket and screw are already installed in the adjustable tube.

With the adjustable tube installed, the block is ready to be lowered into the Cradle and Support. Use caution to locate the adjustable tube correctly on the support. The two roll pins (MF-229B) installed in the lower leveling pad (6411) are designed to locate the leveling pads properly.



All mounting bolts should be loose to start with. Due to the design of this fixture the Cradle end of the block is stationary both in relationship to the machine bed key way and in height. This end is not adjustable. The adjustable end of the fixture is located on the same machine bed keyway as the cradle. Once the block is loaded into the fixture it is ready to be aligned for the line boring operation. Up and down adjustment is accomplished using the leveling screw (6408) inside the adjustable tube. The block is adjusted in and out by activating the air float on the support, and turning the adjustment screw using the previously installed ratchet wrench. Once the block is located in and out deactivate the air float and tighten the support end mounting bolt to lock into place. Tighten the three (3) mounting bolts on the Cradle end of the fixture now. The alignment of the block should be checked again at this time. Repeat alignment adjustments as needed.

6821 Adjustable, Universal Line Bore Parallel Assembly


This fixture is designed to be mounted directly on the bed of the F90 series machine.

Due to the large size of these blocks, care must be taken when loading and unloading to avoid bumping the block into the column or spindle unit.


WARNING Handle these large blocks with Extreme care and guidance. A block hoist is required when handling these blocks.

Use diagrams on the following pages when referring to part numbers listed below. This Line Bore fixture consists of a stationary parallel and an adjustable parallel used in conjunction with a cradle that fits the block to be machined.


Install the 6820 Pivot Key (with Pivot Pin already pressed in) into the center keyway on the right hand side of the F90 bed. Tighten the two MF-72 set screws down. This will hold the Pivot key in place while the parallel pivots on the Pivot Pin (6819). Place the parallel onto the pivot pin, install the mounting bolts and washers but do not tighten down.



Install the adjustable parallel onto the left hand side of the F90 machine bed with the In/Out adjusting block (6830) located in the front keyway. Install the mounting bolts and washers but do not tighten down.




Once both parallels are installed on the machine bed, place a magnetic indicator on the spindle towards the main bed. Indicate the adjustable parallel into the stationary parallel to within .002" on the In/Out and height. This lines the fixture up close so the block can be loaded and then use minor adjustments on the fixture to line the block up.



Select the set of V cradles for the block you are going to be machining. There are various types of cradles that can be used on this fixture. There are risers available also that can be mounted to the cradles to accommodate certain blocks. For cradle and riser selection refer to the Options section of this manual. The CAT 3500 series cradle is shown in this example.


Place the cradles on the parallel. Line up the horizontal key on the cradles with the key slot on the parallels. Generally, the rearward key slot is used, but on large blocks such as the CAT 3500, it is necessary to use the front key slot to allow clearance between the machine column, and engine block. Install mounting bolts and lock the cradles down. Due to the extreme weight of these blocks, clamping is usually not required. Threaded rods and clamp bars bridged across the cylinder bore, and threaded into the cradles is a way to secure the block if desired.

For in-line blocks, cradles are not used. In this case, round locators are bolted directly to the parallels. Lower the block with the end cylinders over the locators and push the block towards the front or rear. This will position the block in a straight line with the machine travel. Secure with threaded rods and clamp bars bridged across the cylinder bore, and threaded into the locators.




Lower the block slowly down into the cradles. Using a heavy soft mallet, tap the sides of the cradles to allow the block to settle into position. The block is now ready for alignment.

Up and down adjustment is accomplished by turning the screw on the side of the adjustable parallel. The in/out direction is adjusted by turning screw at the front of the adjustable parallel. Apply air pressure to the fixture while adjusting the in/out direction. Once the block is aligned, tighten down the fixture bolts and recheck alignment. Readjust as necessary.



7119V Dual Axis Table Assembly

REFBUL90-120197



Instructions for Small In-Line Blocks

The Dual Axis Table has the capability of holding small (less than 13 ½" from pan rail to head surface) in-line cylinder blocks for resurfacing. This will require the use of parts from the 7119P Universal Head Fixturing package.


Mounting Block to Table

There are two (2) methods for mounting blocks to the Table. Blocks with the main caps removed or with the raised main bearings can be mounted directly to the table surface. Block with the main bearing caps installed which are lower than the pan rail surface must be mounted using support blocks from the Universal Fixturing package.

Blocks with Main Caps Removed or Raised Main Bearings

Remove any burrs from pan rails of block.

Locate cone washers on table to approximately center block in path of cutter-head and 'hook' the edge of the pan rail in the rear. Clamp the block using clamp handle assembly. We suggest you install the stop rod assembly on the left hand end of the block. This is an added safety precaution.




Check that all bolts and hold downs are tight. Loosen table clamp and level head surface of block in both directions. Lock table clamp and recheck block for level.

Blocks with Main Caps Installed

Remove any burrs from pan rails of block.

Position rear supports and front supports to hold block approximately centered in path of cutter-head. Generally, place the front supports closer together than the rear supports.


Place the block on the supports. Reposition the supports if necessary to clear main caps. Etc. Elevate the cones to hook the pan rail in the rear. Tighten set screws to lock cones in place. Tighten the hex bolts on the supports. Adjust the support block jack to eliminate any rocking. Lightly apply the clamp handle assembly.




Loosen table clamp and level head surface of block in both directions. Lock table clamp. With the level still on the block tighten clamp handle assembly with appropriate clamp nose on the lower portion of a port or indent near the middle of the block. Tighten the clamp 1/8 to 1/4 turn after contacting the block. Do not over-tighten. Watch the level as you tighten to check for movement or warping. If the block moves or warps, repositioning the front supports inward will generally solve the problem. Check to see that the block cannot be moved in the fixture. We suggest that you install the stop rod assembly on the left hand end of the block. This is an added safety precaution.

Typical Head Set Up Procedure

Find the desired ports or bosses, in the head, to position cones (long or short) on rear support blocks.
 Measure the distance between the centerlines of these ports (bosses) within 1/16" (1mm – 5mm).
 Measure the distance from rear support points to front support points on the head.




Position rear support blocks and front support blocks to hold the head approximately centered on the table top and spaced apart per dimensions measured in step '1' above. Generally, place the front blocks closer together than the rear blocks. If necessary, use either 2 or 4 spacers to raise the head for clearing studs or to angle the head so the cutterhead clears the head clamp handle assembly.



Place the head on the support blocks. Elevate the cones to 'hook' the two ports (bosses) on the head and tighten their set-screws. Adjust the position of the front support blocks if necessary. Tighten the hex bolts on the support blocks. Push the head back firmly into the cones. Adjust the support block jack to eliminate any rocking of the head. Do not tighten the head clamp handle assembly yet.

Unlock the table. Using the two hand-wheels, level the head surface to be cut. Lock the table in this position.


REFSETUP3-092292




The head clamp handle assembly has a replaceable nose that pushes on the head. With the level still on the head surface, tighten the head clamp handle assembly on the lower edge of a port or indent near the middle of the head. Tighten the clamp 1/8 to 1/4 turn after contacting the head. Do not over tighten. Watch the level as you tighten to check for movement or warping. Some heads are very sensitive to support block placement, and the front support blocks may have to be moved slightly inward to prevent this warping. Check to see that the head cannot be moved in the fixture.

Slide the end stop block up against the left end of the head towards the rear. If possible, rotate the stop rod to contact a machined area on the end of the head. This will aid in loading a run of similar heads.

REFSETUP4-123192



Visually check for clearance between the cutterhead and head fixture tooling pieces, especially the head clamp handle, assembly. The head should be approximately centered in the path of the cutterhead.



12" Multi Tooth Milling Head - 6865

This milling head holds 14 insert cartridges. Each insert has 10 cutting edges, 5 on each side. The inserts need to be adjusted to be at equal height of each other to within .0004" (.01mm). To set the height of the inserts, install the milling head into the machine spindle. Install the inserts. Back off the small set screw above each tool cartridge. Loosen each tool cartridge, push up, and re-tighten.

Using an indicator with a large diameter convex tip, find the insert that is at the lowest setting. Now, adjust the remaining inserts to equal height by turning the small set screw above each tool cartridge.

There are a couple spindle motor parameters that need to be changed to gain more torque that this milling head requires.

Go to "Set up", then "General Options".

Find the line labeled "Spindle".

Find the column labeled "Position Gain", and change it to 10. (Record the original setting before changing)

Find the column labeled "Velocity Gain", and change it to 600. (Record the original setting before changing)

100 to 120 RPM and a feed rate of .020"(.05mm) to .040"(1mm) is recommended. Maximum depth of cut .020"(.05mm)

When finish with the machining operation, re-enter the original spindle motor settings as recorded earlier.

18" Multi Tooth Milling Head 6864

This milling head holds 9 insert cartridges. Each insert has 10 cutting edges, 5 on each side. The inserts need to be adjusted to be at equal height of each other to within .0004" (.01mm). To set the height of the inserts, install the milling head into the machine spindle. Install the inserts. Back off the small set screw above each tool cartridge. Loosen each tool cartridge, push up, and re-tighten.

Using an indicator with a large diameter convex tip, find the insert that is at the lowest setting. Now, adjust the remaining inserts to equal height by turning the small set screw above each tool cartridge. Install the dampener band around the perimeter of the milling head.

There are a couple spindle motor parameters that need to be changed to gain more torque that this milling head requires.

Go to "Set up", then "General Options".

Find the line labeled "Spindle".

Find the column labeled "Position Gain", and change it to 10. (Record the original setting before changing)

Find the column labeled "Velocity Gain", and change it to 600. (Record the original setting before changing)

Find the column labeled "Accel Rate", and change it to 2. (Record the original setting before changing)

70 to 90 RPM and a feed rate of .020"(.05mm) to .040"(1mm) is recommended. Limit the depth of cut to .001" (.025mm) to .002" (.05mm)

When finish with the machining operation, re-enter the original spindle motor settings as recorded earlier.

General Machine Information

Before starting to build or use any of the Rottler operating programs it is important to understand how the machine operates internally.

The Rottler F80DM model uses Computerized Numeric Control (CNC). The CNC is always operating when the machine is turned on. However, you will not see the CNC controls unless you switch over to the CNC operating screen.

Homing

The F80DM MUST be homed anytime it is turned off. If the machine has not been homed the reference positions for all programs will be off.

The purpose of Homing the machine is to set reference points in each axis for the machine to operate from. If the machine is not homed the reference points may be off position. The reference point is set in exactly the same position each time the machine is homed. The machine keeps track of these reference positions internally and the operator will not see them.

Building Programs

NOTE: The instructions in this section are done WITHOUT using tool or Fixture offset values.

Create a Block Program

Block Programs are listed on the left hand side of the screen. Mode programs that are for a specific Block Model are listed on the right side of the screen.

New

From the Program Select screen select New from the Left hand menu. This will open a window where will enter the Block name and configuration i.e. V6, V8 or Inline and number of cylinders.

NOTE: There is an existing program on start-up of new software called Part Program. This can be deleted after the first Block Program is entered.



Options


If you need to change the block configuration or name of a block that has already been created, use the Options button. This will bring up the same window as when the block was created.

Creating Operating Modes for a Block Model

Select the Block model on the left hand side of the screen.

New

Selecting New will bring up a window that lists all the Modes that can be performed on the selected block model. Highlight the Mode you want to create and press OK.



The selected mode will show up on the right hand side of the screen.



Std (Standard) Setup


Pressing Std Setup will cause all of the available Modes to be inserted into the Modes area on the right hand side.

Select

Pressing Select with a Mode highlighted will open the operations screens for using the program.

Options

Pressing the Options button with a Mode highlighted will open a window where you can change the mode name. There is also a check box to allow positive number to be entered into the program where they are normally forced to a negative value.



Cylinder Bore Mode 2 Axis:

Select Cylinder Bore and then Rough Through Bore on the screen. This will bring up the boring program with the Set Zeros tab shown.

NOTE: Once a certain feature is discussed in a particular mode it will not be discussed again in the following modes.




Setting Zeros:

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis (except the Spindle rotation) will need to have a zero point set for the machine to operate from. Every program will save its individual zero positions. The next time that program is selected the zero position will be the exact same distance from the Home position for each axis.

Horizontal:


For this example, the Dowel Pin will be our zero point for the Horizontal. Using an indicator center the spindle on the Dowel Pin then press the Horizontal button. The display next to this button will go to zero. The Horizontal position has now been set.



Vertical Zero:

There are three different ways to use the boring software, Blueprinting, Indicating and Probing. It is not unusual for all three modes to be used on the same size block. The vertical stops for these different operating programs will vary. Be sure the vertical stops are set correctly for the mode you are using.

For this example the deck will be our zero for the Vertical axis. Insert a tool holder into the cutterhead you will be using to bore the block. Center the cutterhead over a cylinder. Using the Vertical Handwheel, bring the cutterhead down until the tool just touches the deck and press the Vertical Zero button. The display next to this button will go to zero. The Vertical zero has now been set.




The zeros points for all axis have now been set. All the numbers entered from this point on will reference these zero positions. You are finished with the Set Zeros screen, select the next Tab to the Right, Vertical Stops.

Blueprinting:

Even if you are not going to be boring a block to the blue print specifications it is recommended to have the Blueprint values entered. It will speed up the process of indicating and probing a block by giving the operator a close estimate of bore location.


Programming Vertical Stops:

To build a program you must set the Vertical Stops for the program.



Block Clearance:

This is the distance above the zero position or block deck allowing the cutterhead to move to the next bore unobstructed. If you are Blueprinting a block the number will be just enough to allow the cutterhead to clear the block deck.




Centering Height:

When Blueprinting this stop is not needed. It should be the same as the block Clearance Height.

Start Boring Height:

This is the distance above zero or the block deck where you want the cutterhead to start rotating and the downward feed to start. Generally this is just a short distance above the block deck to minimize the amount of time the machine bores through air.



Bottom of the Bore:

This is the distance below zero or the Block deck where you want the machine to stop boring and retract out of the cylinder. When the spindle retracts it will then go to the Block Clearance position.

This is an example of what the above program would look like on the vertical stops.

Program: Part Program	Continuous DTG	0.000	Z	0.0000	Y	0.0000
Mode: Cylinder Bore	Feedrate override	1.00	X	0.0000	4th	0.000

Set Zeros	Vertical Stops	Left Locations	Right Locations
BORE PROFILE		DWELL OPTIONS	
Block Clearance	0.0000 SET	Finish RPMS	60.00
Centering Height	0.0000 SET	Finish Revolutions	2.00
<input checked="" type="checkbox"/> Engage Auto Centering			
Start Boring Height	0.0000 SET		
Bottom of Bore	-1.0000 SET		

PROGRAM SELECT


X- X+ Z+ Z- CW CCW

Stop Machine

When Blueprinting the Probe is not used. It will be discussed later in this Chapter.

Bore Locations:

To build a program you must set the Horizontal Stop for the program. All Horizontal stops are based from where their zero positions were set. The following illustration shows how the stop positions were derived. These stops would be used when blueprinting a block.



The following is an example of what the screens would look like for the above block.

Left Locations:



Right Locations:



The Horizontal and In/Out stops have now been set.

Boring a Block:

Once the Vertical, Horizontal and In/Out stops have all been entered the Spindle RPM and Feed Rate need to be entered. This is done on the Set Zeros screen. Once this is done you can go to the Left and/ or Right Bore location screens and bore the cylinders.

Pressing the Bore Left for Bore Right buttons Will Bore all the cylinders that have Green bore button below them.

Pressing a Bore button once will turn that button Yellow. Any Yellow button will not be bored when the Bore Left or Right button is pressed.

Double clicking any Bore button will turn all the Bore button yellow EXCEPT the one that was double click.


Indicating:

Even if you are not going to be boring a block to the blue print specifications it is recommended to have these values entered. It will speed up the process of indicating and probing a block by giving the operator a close estimate of bore location.

Vertical Zero:

There are three different ways to use the boring software, Blueprinting, Indicating and Probing. It is not unusual for all three modes to be used on the same size block. The vertical stops for these different operating programs will vary. Be sure the vertical stops are set correctly for the mode you are using.


For this example the deck will be our zero for the Vertical axis. Insert a tool holder into the cutterhead you will be using to bore the block. Center the cutterhead over a cylinder. Using the Vertical Handwheel, bring the cutterhead down until the tool just touches the deck and press the Vertical Zero button. The display above this button will go to zero. The Vertical zero has now been set.



The zeros points for all axis have now been set. All the numbers entered from this point on will reference these zero positions. You are finished with the Set Zeros screen, select the next Tab to the Right.


Programming Vertical Stops:

To build a program you must set the Vertical Stops for the program.




Block Clearance:

This is the distance above the zero position or block deck allowing the cutterhead to move to the next bore unobstructed. When you are indicating the cylinders in you must have this stop set so the indicator will clear the block surface when traveling to the next cylinder.




Centering Height:

This is a distance above the vertical zero where you will be manually centering the block. The drawing below is a typical set up for manual centering or indicating a cylinder.

**Start Boring Height:**

This is the distance above zero or the block deck where you want the cutterhead to start rotating and the downward feed to start. Generally this is just a short distance above the block deck to minimize the amount of time the machine bores through air. This will be a negative number.



Bottom of the Bore:

This is the distance below zero or the Block deck where you want the machine to stop boring and retract out of the cylinder. When the spindle retracts it will then go to the block Clearance position.

This is an example of what the above program would look like on the vertical stops.

Program: Part Program Continuous DTG: 0.000 Z 0.0000 Y 0.0000

Mode: Cylinder Bore Feedrate override: 1.00 X 0.0000 4th 0.000

PROGRAM SELECT

X- X+

Z+

Z-

CW CCW

Stop Machine

Vertical Stops

BORE PROFILE

Block Clearance 0.0000 SET

Centering Height 0.0000 SET

Engage Auto Centering

Start Boring Height 0.0000 SET

Bottom of Bore -1.0000 SET

DWELL OPTIONS

Finish RPMS 60.00


Finish Revolutions 2.00

The Vertical stops have now been set. You are finished with the Vertical Stops screen, select Left and/or Right Locations.

Bore Locations:

To build a program you must set the Horizontal and In/Out Stops for the program. There are eight (8) Horizontal and In/Out stops used in the boring program. All Horizontal and In/Out stop are based from where their zero positions were set.

Select Left Locations and the Blueprint. Program the blueprint values (or close approximation) into the Horizontal and In/Out stops. Do the same for the Right Locations.



Select Left Locations and then Indicated. If you have programmed the blueprint locations into this program then press Copy Values and then Blueprint. This will cause the values from the Blueprint page to be copied into the Indicated page. This give you a starting point to indicate the individual cylinder from.

Press the Move 1 button. The machine will move to the first cylinder and stop at the centering position. Manually indicate the cylinder in using the Horizontal and In/Out handwheel. Once the cylinder is centered press the Set 1 button. This will transfer the current position of the machine into the first set of Data Boxes. Repeat this process for all the cylinders that need to be indicated.

Press the Right Locations tab and repeat the above procedure for the cylinders to be indicated on the right bank.

Mill Mode 2 Axis:

Setting Zeros:

The purpose of setting zero points is to give the operator a specific point to build programs from. The machine also uses these zero points to run the program from. The zero points can be set at any point in the machines' travel. Each axis will need to have a zero point set for the machine to operate from.




Horizontal Zero:

For this example we are going to set the Horizontal Zero approximately $\frac{1}{4}$ " from the right hand side of the work piece.

Vertical Zero:

For this example the Vertical Zero will be at the deck height of the work piece.



Set the Spindle RPM and Feed rate on this screen.

Start the spindle. Press the Vert .001 button to put the handwheel in .001 per detent. Slowly move the spindle downward until you can hear or see the cutter just touch the block. Press your Vertical Zero button here. Press the Right travel button to feed the spindle off of the work piece. When the cutter has cleared the work piece press the Right travel button again to stop the feeding. Press the Horizontal Zero here.

Your zero position for all axis have now been set.

Mill Operation:

This screen is used to set certain parameters the F80DM will use to run the automatic cycle.

Program: Part Program	Continuous DTG	0.000	Z	0.0000	Y	0.0000
Mode: Mill Cycle	Feedrate override	1.00	X	0.0000	4th	0.000

Set Zeros

End

Horizontal End: -10.0000 [SET]

Amount per Pass: 0.0040

Vertical Start: 0.0000 [Copy Highest]

Vertical End: -0.0100 [Copy Lowest]

Additional Depth: 0.0000

Operation

Rough Settings

Rough Feed Rate: 0.0030

Rough Spindle RPM: 600.0000

Finish Cut Settings

Finish Amount: 0.0020

Finish Feed Rate: 0.0020

Finish Spindle RPM: 400.0000

PROGRAM SELECT

X- X+

Z+ Z-

CW CCW

Stop Machine

TURN WEDGE ON START AUTO CYCLE

End:

Horizontal End

This displays the current end stop value. To enter a new value press the display and a pop-up numerical key pad will appear. Press the desired end stop value and then ENTER. This is the distance from where the Horizontal Zero was set. You can move the fly cutter manually to the end of the cut and press the SET button. This will automatically put the Horizontal End value in for you.

Amount Per Pass:

This is the amount of material removed from the work piece on each pass of the cutterhead.

Vertical Start:

This is the Vertical Position the machine will start cutting at. This value is usually Zero which is usually the starting Deck Height.

Vertical End:

This is the Vertical Position the machine will stop cutting at. It is the Total amount of amterial you want to remove in the Milling process.

Copy Lowest Copy Highest:

These buttons will be discussed in the Mill Probing section of this Chapter.

Rough Settings:

These values are used when taking multiple passes on a work piece. These values can be set high to remove material quickly. The finish on the work piece does not matter in these settings. There will be a Final pass that will apply the finish to the work piece.

Rough Feed Rate:

Enter the desired Roughing Feed Rate;

Rough Spindle RPM:

Enter the Desired Roughing Spindle RPM.

Finish Cut Settings:

These values will be used for the last pass the machine will make on the work piece. These will determine the finish left on the work piece.

Finish Amount:

Enter the amount to be removed on the last pass.

Finish Feed Rate:

Enter the desired Finish Feed Rate.

Finish RPM:

Enter the desired Finish Spindle RPM.

NOTE: You do not need to have evenly divisible numbers in these sections. The computer will do the math to remove the correct amount each time and for the final pass to be at the amount you set.

Program: Part Program	Continuous DTG	0.000	Z	0.0000	Y	0.0000
Mode: Mill Cycle	Feedrate override	1.00	X	0.0000	4th	0.000

Set Zeros	Operation
PROGRAM SELECT	End
X-	Horizontal End -10.0000 <input type="button" value="SET"/>
X+	Amount per Pass 0.0040
Z+	Vertical Start 0.0000 <input type="button" value="Copy Highest"/>
Z-	Vertical End -0.0100 <input type="button" value="Copy Lowest"/>
CW	Additional Depth 0.0000
CCW	

Rough Settings	
Rough Feed Rate	0.0030
Rough Spindle RPM	600.0000

Finish Cut Settings	
Finish Amount	0.0020
Finish Feed Rate	0.0020
Finish Spindle RPM	400.0000

<input type="button" value="Stop Machine"/>	<input type="button" value="TURN WEDGE ON"/>	<input type="button" value="START AUTO CYCLE"/>
---------------------------------------------	----------------------------------------------	-------------------------------------------------

Start Auto Cycle:

Pressing this button will start the machines automatic cycle. The cycle to be run is determined by the setting on this page. If you only require one pass to be made, do not enter any values into the Rough Setting, only the Finish Cut Settings.

MAINTENANCE

Contents

Quick Reference Lubrication Chart: F80DM	6-1
Quick Reference Preventative Maintenance Chart: F80DM.....	6-1
Grease Cross Reference Chart	6-2
Maintenance.....	6-6
Lubrication	6-6
Outer Spindle	6-6
Upper Belt Housing	6-6
Oil Reservoir System	6-7
Inner Spindle Bearings	6-7
Vertical Ballscrew Bearings.....	6-7
Lubrication Locations	6-8
Right Angle Drive Lubrication Information	6-10
Air Line Diagram.....	6-11
F80DM Wiring Diagram	6-12
Outer Spindle Bushing Adjustment.....	6-13
Upper Bushing Adjustment.....	6-14
Spindle Sweep	6-15
Horizontal Gibs	6-16
Adjusting Y-Axis Gibs	6-18
Adjustment Procedure	6-19
Spindle Belt Adjustment	6-20
Top and Side Rail Adjustment	6-21
Mill Tilt Adjustment Procedure.....	6-22
Checking Wear on Column Turcite Pads.....	6-24
Digital Micrometer setting instructions.....	6-26
To set or edit micrometer	6-27

Quick Reference Lubrication Chart: F80DM

Refer to the maintenance section in the manual for lubrication location points and instruction.

Assembly	Frequency	Lube Operation	Recommended Lubricant	Date Serviced
Outer Spindle	8 Hours	Wipe with oil	ISO VG 68 Way Oil	
	1000 Hours	Soak felt wiper with oil		
Oil Reservoir System	8 Hours	Check upper oil lines are full	ISO VG 68 Way Oil	
	175 Hours	Fill reservoir with oil if needed		
Upper Vertical Ballscrew Pillow Block Bearing	175 Hours	Grease	NLGI 2 White Lithium Grease	
Lower Vertical Ballscrew Bearing Pack	175 Hours	Grease	NLGI 2 White Lithium Grease	
Rear Y Axis Bearing Housing Grease Fitting	175 Hours	Grease	NLGI 2 White Lithium Grease	
Column Feed Gear Housing	1000 Hours	Fill with oil	GL-5 or MT-1 80W-90 Gear Oil	

Quick Reference Preventative Maintenance Chart: F80DM

Refer to the procedures in the maintenance section of the manual to make or check these adjustments. Not all of the items listed in the table below have adjustment. The information should be recorded and the amount of wear tracked so the part can be replaced before down time on the machine occurs.

Procedure	Frequency	Date Serviced/Comments
Spindle Sweep Adjustment	150 Hours	
Outer Spindle Bushing Adjustment	500 Hours	
Spindle Tilt Measurement	500 Hours	
Inner Spindle Bearing Adjustment	1000 Hours	
Horizontal Gib(s) Adjustment	1000 Hours	
X,Y,Z Auto Mode Backlash Adjustment	1000 Hours	
X,Y,Z Handwheel Backlash Adjustment	1000 Hours	
Electrical Enclosure Air Filter Replacement	1000 Hours	
Machine Level Adjustment	1000 Hours	
Spindle Drive Belt Adjustment	1000 Hours	
Vertical Drive Belt Adjustment	1000 Hours	
Horizontal Ballscrew Inspection	2000 Hours	
Spindle Wear Measurement	2000 Hours	
Horizontal Way Wear Measurement	2000 Hours	

Grease Cross Reference Chart

ISO AND UNII SYMBOLS	APPLICATION FIELD	Agip	api	ARAL	ARCO	barelli	bellini	BERGOLINE	BP	BRYTOL INDUSTRIAL OILS	Castrol	Chevron
AN 68	LUBRIFICAT. LOSS	RADULA 68 ACER 68	API MF-68	ARAL DURAL MR 68	GASCON 68	MIN 68	TRAMMISSION 68	ACCA 68	CS 68	CM 68	MAGNA 68	CIRCULATING OIL 68 GST OIL 68
CB 32	GEARS	ACER 32	API MF-32 API CIS-32	ARAL DURAL MR46 ARAL VITAM GF 32	RUBILENE 32	NITAO 32	SPRINTER AS 32	BERGOLUID 32 PARATER S 32	ENERGOL CS 32	CMC 32	MAGNA 32 PERFECTO T32	CIRCULATING OIL 46 GST OIL 46
CB 68	MODERATELY CHARGED	ACER 68	API MF-68 API CIS-68	ARAL DURAL MR 68 ARAL VITAM GF 68	RUBILENE 68	NITAO 68	SPRINTER AS 68	BERGOLUID 68 PARATER S 68	ENERGOL CS 32	CMC 68	MAGNA 68 PERFECTO T68	CIRCULATING OIL 68 GST OIL 68
CB 150		ACER 150	API MF-150 API CIS-150	ARAL DURAL MR 150 ARAL DEGOL TU 150	RUBILENE 150	NITAO 150	SPRINTER AS 150	BERGOLUID 150 PARATER S 150	ENERGOL CS 150	CMC 150	MAGNA 150	CIRCULATING OIL 150 GST OIL 150
CC 150	GEARS VERY CHARGED	BLASIA 150	API DT-150	ARAL DEGOL BG 150	PENNANT NL 150	G.E.P. 150	RED R14 150	BERGOFLEP EP150	ENERGOL GR-XP 150	DENTOL EP 150	ALPHA SP 150	NL GEAR COMPOUND 150
CC 320		BLASIA 320	API DT-320	ARAL DEGOL BG 320	PENNANT NL 320	G.E.P. 320	RED R14 320	BERGOFLEP EP320	ENERGOL GR-XP 320	DENTOL EP 320	ALPHA SP 320	NL GEAR COMPOUND 320
CC 460		BLASIA 460	API DT-460	ARAL DEGOL BG 460	PENNANT NL 460	G.E.P. 460	RED R14 460	BERGOFLEP EP460	ENERGOL GR-XP 460	DENTOL EP 460	ALPHA SP 460	NL GEAR COMPOUND 460
FD 5	SPINDLES, BEARINGS AND COUPLED CLUTCHES	OSO 10		ARAL DURAL SR 5	DURO OIL 10	VELOS A 10	SPRINTER ADPV5	BERGOSPIN 5	ENERGOL HP 5	AROS 5	MAGNA AB 5	MECHANISMLPS 15
FD 10		OSO 10	API CIS-10	ARAL DURAL SR 10	DURO OIL 10	VELOS A 10	SPRINTER ADPV10	ENERGOL 10	ENERGOL HP 10	MOVIL 10	HYSPIN AWS 10	
FD 22		OSO 15	API CIS-32	ARAL DURAL SR 22	DURO OIL 22	TIAIRO 22	SPRINTER ADPV22	BERGOSPIN 22	ENERGOL HLP-Z 22	MOVIL 22	HYSPIN AWS 22	
G 32		EXIDIA 32	API MX-32	ARAL DURAL SR 32	TRUSLIDE 32	TIAIRO BK 32	WAY 32	ENGINE K 32	ENERGOL GHL 32	VAITAK 32 AS 32	MAGNA CG 32	VISTAC OIL 32X
G 68		EXIDIA 68	API MX-68	ARAL DEGANIT B 68	TRUSLIDE 68	M.P. 68	WAY 68	ENGINE K 68	MACCOURAT 68 ENERGOL GHL 68	VAITAK 68 AS 68	MAGNA BD 68 MAGNA BDX 68	VISTAC OIL 68X
G 220		EXIDIA 220	API MX-220	ARAL DEGANIT B 220	TRUSLIDE 220	M.P. 220	WAY 220	ENGINE K 220	MACCOURAT 220 ENERGOL GHL 220	VAITAK 220 AS 220	MAGNA CF 220 MAGNA CFX 220	VISTAC OIL 220X
HM 32		OSO 32	API CIS-32	ARAL VITAM GF 32	DURO OIL AW 32	TIAIRO 32	SPRINTER ADPV 32	PARATER S 32 PARAVIS HLP 32	ENERGOL HLP-Z 32 HYDRO D 32	AROS 32 HYDRO D 32	HYSPIN AWS 32	MECHANISMLPS 32
HM 46	HYDROSTATIC SYSTEMS	OSO 46	API CIS-46	ARAL VITAM GF 46	DURO OIL AW 46	TIAIRO 46	SPRINTER ADPV 46	PARATER S 46 PARAVIS HLP 46	ENERGOL HLP-Z 46 HYDRO D 46	AROS 46 HYDRO D 46	HYSPIN AWS 46	MECHANISMLPS 46
HM 68		OSO 68	API CIS-68	ARALVITAM GF68	DURO OIL AW 68	TIAIRO 68	SPRINTER ADPV 68	PARATER S 68 PARAVIS HLP 68	ENERGOL HLP-Z 68 HYDRO D 68	AROS 68 HYDRO D 68	HYSPIN AWS 68	MECHANISMLPS 68
HG 32	HYDRAULIC SYSTEMS AND GUIDES	EXIDIA 32	API CIS-32 EP	ARAL DEGANIT B 68	TRUSLIDE OGF	TIAIRO BK 32	WAY SI 32 WAYCUT N 32	ENGINE K 32	ENERGOL GHL 32	VAITAK OGF	MAGNA GC 32	VISTAC OIL 32X
HG 68		EXIDIA 68	API CIS-68 EP	ARAL DEGANIT B 68	TRUSLIDE 68	TIAIRO BK 68	WAY SI 68 WAYCUT N 68	ENGINE HY 68	ENERGOL GHL 68	VAITAK 68	MAGNA AX 68	
G 32		GR MU EP 1	API GREASE FGX-1	ARAL ARALUB HL 1	LITHOLINE HEPR.1	LITIO EP 1	GREASE LI EP 1	RULTEN 900 EP 1	GREASE LTX1 GREASE LTX1-EP	BRYGREASE LT 1 BRYGREASE LT1EP	SPHEEROL APT 1 SPHEEROL EPL 1	DURALITH GREASE EP 1
G 68	MULTI FUNCTIONING GREASES	GR MU EP 2	API GREASE LT-S API GREASE FGX-2	ARAL ARALUB HL 2	LITHOLINE HEPR.2	LITIO EP 2	GREASE LI EP 2	RULTEN 900 N2 EP 2	GREASE LTX2 GREASE LTX2-EP	BRYGREASE LT 2 BRYGREASE LT2EP	SPHEEROL APT 2 SPHEEROL EPL 2	DURALITH GREASE EP 2
G 220		GR MU EP 3	API GREASE CR-S API GREASE FGX-3	ARAL ARALUB LF 3	LITHOLINE HEPR.3	PILMIT 3	GREASE LI EP 3	RULTEN 900 N. 3	GREASE LTX3	BRYGREASE LT 3 BRYGREASE LT3EP	SPHEEROL APT 3 SPHEEROL EPL 3	DURALITH GREASE EP 3

ISO AND UNI SYMBOLS	APPLICATION FIELD											
AN 68	LUBRIFICAT. LOSS	LG AN 68	MOVIXA 68	NURAY 68	EPAL 68	ARIAN 68	RENOLIN 68	BEARING 68	IP ARILLA OIL 68	CRUCOLAN 68	BETA 52/68	INDUSTRIAL 68
CB 32	GEARS MODERATELY CHARGED	OLEOL HM CB 32	POLYTELIS 32	TERESSO 32 NUTO 32	BRIGHT 32	SOLNA 32	RENOLIN 32	FILETE V 32 PRIESTAN 32	IP HERMEA OIL 32 IP HYDRUS OIL 32	CRUCOLAN 32	BETA 30/32	OLNEO 32
CB 68		OLEOL RH CB 68	POLYTELIS 68	TERESSO 68 NUTO 68	BRIGHT 68	SOLNA 68	RENOLIN 68	FILETE V 68 PRIESTAN 68	IP HERMEA OIL 68 IP HYDRUS OIL 68	CRUCOLAN 68	BETA 52/68	OLNEO 68
CB 150		OLEOL HH CB 150	POLYTELIS 150	NUTO 150	BRIGHT 150	SOLNA 150	RENOLIN 150	RENOLIN 150	FILETE V 150 PRIESTAN 150	IP HERMEA OIL 150 IP HYDRUS OIL 150	CRUCOLAN 150	BETA 120/150
CC 150	GEARS VERY CHARGED	OLGEAR EP CC 150	REDUCTELF SP 150	SPARTAN EP 150	ELTON EP 150	GIRAN 150	RENEPCOMFOND 104	RILEN EP 150	IP MELLANA OIL 150	LAMORA 150	DELTA EP 118/150	DACTA EP 150
CC 320		OLGEAR EP CC 320	REDUCTELF SP 320	SPARTAN EP 320	ELTON EP 320	GIRAN 320	RENEPCOMFOND 108 RENEP SUPER 6	RILEN EP 320	IP MELLANA OIL 320	LAMORA 320	DELTA EP 230/320	DACTA EP 320
CC 460		OLGEAR EP CC 460	REDUCTELF SP 460	SPARTAN FP 460	ELTON EP 460	GIRAN 460	RENEPCOMFOND 110 RENEP SUPER 10	RILEN EP 460	IP MELLANA OIL 460	LAMORA 460	LAMORA 460	DELTA EP 320/460
FD 5	SPINDLES BEARINGS AND COUPLED CLUTCHES	OLEOL HM FD 5	SPINELF 5	NUTO H 5	NEDEL 5	HYDRAN 10	RENOLIN MR 1	FILETE V 5	IP HYDRUS OIL 05	CRUCOLAN 5	VELOX 13/05	OLEODIN 5 OLNEO HLP 5
FD 10		OLEOL HM FD 10	SPINELF 10	SPINESSO 10	NEDEL 10	HYDRAN 10	RENOLIN MR 3	FILETE V 10	IP HYDRUS OIL 10	CRUCOLAN 10	VELOX 15/10	OLEODIN 10 OLNEO HLP 10
FD 22		OLEOL HM FD 22	SPINELF 22	SPINESSO 22	NEDEL 22	HYDRAN 22	HYDRAN 22	RENOLIN MR 5	FILETE V 22	IP HYDRUS OIL 22	CRUCOLAN 22	VELOX 20/15
G 32	GUIDES	WAY LUBE EP G 32	MOGLIA 32	FEBIS K 32	ARIF T 32	HYDRAN G 32	RENOLIN 1	NOOROP V 32	IP BANTIA OIL HG 32	LAMORA SUPER POLADD 32	ALPHA 29/32	SLEDOL 32
G 68		WAY LUBE EP G 68	MOGLIA 68	FEBIS K 68	ARIF T 68	HYDRAN G 68	RENOLIN 2	NOOROP V 68	IP BANTIA OIL HG 32	LAMORA SUPER POLADD 68	ALPHA 52/68	SLEDOL 68
G 220		WAY LUBE EP G 220	MOGLIA 220	FEBIS K 220	ARIF T 220	HYDRAN G 220	RENOLIN 5	NOOROP V 220	IP BANTIA OIL G.220	LAMORA SUPER POLADD 220	ALPHA 150/220	SLEDOL 220
HM 32	HYDROSTATIC SYSTEMS	OLEOL HM 32	ELFOLNA 32	NUTO H 32	HYDER 32	HYDRAN 32	RENOLIN B 32	FILETE V 32	IP HYDRUS OIL 32	LAMORA 32	HYDROLUBE 30/32	OLEODIN 32 OLNEO HLP 32
HM 46		OLEOL HM 46	ELFOLNA 46	NUTO H 46	HYDER 46	HYDRAN 46	RENOLIN B 46	FILETE V 46	IP HYDRUS OIL 46	LAMORA 46	HYDROLUBE 40/46	OLEODIN 46 OLNEO HLP 46
HM 68		OLEOL HM 68	ELFOLNA 68	NUTO H 68	HYDER 68	HYDER 68	RENOLIN B 68	FILETE V 68	IP HYDRUS OIL 46 IP HYDRUS OIL 68	LAMORA 68	HYDROLUBE 52/68	OLEODIN 68 OLNEO HLP 68
HG 32	HYDRAULIC SYSTEMS AND GUIDES	OLEOL HG 32	HYGLISS 32	FEBIS K 32	TERCAL 32	HYDRAN G 32	RENOLIN 1	FILETE VE 32	IP BANTIA OIL HG 32	LAMORA 32	HYDROLUBE EP 30/32	SLEDOL GC 32
HG 68		OLEOL HG 68	HYGLISS 68	FEBIS K 68	TERCAL 68	HYDRAN G 68	RENOLIN 3	FILETE VE 68	IP BANTIA OIL HG 68	LAMORA 68	HYDROLUBE EP 50/68	SLEDOL GC 68
G 32	MULTI FUNCTIONING GREASES	LHITGREASE XM 1	ROLEXA 1 EPEXA 1	BEACON EP 1	LITNER EP 1	MARSON EPL 1	RENOLIT 1	VEGA 1	IP ATHESIA GR 1 IP ATHESIA GREP 1	CENTOPLEX 1 EP	LITGREASE EP 1	ROLLER EP 1
G 68		LHITGREASE XM 2	ROLEXA 2 EPEXA 2	BEACON 2 ESSO GP GREASE	LITNER EP 2	MARSON EPL 2	RENOLIT 2 RENOLIT FEP 2	VEGA 2	IP ATHESIA GR 2 IP ATHESIA GREP 2	CENTOPLEX 2 EP	LITGREASE EP 2	ROLLER EP 2
G 220		LHITGREASE XM 3	ROLEXA 3	BEACON 3	LITNER EP 3	MARSON EPL 3	RENOLIT 3 RENOLIT FEP 3	VEGA 3	IP ATHESIA GR 3	CENTOPLEX 3 EP	LITGREASE EP 3	ROLLER EP 3

ISO AND UNI SYMBOLS	APPLICATION FIELD	Shell	Mobil	Elf	Persian Oil	REPOL	Q8	REINACH	ROLOIL	Shell	SAF-DIE	SPRINGOIL
AN 68	LUBRIFCATION LOSS	MILPAR 68	RUBREX 400	TECNOL 68	CASTOR 68	VERDI 68	VERDI 68	OLIO VER 15	LEMANIA 68	VITREA OIL 68	SINLUBE 68	MURAX 68
CB 32	GEARS	TURBO 32	MOBIL VACTRA OIL LIGHT	VITROL 32	REGULUS 32	VERDI 32	VERDI 32	OLIO EHT 13	ARM 32-V	VITREA OIL 32	SINLUBE GR 32	ENGINE SPECIAL 32
CB 68	MODERATELY CHARGED	TURBO 68	MOBIL VACTRA OIL MEDIUM	VITROL 68	REGULUS 68	VERDI 68	VERDI 68	OLIO EHT 15	ARM 68-V	TELLUS OIL C32	SINLUBE GR 68	ENGINE SPECIAL 68
CB 150		TURBO 150	MOBIL VACTRA OIL EXTRA HEAVY	VITROL 150	REGULUS 150	VERDI 150	VERDI 150	OLIO BMS/SC/NA/120	ARM 150-V	TELLUS OIL C68	SINLUBE GR 150	ENGINE SPECIAL 150
CC 150	GEARS	ROTO EP 150	MOBIL GEAR 629	REDOL EP 150	TAURUS WRP 150	GOYA 150	GOYA 150	OLIO ERPOL EP 150	EP 150	OMALLA OIL 150	SINLUBE GRIS 150	GEAR 150/EP
CC 320	GEARS VERY CHARGED	ROTO EP 320	MOBIL GEAR 632	REDOL EP 320	TAURUS WRP 320	GOYA 320	GOYA 320	OLIO ERPOL EP 320	EP 320	OMALLA OIL 230	SINLUBE GRIS 320	GEAR 320/EP
CC 460		ROTO EP 460	MOBIL GEAR 634	REDOL EP 460	TAURUS WRP 460	GOYA 460	GOYA 460	OLIO ERPOL EP 460	EP 460	OMALLA OIL 460	SINLUBE GRIS 460	GEAR 460/EP
FD 5	SPINDLES, BEARINGS AND COUPLED CLUTCHES	VELOX 5	MOBIL VELOCITE OIL No. 4	IDROL 10	ORION 5	PUCONI 4P	PUCONI 4P	OLIO EHT 10	TELLUS OIL C5	TELLUS OIL C5	SINLUBE 5	FUSING HD 10
FD 10		VELOX 10	MOBIL VELOCITE OIL DTE 21	IDROL 10	ORION 10	HAYDN 10	HAYDN 10	OLIO EHT 10	LR 10	TELLUS OIL C10	SINLUBE 10	FUSING HD 10
FD 22		VELOX 22	MOBIL VELOCITE OIL DTE 22	IDROL 22	SIRIUS H 22	HAYDN 22	HAYDN 22	OLIO EHT 12	LR 22	TELLUS OIL C22	SINLUBE 22	FUSING HD 22
G 32		LUBEX K 32	MOBIL VOLUME 145	AROL S 32	GEMINI CS 32	WAGNER 32	WAGNER 32	OLIO TRAX 13	TONNA OIL T 32	TONNA OIL T 32	SINLUBE SL 32	SLIDE 32/K
G 68		LUBEX K 68	MOBIL VACTRA OIL No. 2	AROL S 68	GEMINI SW 68	WAGNER 68	WAGNER 68	OLIO TRAX 15	TONNA OIL T 68	TONNA OIL T 68	SINLUBE SL 68	SLIDE 68/K
G 220		LUBEX K 220	MOBIL VACTRA OIL No. 4	AROL S 220	GEMINI SW 220	WAGNER 220	WAGNER 220	OLIO ANTIGIOCCIA 1450	TONNA OIL T 220	TONNA OIL T 220	SINLUBE SL 220	SLIDE 220/K
HM 32		MOVO H 32	MOBIL DTE 24	IDROL 32	SIRIUS H 32	HAYDN 32	HAYDN 32	OLIO EHT 13 H	LI 32	TELLUS OIL 32	SINHYDRO 32	ENGINE SPECIAL 32
HM 46	HYDROSTATIC SYSTEMS	MOVO H 46	MOBIL DTE 25	IDROL 46	SIRIUS H 46	HAYDN 46	HAYDN 46	OLIO EHT 14 H	LI 46	HYDRAULIC OIL 32	SINHYDRO 46	ENGINE SPECIAL 46
HM 68		MOVO H 68	MOBIL DTE 28	IDROL 68	SIRIUS H 68	HAYDN 68	HAYDN 68	OLIO EHT 15 H	LI 68	TELLUS OIL 46	SINHYDRO 68	ENGINE SPECIAL 68
HG 32	HYDRAULIC SYSTEMS AND GUIDES	LUBEX K 32	MOBIL VAQUOLINE OIL 1405	AROL S 22	GEMINI CS 32	WAGNER 32	WAGNER 32	OLIO DYN 32	LI 32-EP	TELLUS OIL 68	SINLUBE SL 32	SLIDE 32/K
HG 68		LUBEX K 68	MOBIL VAQUOLINE OIL 1409	AROL S 32	GEMINI CS 68	WAGNER 68	WAGNER 68	OLIO DYN 68	LI 68-EP	TONNA OIL T 32	SINLUBE SL 68	SLIDE 68/K
G 32		LITEK EP 1	MOBILPLEX 46	LT GREASE 1	LIBRA GREASE 1	REMBRANDT EP 1	REMBRANDT EP 1	GRASSO SFERULLF	LITEK EP 1	TONNA OIL T 32	GEP 1	UNIVERSAL EP1
G 68	MULTI FUNCTIONING GREASES	LITEK EP 2	MOBILPLEX 47	LT GREASE 2	LIBRA GREASE 2	REMBRANDT EP 2	REMBRANDT EP 2	GRASSO SFERULLIC	LITEK EP 2	TONNA OIL T 68	GEP 2	UNIVERSAL EP2
G 220		LITEK EP 3	MOBILPLEX 48	LT GREASE 3	LIBRA GREASE 3	REMBRANDT EP 3	REMBRANDT EP 3	GRASSO SFERULLD	MERCURY 3	TONNA OIL T 68	GEP 3	SERVICE/2
					LIBRA GREASE EP3							SERVICE/3

ISO AND UNI SYMBOLS	APPLICATION FIELD	SYNTECO	TAMOIL	TEMNEX	STAR	TOTAL	Vabrilol	VALVOLINE	Vanguard	VASCO	WEBER	WZADOL
AN 68	LUBRICATION LOSS	HYDRAULIC N 68	TAMLUBE OIL 68	VERTEX 68	OMNIS 68 ALCALD OIL 60	CORTIS 68	METIX 68	CIR 68	KOMOL ST 68	SIGNAL TR 68 (5)	WEBER WESCOM 68	ENGINE 68
CB 32	GEARS MODERATELY CHARGED	PACEMAKER R003	INDUSTRIAL OIL 32	CONTEX 32	OMNIS 32 RANCO OIL HD 32	CORTIS 32 AZOLLA ZS 32	METRA 32	CIR 32	KOMOL ST 32	SIGNAL M.U. EP 32 (3)	WEBER VA 32	ENGINE RE 32
CB 68		PACEMAKER R005	INDUSTRIAL OIL 68	CONTEX 68	OMNIS 68 RANCO OIL HD 68	CORTIS 68 AZOLLA ZS 68	METRA 68	CIR 68	KOMOL ST 68	SIGNAL M.U. EP 68 (5)	WEBER VA 68	ENGINE RE 68
CB 150		PACEMAKER R0012	INDUSTRIAL OIL 150	CONTEX 150	OMNIS 150 RANCO OIL HD 150	CORTIS 150 AZOLLA ZS 150	METRA 150	CIR 150	KOMOL ST 150	SIGNAL M.U. EP 150 (10)	WEBER VA 150	ENGINE RE 150
CC 150	GEARS VERY CHARGED	PACEMAKER R0012	CHITEREP LUBR 150	FACTOR 150	MEROPA 150	CARTER EP 150	GEARLUBE EP 150	GEAR EP 150	GEARING EP 150	SIGNAL M.U. EP 150 (10)	WEBER FARGO EP 150	ENGINE E P 150
CC 320		PACEMAKER R0024	CHITEREP LUBR 320	FACTOR 320	MEROPA 320	CARTER EP 320	GEARLUBE EP 320	GEAR EP 320	GEARING EP 320	SIGNAL M.U. EP 320 (22)	WEBER FARGO EP 320	ENGINE E P 320
CC 460		PACEMAKER R0032	CHITEREP LUBR 460	FACTOR 460	FACTOR 460	MEROPA 460	CARTER EP 460	GEARLUBE EP 460	GEAR EP 460	GEARING EP 460	SIGNAL M.U. EP 460 (37)	WEBER FARGO EP 460
FD 5	SPINDLES, BEARINGS AND COUPLED CLUTCHES			ECTON 5	300 OIL 5		RINOL 5	ETC 5	KOMOL SVR 5	SIGNAL ELUROS 5 (12)	WEBER W.L. 10	ENGINE HY SY 05B
FD 10			TAMSPINDLE OIL 10	ECTON 10	SPRINTEX OIL 10	AZOLLA ZS 15	RINOL 10	ETC 10	KOMOL SVR 10	SIGNAL CO 10 (1)	WEBER W.L. 15	ENGINE HY SY 10B
FD 22			TAMSPINDLE OIL 22	ECTON 22	ECTON 22	SPRINTEX OIL 22	AZOLLA ZS 15	RINOL 22	ETC 22	KOMOL SVR 22	SIGNAL CO 22 (2)	WEBER W.L. 22
G 32	GUIDES	PACEMAKER R003	TAMWAY OIL 32	BARTON 11		DROSER A MS 32	METRA K 32	GES 32	C.O. SPECIAL 32	SIGNAL VUJU 32 (3)	WEBER WAY 32	ENGINE HD T 02
G 68		PACEMAKER 55	TAMWAY OIL 68	BARTON 20	WAY LUBRICANT 68	DROSER A MS 68	METRA K 68	GES 68	STOL 68	SIGNAL M.V.S.G 68 (5)	WEBER WAY 68	ENGINE HD T 08
G 220		PACEMAKER 80	TAMWAY OIL 220	BARTON 44	WAY LUBRICANT 220	DROSER A MS 220	METRA K 220	GES 220	STOL 220	SIGNAL M.V.S.G 220 (12)	WEBER WAY 220	ENGINE HD T 20
HM 32	HYDROSTATIC SYSTEMS	PACEMAKER 32	HYDRAULIC OIL 32	ECTON X 32	RANCO OIL HD 32	AZOLLA ZS 32	GAMMA X 32	HYDRAULIC H.P 32	HYDRAULIC 32	SIGNAL CO 32 (3)	WEBER WL 32	ENGINE HY SY 32B
HM 46		PACEMAKER 46	HYDRAULIC OIL 46	ECTON X 46	RANCO OIL HD 46	AZOLLA ZS 46	GAMMA X 46	HYDRAULIC H.P 46	HYDRAULIC 46	SIGNAL CO 46 (4)	WEBER WL 46	ENGINE HY SY 46B
HM 68		PACEMAKER 68	HYDRAULIC OIL 68	ECTON X 68	RANCO OIL HD 68	AZOLLA ZS 68	GAMMA X 68	HYDRAULIC H.P 68	HYDRAULIC 68	SIGNAL CO 68 (5)	WEBER WL 68	ENGINE HY SY 68B
HG 32	HYDRAULIC SYSTEMS AND GUIDES	PACEMAKER R003	TAMWAY OIL 32	BARTON 11	CLEARTEX D RANCO OIL HD 32	DROSER A MS 32	METRA X 32	GES 32	C.O. SPECIAL 32	SIGNAL VUJU 32 (3)	WEBER WESSTOCK 32	ENGINE HOT 32/A
HG 68		PACEMAKER 55	TAMWAY OIL 68	BARTON 18	CLEARTEX F RANCO OIL HD 68	DROSER A MS 68	METRA X 68	GES 68	C.O. SPECIAL 68	SIGNAL VUJU 68 (5)	WEBER WESSTOCK 68	ENGINE HOT 68/A
G 32	MULTI FUNCTIONING GREASES	SINT GREASE EP 1	TAMUTHGREASE 1EP	GRASSO C-1 SPECK GRASSO MR 100	MULTIFAK EP 1 MAIFAK 1	MULTIS EP 1 MULTIS 1	CSMPA 1 GREASE CSEEP 1 GREASE	L 1 EP GREASE	LIKO 1 LIKO EP 1	SIGNAL ROLSPER EP 1	WEBER GREASE MP 1	GOLD 200 F1 GOLD 200 EP 1
G 68		SINT GREASE EP 2	TAMUTHGREASE 2	GRASSO C-2 SPECK GRASSO MR 100	MULTIFAK EP 2 MULTIFAK MP 2	MULTIS EP 2 MULTIS 2	CSMPA 2 GREASE CSEEP 2 GREASE	L 2 EP GREASE	LIKO 2 LIKO EP 2	SIGNAL ROLSPER EP 2	WEBER GREASE MP 2	GOLD 200 F2 GOLD 200 EP 2
G 220		SINT GREASE EP 3	TAMUTHGREASE 3	GRASSO C-3 SPECK GRASSO MR 100	MULTIFAK HD 3 MAIFAK HD 3	MULTIS EP 3 MULTIS 3	CSMPA 3 GREASE CSEEP 3 GREASE	L 3 EP GREASE	LIKO 3 LIKO EP 3	SIGNAL ROLSPER EP 3	WEBER GREASE MP 3	GOLD 200 F3 GOLD 200 EP 3

Maintenance

Lubrication

Refer to images following these written instructions:

Below are the directions that explain how and where to add oil to the different systems:

CAUTION Do not overfill any of the lubrication points, serious electrical damage may result.

Outer Spindle

The Outer Spindle is hard chromed and is supported in tapered, cast iron spindle bushings. The Outer Spindle supports the Inner Spindle, bearings, seals etc... and maintains the boring rigidity.


Every 8 hours:

The Outer Spindle needs to be moved down to the lower limit, wiped clean, and then lightly coated with a ISO VG 68 Way Oil. This is very important, if the spindle is allowed to operate dirty the cast iron dust will act as an abrasive on the spindle chrome. This will cause the spindle to wear prematurely. The outer spindle is a very expensive item to replace.

Every 1000 Hours:

Open the sheet metal cover from the front of the spindle unit. There is a large nut where the outer spindle passes through the top of the spindle base. Using a spanner wrench or punch carefully remove the upper nut.

Note: *Do not adjust the nut below the felt wiper (see the mechanical section for correct adjustment of this nut).*



Slide the felt wiper back into place and tighten the Upper Nut back down.

Upper Belt Housing

No lubrication is necessary in the Upper Belt Housing.

Oil Reservoir System

Every 8 hours check the oil supply lines to the upper spindle to be sure they are full of oil.

IMPORTANT

The oil reservoir system is located inside the lower portion of the column. This system lubricates the following:

- Ways
- Inner Spindle Bearings (Upper and Lower)
- Horizontal Ballscrew
- Outer Spindle

Every 175 Hours:

The oil level of the reservoir should be checked, and filled with **ISO VG 68 WAY OIL**.

When the oil reservoir is low or empty on the F80DM machine, the control will “LOW OIL” and will not run until the reservoir has been filled.

The oil system may require priming if the reservoir has been run empty. You can do this manually or automatically. To prime automatically, change the oiler machine parameter #123 to a value of 10. This will turn the oiler solenoid on every ten seconds as long as the spindle is running. Take note when the oil lines are full, reset the oiler parameter and operate the machine normally. To prime manually, open the air door on the lower left hand side of the column, locate the blue solenoid, press the manual override button on the solenoid repeatedly until the oil lines are full. You need to pause for a second between button presses to allow the valve to reset. Pressing the button too fast will not pump oil through the system.

Inner Spindle Bearings

The Inner Spindle Bearings are lubricated from the oil reservoir system. It is normal for a small amount of this oil to seep through the spindle bearings and onto the cutterhead.


Vertical Ballscrew Bearings

The Upper Pillow Block bearing is located on the top plate just below the driven sprocket. The lower bearing set is located at the bottom of the ballscrew in the spindle base.



Every 175 Hours:

These bearings should be greased with NLGI 2 White Lithium Grease.

Lubrication Locations



Lubrication Locations cont:




Right Angle Drive Lubrication Information

All right angle drives require lubrication at the point where the pinion drive intersects with the drive gear. This is generally in the area where the cutterhead is attached, except for the units that have belt drive. There will be a small pipe plug that is removed to check oil level and add oil if needed. See illustration below for general locations.

With the drive mounted on the machine spindle the oil level should be even with the bottom of the pipe plug threads.

All Rottler Right Angle Drives are filled with Union 76 Turbine Oil 68 prior to shipment. Use this or an equivalent ISO VG68 oil if the need to add or change oil arises.

When adding oil, fill until oil starts to run out of fill hole. Allow excess oil to drain, then coat pipe plug threads with anti-seize compound and replace it.



Air Line Diagram

Image Currently Unavailable

F80DM Wiring Diagram

Image Currently Unavailable

Outer Spindle Bushing Adjustment

The Lower Spindle Bushing will be adjusted in this demonstration.


1. Start the Rottler Software.
2. Move the spindle to its full downward position.



Retainer – O-Ring and felt are underneath

3. Loosen the four 10-24 bolts in the Retainer and pull out the O-Ring and Felt.
4. Loosen set screw at top of Bushing Carrier.
5. Take a punch and tighten Lower Bushing Nut with palm of hand. Raise spindle 5” and repeat. This helps set the bushing in the bushing carrier.

(WARNING: Do not tighten Spindle bushing retaining nut when spindle is at the top 3” of travel. Excessive wear and premature failure could result.)



6. Once the Retaining Nut will not tighten any more, a couple soft taps with a punch and a hammer to tighten it is all that is necessary to finish procedure.
7. Re-Install Felt, O-Ring, then Retainer in that order. Tighten down (4) 10-24 bolts.
8. Tighten Set Screw in Bushing Carrier.

Upper Bushing Adjustment

9. Repeat steps 3 and 4.
10. Take a punch and tighten Lower Bushing Nut with palm of hand. This time Lower spindle 5" and repeat.

(WARNING: Do not tighten Spindle bushing retaining nut when spindle is at the top 3" of travel. Excessive wear and premature failure could result.)

Once the Retaining Nut will not tighten any more, a couple soft taps with a punch and a hammer to tighten it is all that is necessary to finish procedure.

Re-Install Felt, O-Ring, then Retainer in that order. Tighten down (4) 10-24 bolts.

Tighten Set Screw in Bushing Carrier.

Note: It is recommended to sweep in your spindle after this maintenance procedure.

Spindle Sweep

The outer spindle must be swept into the main bed of the machine to achieve accurate bores.

Remove all fixturing from the machine bed, clean and stone if needed.

Install a boring cutterhead into the machine.

Install the sweep are into the cutterhead.

Bring the machine down until you have about .005" pressure on the indicator.

CAUTION Disconnect all power and air to the machine before continuing, severe bodily injury may occur.


Turn the sweep arm to the 9 O'clock position. Zero the indicator here.

Loosen the 6 socket head cap screws on the lower spindle hub. You do not want them all the way loose, just snug.

Use the three (3) set screws in the spindle base to move the spindle until the indicator reads within .0005" with a full 360 degree sweep of the indicator.


Note: *You do not want the right hand side of the spindle to be more positive than the left, it will interfere with the automatic tilt of the machine when in Mill mode.*

Once the spindle is swept in tighten the six (6) socket head cap screws and double check that the sweep did not move.



Horizontal Gibs

The Horizontal gibs are located under the main column, on the back side of the front way. These gibs keep the column from “cocking” when the direction of travel is changed. This adjustment becomes more critical when line boring. If the gibs are too loose the column will turn slightly side ways when traveling. This will cause the alignment of the right angle drive to be off. The cutterhead will then cut heavier on one side of the bore.



To adjust:

Loosen the Gib bolts (two on each side)

Loosen the Lock Nut on the set screw.

Tighten the set screw as much as possible using only the correct size Allen Wrench. This will pull the Front Way bearing up against the front way while pressing the Gib up against the back of the Front Way.

Loosen the Set Screw.

Tighten the set screw up until you can feel it contact the Gib.


Lock the Lock nut.

Run the machine back and forth to let the gibs adjust to adjust in.

Tighten the Gib bolts. Torque to 5 ft. lbs. or 60 in. lbs.

If the machine will not travel full speed or the handwheel movement is erratic the gibs may be too tight. Re-adjust leaving the Set Screw a little bit looser than the previous adjustment.

Another way to check for correct adjustment is to attach a magnetic base dial indicator (.0001 resolution) to the column with the indicator tip contacting the machine way surface.



Now using the handwheel in .010" per click mode, move the column back and forth, about two turns on the handwheel in each direction at a rapid rate.


Note the amount of movement on the dial indicator.

The acceptable amount of movement on the dial indicator is between .0002"-.0005".


Adjust as necessary. This procedure must be performed at both, the right, and left, sides of the column.

Adjusting Y-Axis Gibs

The Y-Axis adjusting gibs are located at the top of the machine column that the spindle base is mounted on. There are gibs located on the top and side rails on the left side of the column. Two are located on the top rail and two are located on the side rail.



On the right side of the column there are gibs located on the top rail.



Adjustment Procedure

1. On the left side rail loosen the jam nuts.
2. Tighten the set screws until they bottom out and can't be turned further.
3. Loosen each set screw 1/8 turn.
4. Tighten jam nuts.
5. On both top rails loosen jam nuts.
6. Tighten the set screws until they bottom out and can't be turned further.
7. Loosen each set screw 3/4 turn.
8. Tighten jam nuts.

Spindle Belt Adjustment

The spindle belt should not require adjustment very often, but if required use the following instructions.


Open the Spindle Base shroud.

Loosen the four Motor mounting bolts on the spindle motor.

Tighten or loosen the Tension adjustment bolt on the rear of the belt housing until 5 pounds of pressure causes the spindle belt to deflect 1/4".

If the spindle motor is run at high speed and a high pitched whining is heard from the belt housing area the belt adjustment is probably too tight.

If you can visually see the belt jumping around while running the belt is too loose.



Top and Side Rail Adjustment

1. Loosen jam nuts on side rail adjustment screws
2. Tighten adjustment screws until they bottom out
3. Back adjustment screws out 1/8 of a turn
4. Tighten jam nuts



5. Loosen jam nuts on top rail adjustment screws
6. Tighten adjustment screws until they bottom out
7. Back adjustment screws out 3/4 of a turn
8. Tighten jam nuts



Mill Tilt Adjustment Procedure

1. Position the Y axis in the middle of its travel. Using a 5/32" hex key, loosen the locking set screw through the access hole in the right side guide rail



2. Put the machine in "Mill Cycle" mode, with the wedge turned off. Attach an indicator as shown in the following photo, and set to zero position.




3. Using a 3/16" hex key, turn the adjustment screw in or out to increase, or decrease, the amount of mill tilt. Turn the screw CCW to increase, or turn CW to decrease the amount as shown in the photo at step #2. After each adjustment, turn the "Wedge On", to check the amount. Set to .002" - .004" (.05mm - .1mm) of lift with the wedge turned on. Turn the wedge off to readjust, and then turn the wedge on to check the amount.
4. When finished, tighten the locking set screw as shown in the photo in step #1.
5. Repeat the procedure for the rear wedge.




6. After adjusting the rear wedge, re-check the front, to make sure it did not change.

Checking Wear on Column Turcite Pads


Remove bolts holding way covers to column.



Slide way covers away from column to gain access to column way.
Remove wipers from Turcite pads.



Measure height of Turcite pads using either feeler gauge or dial indicator method.



Pads will have to be replaced or shimmed if height difference between the 4 pads exceeds .005".

Digital Micrometer setting instructions


Turn the thimble until the '0' line on the thimble lines up with the vertical line nearest the spindle lock ring.



Determine which cutter head bore range the micrometer is going to be used on. (example; 2.9 – 6.0)
We want to initially set the micrometer to the minimum bore diameter of this cutterhead.

NOTE: MICROMETER CAN NOT BE PROGRAMMED IF THE LETTERS INC APPEAR IN THE DISPLAY. To get rid of INC, quickly press the in/mm/ABS button.



To set or edit micrometer

Press and hold the set/on button and the + or – button at the same time. “Set” will flash in the display. This places the micrometer in edit mode. (CAUTION: use a pencil tip or something similar to gently push the small round buttons - they are quite small and a bit delicate.)

Press and hold the + or – buttons to change the display number to the minimum bore diameter determined earlier (example; 2.9). Caution: Pushing the + or – buttons and holding in place will cause the numbers to scroll automatically. The numbers will count slowly at first and once 0.010” has been counted off the scrolling speed will pick dramatically.

After you have reached the desired number in the display, press the set/on button twice quickly to exit the edit mode. “Set” should no longer be flashing in the display. The micrometer is now ready for use.

CAUTION: AFTER MICROMETER SET-UP IS COMPLETE, DO NOT PUSH SET/ON BUTTON AGAIN. PUSHING THE SET/ON BUTTON DURING USE WILL RETURN THE DISPLAY TO THE ORIGINAL MINIMUM BORE DIAMETER. THE ONLY TIME YOU SHOULD USE THE SET/ON BUTTON AGAIN IS TO- A. To shut micrometer off at which time you push and hold the button or B. to turn micrometer display back on at which time you push button one time. The display will then show the last reading before micrometer was shut off.

CAUTION: DO NOT BACK THE THIMBLE ALL THE WAY OUT TO THE END OF IT’S TRAVEL. ONCE THE THIMBLE IS BACKED ALL THE WAY OUT, IT WILL NO LONGER ROTATE PROPERLY AND THE DIGITAL HEAD WILL NEED TO BE REPLACED.

Micrometer is calibrated in inch mode. If metric is desired, press and hold in/mm/ABS button until mode changes to metric (approximately 3-4 seconds). A quick press of the in/mm/ABS button will put micrometer in ABS mode: 0.000, with another quick press returning it to initial setting.

Set up the cutter head and bore a set up hole. Measure the bore accurately. Set the digital display to this bore dimension and then -

Loosen the set screw holding the large diameter anvil. Slide the anvil back out of the way.



Place the tool holder used to bore the hole into the micrometer frame. Slide the location nub on the back of the tool holder gently up against the end of the digital micrometer shaft.



Slide the large diameter anvil up until it touches the end of the cutting tip of the tool holder. Tighten the set screw.



Back the digital micrometer shaft off, then bring it up to touch the tool holder and recheck that the numbers in the display are the same as the numbers previously shown.



The micrometer is now set up for use with this cutter head.

Note: this procedure must be repeated to set the micrometer to a different cutter head. The micrometer can only be set to one cutter head at a time.

To shut off micrometer press and hold set/on button until screen goes blank or let micrometer set until display disappears.

With initial setting of micrometer it is recommended that you use the procedure detailed below in the event you think you have size problems.



Procedure:

The short vertical lines that cross the horizontal scale on the micrometer sleeve are reference marks. Set the zero on the micrometer thimble even with the first vertical line and note the size shown in the digital display. Record this size for future reference. Now follow the same procedure for each line and record the sizes. At any time you feel your micrometer is reading incorrectly, you can quickly refer to the recorded size of the line closest to the range you are using and check that the micrometer is still accurate.

This page intentionally left blank

TROUBLESHOOTING

Please visit the service tab of our web page at Send a Service Request www.rottlermfg.com or contact the Rottler Factory Service at service@rottlermfg.com for assistance and your service request.

You may also call Rottler at 1-800-452-0534 or 1-253-872-7050

Please ensure you have the Machine Model and Serial Number available when contacting Rottler for Service

This page intentionally left blank

MACHINE PARTS

Contents

Rottler Replacement and Specialty Inserts.....	8-1
GENERAL INFORMATION.....	8-1
Tool Nose Radius	8-1
Edge Preparation.....	8-1
Surfacing Inserts Cutting Speed Calculation	8-2
CYLINDER BORING INSERTS	8-2
RT321 (General purpose and sleeving).....	8-2
RT322 (General purpose and sleeving).....	8-3
RTS321 (Steel Cutting).....	8-3
RTS322 (Steel Cutting).....	8-3
RT211 (General purpose and sleeving)	8-4
RT212 (General purpose and sleeving).....	8-4
RT321F (Precision Counterboring and Finishing).....	8-4
RT322F (Precision Counterboring and Finishing).....	8-4
RT211F (Precision Counterboring and Finishing).....	8-5
RT212F (Precision Counterboring and Finishing).....	8-5
RS322 (High speed oversize through boring).....	8-5
6301E (High speed oversize through boring)	8-5
501-29-6K (High speed aluminum boring).....	8-6
511-29-20E (Steel boring).....	8-6
SURFACING INSERTS.....	8-6
6303B.....	8-6
6303M.....	8-6
6303U.....	8-6

6303K.....	8-7
RS322.....	8-7
6301J.....	8-7
6303V	8-7
1/2" (12.70mm) SURFACING INSERTS	8-7
6303P	8-7
6303Q	8-7
6864E	8-8
Bi-metal Surfacing.....	8-8
6303S	8-8
6303U	8-8
INSERTS FOR SHELL MILLING CUTTERHEADS.....	8-10
6514T	8-10
MAIN LINE BORING INSERTS	8-10
CONNECTING ROD INSERTS.....	8-10
Machine Parts	8-11
F88S Front View:	8-11
F88S Left Side View:	8-12
F88S Right Side View:.....	8-13
F88S Rear View:.....	8-14
F85 Front View:.....	8-15
F85S Rear View:.....	8-16
F84S Rear View:.....	8-17
F85S – F84S Right Side View:	8-18
F85S – F84S Left Side View:.....	8-19
Air Control Door:	8-20
Air Control Tower:	8-21

Electrical Enclosure	8-22
Right side Spindle Base:	8-23
Left Side Spindle Base:.....	8-24
Spindle Base Top View:	8-25
Spindle Base Section A-A:.....	8-26
Spindle Base Section B-B:.....	8-27
Spindle Base Section C-C:.....	8-28
Spindle Base Section D-D:	8-29
Spindle Base Section E-E:	8-30
Spindle Base Section F-F:.....	8-31
F88S Tower Assembly:.....	8-32
F88S Motor Assembly:.....	8-33
F85S / F84S Motor Assembly:	8-34
Top Plate Assembly:.....	8-35
Centering Gear Housing:.....	8-36
Auto Centering Motor and Clutch:.....	8-37
Lower Spindle:.....	8-38
Draw Bar / Centering Assembly:	8-39
Upper Housing F80S (Belt Drive):.....	8-40
Pendant Swing Arm:.....	8-41
Pendant Assembly:	8-42
F84S Machine Bed:.....	8-43
F85S / F88S Machine Bed:	8-44
F88S / F85S / F84S Runway:.....	8-45
Way Cover Assembly:	8-46
Column Drive Assembly:	8-47
Column Drive Gear Housing:	8-48
6580W Chip Shield Assembly:	8-49

Rottler Replacement and Specialty Inserts

Below is a description of the cutting inserts available from Rottler. The inserts have gone through extensive performance testing. To take full advantage of the capabilities of your Rottler machine, we highly recommend Rottler cutting tools be used. Rottler machine performance can be significantly reduced if qualified tooling is not used. Using an incorrect insert can result in bore geometry inconsistency, short tool life, and poor surface finish.

Below are general guidelines. When using these inserts it is best to refer to the operator manual of the particular machine you are using. Rottler Manufacturing's latest operator manuals have more detailed information on feeds and speeds for the particular machine and cutterhead that you are using.


GENERAL INFORMATION

Rottler CBN and PCD Inserts are laser marked with our part number on one side. On single sided inserts, the part number is on the back side of the insert.

Rottler surfacing insert toolholders are designed so they can hold square and round inserts that are of the same basic size. For example, a 3/8" (9.52 mm) IC round and 3/8" (9.52 mm) IC square insert will fit into the standard 3/8" (9.52 mm) IC Rottler toolholders. IC refers to inscribed circle.

Rottler SF, F60, F80 and F90 Series surfacing cutterheads are supplied standard with Rottler 3/8" (9.52 mm) IC toolholders fitted to our surfacing heads. Optional 1/2" (12.7 mm) toolholders are interchangeable with 3/8" (9.52 mm) toolholders.

Insert breaking or chipping can be caused by several things. It can be caused by not operating the insert at the correct RPM. It is very typical for an insert to break or chip when cutting too slow. Interrupted cuts can cause an insert to break as well. When making a heavy sleeve cut in a cylinder that has been cracked it is often required to slow the RPM down to 1/2 the normal operating speed to prevent chipping of the insert.



Tool Nose Radius

The tool nose radius has an important effect on the cutting process. If you use the same feed rate per revolution on two different sized tool nose radius the larger tool radius will give a smoother finish. There are two other important characteristics of the tool radius. The larger the tool radius the stronger the cutting edge. The larger radius will hold up to interrupted cuts better than a smaller radius.

A disadvantage of a larger tool radius is that it creates more tool pressure than a smaller radius. When using long small diameter boring bars or large diameter milling cutterheads the high tool pressure of a large radius can cause chatter in the finish.

Edge Preparation

Rottler inserts have edge preparations specifically designed for proper cutting performance. Some inserts have sharp edges, some have a few ten thousandths of an inch honed edge. Others have a T land which is actually a beveled edge. Generally the sharp edge will require the minimum amount of cutting pressure but the edge will not be as strong and long lasting. The T land insert is at the opposite end of the spectrum. It generates a lot of cutting force and can create chatter. The advantage of a T land is that it is very tough. Most Rottler inserts have a honed edge which gives a good balance between cutting performance and tool life.

Surfacing Inserts Cutting Speed Calculation

Inserts are designed to cut within a speed range – SFPM. In order to convert from cutting speed to RPM, use the following formula:

$$\text{RPM} = \frac{\text{SFPM} \times 3.82}{\text{DIAMETER}}$$

SFPM = Surface Feet per Minute

RPM = Revolutions per Minute

DIAMETER in Inches

The feed rate on most Rottler machines is designated in inches / revolution. The F65M and the SFM have feed rates designated in inches / minute. It is important to adjust the inches / minute rate to obtain the correct load (inches / revolution). Following are the formulas to use. You do not have to perform this calculation with an “A” model machine

If you know the RPM and the Feed Rate per Revolution you want, use the following formula to obtain the correct Feed Rate per minute.

$$\text{FRM} = \text{RPM} \times \text{FRR}$$

FRM = Feed Rate Inches per Minute

FRR = Feed Rate Inches per Revolution

RPM = Spindle Revolutions per Minute

METRIC CONVERSION
1 inch = 25.4mm = 2.54cm
1mm = .040 inches


CYLINDER BORING INSERTS

Rottler has just completed the development of group of new triangular inserts for cylinder boring. Extensive trials were made to come up with new inserts that would outperform the older inserts. The result is a group of inserts that are the same unit cost but have 5 – 50% increased tool life. The increased tool life decreases overall operation cost to the end user.

Rottler offers either triangular or square inserts for cylinder boring, sleeving, and counter boring. Triangular inserts are excellent general purpose inserts for doing all boring, sleeving and counterboring operations.. When doing counter boring operations it is important to use a tool nose radius small enough that it will not interfere with the mating corner on the part that is installed in the counterbore.

When removing less than .060” (1.50mm) on the diameter a square insert is the most economical insert to use. The square inserts Rottler offers have 8 cutting edges. A Triangular insert only has 3 cutting edges.


RT321 (General purpose and sleeving)



A 3/8” (9.52 mm) IC triangular insert with a black ceramic coating and 1/64” (.4 mm) cutting radius. This insert is the best to use for counterboring when the small corner radius is required for clearance or when the machine is at its extended travel limits. The 1/64” (.4 mm) radius should be used when machining to a step where the mating part requires a smaller radius to eliminate an interference problem in the radius. If you are machining a long bore where the spindle must be extended towards the limits of its travel or if a long stub bar is being used, the 1/64” (.4 mm) radius will minimize the possibility of chatter. A feed rate of .002” - .005” (.05 mm - .12 mm) per revolution should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002” - .004”/rev (.02 mm-.1 mm/rev) should be used. When cutting gray cast iron use a speed in the 800 – 1200 SFPM area for best productivity and tool life.

When cutting nodular, ductile, or compacted graphite cast iron the speed should be in the 200 – 400 SFPM area – 300 RPM on a 4" (100 mm) diameter bore. Nodular, ductile, or compacted graphite cast irons, is found most often in high performance engine blocks or sleeves. When cutting these tough cast irons it is best to use a feed rate of between .002 and .005 (.05 mm and .13 mm) per revolution.

RT322 (General purpose and sleeving)



This is the same insert as RT321, except it has a 1/32" (.8 mm) radius. This insert is the best to use for heavy sleeve cutting and can also be used for general machining and counterboring. This larger radius insert will give a smoother finish for a given feed rate when sleeve cutting to allow easier sleeve fitting and closer metal to metal contact for heat transfer. It is possible to use a feed rate that is 30% faster with the RT322 compared with the RT321 and still obtain the same finish. The 1/32" (.8 mm) radius is stronger than the 1/64 (.4mm) radius of the RT321. The RT322 should always be used for heavy sleeve cuts unless the finish part requires the smaller radius for clearance or you are cutting a long bore. The larger radius creates more tool pressure than the small radius. The increased tool pressure may cause chatter in the finish if machining very long bores. A feed rate of .006" - .012" (.15 mm - .3 mm) per revolution should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002" - .004"/rev (.05 mm-.1 mm/rev) should be used. When cutting gray cast iron use a speed in the 800 – 1200 SFPM area for best productivity and tool life.

When cutting nodular, ductile, or compacted graphite cast iron the speed should be in the 200 – 400 SFPM area – 300 RPM on a 4" (100 mm) diameter bore. Nodular, ductile, or compacted graphite cast irons, is found most often in high performance engine blocks or sleeves. When cutting these tough cast irons it is best to use a feed rate of between .006" and .010" (.15 mm and .25 mm) per revolution.

RTS321 (Steel Cutting)



A 3/8" (9.52 mm) IC triangular insert with a grey ceramic coating and 1/64" (.4 mm) cutting radius. This insert is the best to for cutting steel. It has a chip breaker to break steel chips. If you are machining a long bore where the spindle must be extended towards the limits of its travel or if a long stub bar is being used, the 1/64" (.4 mm) radius will minimize the possibility of chatter. A feed rate of .002" - .005" (.05 mm - .12 mm) per revolution should be used to obtain a typical surface finish. When cutting mild steel use a speed in the 400 – 1000 SFPM area for best productivity and tool life. This insert should not be used for cutting cast iron.


Note: When using this insert it is required to use a "0" degree rake cartridge.

RTS322 (Steel Cutting)



A 3/8" (9.52 mm) IC triangular insert with a grey ceramic coating and 1/32" (.8 mm) cutting radius. This insert is the best to for cutting steel. It has a chip breaker to break steel chips. A feed rate of .003" - .008" (.05 mm - .12 mm) per revolution should be used to obtain a typical surface finish. When cutting mild steel use a speed in the 400 – 1000 SFPM area for best productivity and tool life. This insert should not be used for cutting cast iron.

Note: When using this insert it is required to use a "0" degree rake cartridge.

RT211 (General purpose and sleeving)

A 1/4" (6.35 mm) IC triangular insert with a black ceramic coating and 1/64" (.4 mm) cutting radius. The 1/64" (.4 mm) radius should be used when machining to a step where the mating part requires a smaller radius to eliminate an interference problem. If you are machining a long bore where the spindle must be extended towards the limits of its travel or if a long stub bar is being used, the 1/64" (.4 mm) radius will minimize the possibility of chatter. A feed rate of .002" - .005" (.05 mm - .12 mm) should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002" - .004"/rev. (.05 mm - .1 mm/rev) should be used. When cutting gray cast iron use a speed in the 800 – 1200 SFPM area for best productivity and tool life.

When cutting nodular, ductile, or compacted graphite cast iron the speed should be in the 200 – 400 SFPM area – 300 RPM on a 4" (100 mm) diameter bore. Nodular, ductile, or compacted graphite cast irons, is found most often in high performance engine blocks or sleeves. When cutting these tough cast irons it is best to use a feed rate of between .002 and .005 (.05 mm and .13 mm) per revolution.

RT212 (General purpose and sleeving)

This is the same insert as RT212, except it has a 1/32" (1.6 mm) radius. This larger radius insert will give a smoother finish when sleeve cutting to allow easier sleeve fitting and closer metal to metal contact for heat transfer. The 1/32" (1.6 mm) radius is stronger than the 1/64 (.8 mm) radius of the RT321. The RT322 should always be used for sleeve cuts unless the finish part requires the smaller radius for clearance or you are cutting a long bore. The larger radius creates more tool pressure than the small tool radius. The increased tool pressure will create chatter in the finish. A feed rate of .006" - .012" (.15 mm - .3 mm) per revolution should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002" - .004"/rev. (.05 mm - .1 mm/rev) should be used. When cutting gray cast iron use a speed in the 800 – 1200 SFPM area for best productivity and tool life. When cutting nodular, ductile, or compacted graphite cast iron the speed should be in the 200 – 400 SFPM area – 300 RPM on a 4" (100 mm) diameter bore. Nodular, ductile, or compacted graphite cast iron is found most often in high performance engine blocks or sleeves. When cutting these tuff cast irons it is best to use a feed rate of between .006" and .010" (.15 mm and .25 mm) per revolution.

RT321F (Precision Counterboring and Finishing)

A 3/8" (9.52 mm) IC triangular, uncoated insert with a 1/64" (.8 mm) cutting radius. Gives the best finish results when machining precision counter bores often machined in diesel engine blocks. The 1/64" (.8 mm) radius should be used when machining to a step where the mating part requires a smaller radius to eliminate an interference problem. If you are machining a long bore where the spindle must be extended towards the limits of its travel or if a long stub bar is being used, the 1/64" (.8 mm) radius will minimize the possibility of chatter. A feed rate of .002" - .005" (.05 mm - .12 mm) should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002 - .004/rev. (.05 mm - .1 mm/rev) should be used.

RT322F (Precision Counterboring and Finishing)


A 3/8" (9.52 mm) IC triangular, uncoated insert with a 1/32" (1.6 mm) cutting radius. Gives the best finish results when machining precision counter bores often machined in diesel engine blocks. A feed rate of .004" - .008" (.05 mm - .1 mm) should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002 - .004/rev. (.05 mm - .1 mm/rev) should be used. When cutting gray cast iron use a speed in the 300 - 600 SFPM area for best productivity and tool life. Tool life of this insert is significantly less than the RT322.

RT211F (Precision Counterboring and Finishing)

A 1/4" (6.35 mm) IC triangular, uncoated insert with a 1/64" (.8 mm) cutting radius. Gives the best finish results when machining precision counter bores often machined in diesel engine blocks. The 1/64" (.8 mm) radius should be used when machining to a step where the mating part requires a smaller radius to eliminate an interference problem. If you are machining a long bore where the spindle must be extended towards the limits of its travel or if a long stub bar is being used, the 1/64" (.8 mm) radius will minimize the possibility of chatter. A feed rate of .002 - .005 (.05 mm - .12 mm) should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002 - .004/rev. (.05 mm - .1 mm) should be used. When cutting gray cast iron use a speed in the 300 - 600 SFPM area for best productivity and tool life. Tool life of this insert is significantly less than the RT211

RT212F (Precision Counterboring and Finishing)

A 1/4" (6.35 mm) IC triangular insert with a gold coating and 1/32" (1.6 mm) cutting radius. The coating gives the best finish results when machining precision counter bores often machined in diesel engine blocks. A feed rate of .002 - .005 (.05 mm - .12 mm) should be used to obtain a typical surface finish. When machining large counter bores typically found in Cummins or Cat Blocks, a feed rate of .002 - .004/rev. (.05 mm - .1 mm/rev.) should be used. When cutting gray cast iron use a speed in the 300 - 800 SFPM area for best productivity and tool life. Tool life of this insert is significantly less than the RT211.RS322 (High speed oversize through boring)


RS322 (High speed oversize through boring)

A 3/8" (9.52 mm) IC, square insert with a black ceramic coating. It is used on Rottler boring machines for through boring when removing .010" - .060" (.25 mm - 1.5 mm) on the diameter. A very economical insert as it has 8 cutting edges. On a 4" (100mm) bore use 1000 - 1200 RPM and a feed rate of .008" - .012" (.2 mm - .3 mm) per rev feed rate to obtain the typical surface finish. The insert can also be used for sleeve cuts when a square step is not required. For example, when used on an F80 or F5 machine it can be run at 1000 - 1200 RPM and .005/rev (.12 mm/rev) feed rate to remove up to .200" (5 mm) on the diameter from a 4.200" (106 mm) bore.

When cutting nodular, ductile, or compacted graphite cast iron the speed should be in the 200 - 400 SFPM area - 300 RPM on a 4" (100 mm) diameter bore. Nodular, ductile, or compacted graphite cast iron is found most often in high performance engine blocks or sleeves. When cutting these tuff cast irons it is best to use a feed rate of between .006" and .010" (.15 mm and .25 mm) per revolution.

6301E (High speed oversize through boring)

This is a square 3/8" (9.52 mm) IC, 1/32" (1.6 mm) radius, double sided, CBN Insert. These inserts are intended for use on high speed boring on Rottler F80 and F60 series machines. On common cast iron blocks the RPM should be set to achieve 1000 - 2200 SFPM On harder cast irons the RPM should be reduced to obtain acceptable tool life. A feed rate of .010" - .014" (.25 mm - .36 mm) per revolution. They have exceptional long life when removing up to .040" (1.02 mm) on the diameter. They do not give good tool life on some cast irons with high sulfur content.

501-29-6K (High speed aluminum boring)

This is a 3/8" (9.52 mm) IC, triangle insert with a black diamond tip. It has a 1/32" (1.6 mm) radius. This insert is used to bore aluminum cylinders. It cannot be used to bore any other material. It is the best insert for finishing aluminum. For best tool life and finish the insert can be run from 400 – 4000 SFPM. Feed rates between .004" and .010" (.1 mm and .25 mm) should be used.

511-29-20E (Steel boring)


A 3/8" (9.52 mm) IC triangular insert with a gold coating and 1/32" (1.6 mm) cutting radius. This insert is for boring steel and ductile iron. It features a chip breaker to break-up the "string" of metal that can often form when boring steel.

SURFACING INSERTS


Rottler offers a wide variety of inserts used for surfacing. There are many applications in surfacing that include a variety of materials to be surfaced. Cylinder heads with pre-combustion chambers are particularly challenging because there are such a variety of materials used by the different cylinder head manufactures. One of the latest inserts we have tested for cutting cylinder heads with pre-combustion chambers is the 7202Z. It is probably the best for cutting a wide variety of heads with pre-combustion chambers. The 6303B is our standard for cutting a wide variety of cast iron heads. The 6303B will cut aluminum but is not ideal. The best insert for cutting aluminum is the 6303M which is a diamond insert.

When machining large cylinder blocks with larger precision depth counter bores using a 18" (450mm) or larger diameter fly cutter it is important to use a square 6301J insert. The smaller radius minimizes cutter deflection and will result in more accurate counterbore depths.


Below are the inserts commonly used on Rottler machines in surfacing/milling applications. Please read carefully..

6303B

A round 3/8" (9.52 mm) IC, double sided, CBN Insert. An excellent, long life insert for surfacing cast iron heads and blocks - round shape gives many cutting edges on each side of insert. When using a 14" (355.6 mm) cutterhead (SF, F65, F80) speeds range from 900-1200 RPM. When using an 18" (457 mm) cutterhead speeds range from 600-800 RPM.

6303M


A round 3/8" (9.52 mm) IC, single sided, PCD Insert. For use on aluminum only - heads and blocks without liners. This insert has a thin layer of PCD applied to a carbide disk. The diamond appears to be a shiny black wafer. The hardness of the diamond resists the abrasive nature of the silica in aluminum heads and blocks. RPM speeds with a 14" (355.6 mm) cutter range from 900-2000 RPM.

6303U


A round 3/8" (9.52 mm) IC, single sided, CBN Insert. This insert does an excellent job when cutting hard cast iron blocks and heads of a single material or bi-metal. This insert is the best to use when machining compacted graphite cast iron heads and blocks often found in the performance industry. RPM speeds with a 14" (355.6 mm) cutter range from 650-750 RPM.

6303K


A round, gold-colored, 3/8" (9.52 mm) IC, single sided, coated carbide insert. This is a very economical, general purpose insert for surfacing aluminum. It is advisable to use this insert for rough cutting to remove welding or contaminants before. A PCD insert should be used for the final cut to give the super fine finish required for MLS (multi layer steel) head gaskets. RPM speeds with a 14" (355.6 mm) cutterhead range from 600-1000 RPM.

RS322

A square 3/8" (9.52 mm) IC carbide insert with a very dark purple ceramic coating. This carbide insert is normally used for high speed boring. It works well as an economical insert for rough surfacing or heavy stock removal of cast iron. A CBN insert should be used for the final finish cut.


6301J

A square 3/8" (9.52 mm) IC, 1/16" (.0039 mm) radius, double sided, CBN Insert. The 1/16" (.0039 mm) radius of this insert will produce a more accurate (flatter) finish than a round insert typically used for surfacing on F80/F90 Series machines when surfacing large diesel blocks and heads which are high in nickel. The square surfacing insert is intended for F80/F90 applications where it may encounter heavier cuts and greater interrupted cuts. When using an 18" (457 mm) cutter speeds range from 600-800 RPM, and with a 14" (355.6 mm) cutter speeds range from 900-1200 RPM.

6303V

An octagonal 3/8" (9.52 mm) IC, .094" (2.4 mm) corner radius, double sided, solid CBN Insert with 16 cutting corners. The .094" (2.4mm) corner radius of this insert will produce a more accurate (flatter) finish than a round 3/8" (.52mm) or square 1/16" (1.6mm) corner radius insert typically used for surfacing on F70/F80/F90/F100 Series machines when surfacing large diesel blocks and heads which are high in nickel. The octagonal surfacing insert is intended for applications where it may encounter interrupted cuts.

When using an 18" (457 mm) cutterhead, speeds range from 600-800 RPM, and with a 14" (355.6 mm) cutter speeds range from 900-1200 RPM. The .094" (2.4mm) corner radius will allow faster feed rates compared to the 6301J square insert.

1/2" (12.70mm) SURFACING INSERTS**6303P**

A round 1/2" (12.7 mm) IC, single sided, PCD Insert. For use on aluminum only - heads and blocks without liners. This insert has a thin layer of PCD applied to the top of a carbide disk. The diamond appears to be a shiny black wafer. The hardness of the diamond resists the abrasive nature of the silica in aluminum heads and blocks. RPM speeds with a 14" (355.6 mm) cutter range from 1000-2000 RPM. Requires the purchase of 1/2" (12.7 mm) negative rake tool holders. The standard Rottler 3/8" (9.52 mm) IC tool

holders will not hold this insert.

6303Q

A round 1/2" (12.7 mm) IC double sided, CBN Insert. An excellent insert for machining cast iron heads and blocks. Round shape gives many cutting edges on each side of insert. Requires the purchase of 1/2" (12.7 mm) negative rake tool holders. The standard Rottler 3/8" (9.52 mm) IC tool holders will not hold this insert.

6864E

A five sided / five cornered insert coated carbide insert. There are a total of ten cutting corners on this inserts. This is the best insert for roughing and finishing spray weld. This is used in Rottler milling heads that are designed specifically for cutting spray weld. Currently they cannot be used in Rottler's common "flycutter" style surfacing cutterheads.

Bi-metal Surfacing**Cylinder Heads with Pre-combustion Chambers and Aluminum Blocks with Hard Sleeves**

Cylinder heads with pre-combustion chambers or aluminum engine blocks with cast iron or steel cylinder sleeves are a challenge to cut and most often require a special cutting insert and special cutting technique. There are many different material combinations so there is not one insert that works the best on all applications. Below is information to use as a guide to the best insert to use and some of the required cutting parameters.

Generally the tool life when using any of these inserts in the cutting of bi-metal surfaces will be short when compared to cutting a single material. The cost of the insert per surfacing job will be higher compared with cutting single materials. The customer must incorporate the higher insert cost into the price charged for the surfacing job.

Another excellent alternative to cutting cylinder heads with pre-combustion chambers is to remove the combustion chamber from the head, surface the cylinder head, then use the Rottler Pre-combustion Chamber Re-seating Tool to machine the combustion chamber counterbore back to OEM specification depth. It is fast and economical to use. See Bulletin C49.

Cylinder Heads with Protruding Valve Seats

Some cylinder heads have valve seats that protrude into the head gasket surface. Valve seats are made out of a wide variety of material. Some are very hard or difficult to cut when compared with the aluminum or cast iron head surface. In many cases it is best to cut the valve seat down below the head surface in a seat and guide machine. This takes a few more minutes when cutting the valve seats but it can save a lot of time and minimize tooling cost when surfacing the head.

The following inserts use Rottler 3/8" (9.52mm) Toolholders supplied with Rottler Surfacing Cutterheads;

6303S


A round 3/8" (9.52 mm) IC, single sided, CBN Insert. For use on aluminum blocks with iron liners and aluminum heads with steel pre-combustion chambers. RPM speeds with a 14" (355.6 mm) cutter range from 650-750 RPM.

6303U

A round 3/8" (9.52 mm) IC, single sided, CBN Insert. This insert does an excellent job when cutting hard cast iron blocks and heads of a single material or bi-metal. This insert is the best to use when machining compacted graphite cast iron heads and blocks often found in the performance industry. RPM speeds with a 14" (355.6 mm) cutter range from 650-750 RPM.

6303R

A round 3/8" (9.52 mm) IC, single sided, CBN Insert. For use on cast iron heads with steel pre-combustion chambers. RPM speed with a 14" (355.6 mm) cutter range from 600-700 RPM and with an 18" (457 mm) cutter range from 500-600 RPM.

6301I

A square 3/8" (9.52 mm) IC, double sided, ceramic insert. For use on cast iron heads with pre-combustion chambers. You can make one finish cut and two rough cuts with each new cutting edge. Always use a new edge when making a finish cut. Use 350-500 RPM on a 14" (355.6 mm) diameter cutterhead. See Bulletin C49.

6301V

A round 3/8" (9.52 mm) IC, double sided, ceramic insert. For use on cast iron heads with pre-combustion chambers. You can make one finish cut and two rough cuts with each new cutting edge. Always use a new edge when making a finish cut. Use 350-500 RPM on a 14" (355.6 mm) diameter cutterhead. See Bulletin C49.

**SPECIAL TOOLHOLDER AND INSERT FOR SURFACING
DIESEL ALUMINUM HEADS WITH STEEL PRE-CHAMBERS****7202X**


Fly Cutter Tool Holder Assembly uses special 7202Z insert for surfacing aluminum cylinder heads with steel pre-combustion chambers.

7202Z

Round Insert, 3/8" (9.52 mm) IC gold coated for aluminum cylinder heads with steel pre-combustion chamber. For use with 7202X tool holder only. RPM speeds with 14" (355.6 mm) cutter range from 450-550 RPM and with a 16" (406.4 mm) cutter, 400-500 RPM. Requires very slow feed rate. Surfacing these heads is a difficult operation and only the minimum amount of material can be removed per pass. For best results, rotating the insert so that a new 'corner' is used for the final pass should give good results.

INSERTS FOR SHELL MILLING CUTTERHEADS

6514T



Parallelogram configuration, carbide material. Special insert used with the Rottler 650-2-44P 4" (101.6 mm) shell mills only. Designed for general purpose applications.

MAIN LINE BORING INSERTS


Use the same RT series inserts as defined under cylinder boring. Depending on type of toolholder, either 1/4" (6.35 mm) IC or 3/8" (9.52 mm) IC inserts will be required. Commonly 1/64" (.8 mm) radius inserts are used for rough or heavy cutting, and 1/32" (.4 mm) radius inserts are used for finish boring for a smooth surface finish. In extreme conditions where the material is hard or the tool is extended and prone to chatter, use the 1/64" (.8 mm) inserts.

CONNECTING ROD INSERTS


Many customers have reported good results boring connecting rods with Rottler RT inserts. When boring small end bearings made of bronze, the RTF series of inserts should be used.

Machine Parts


F88S Front View:




F88S Left Side View:




F88S Right Side View:




F88S Rear View:




F85 Front View:




F85S Rear View:




F84S Rear View:




F85S – F84S Right Side View:




F85S – F84S Left Side View:



Air Control Door:



Air Control Tower:



Electrical Enclosure


Assembly Image and Parts List are unavailable at this time.

Please visit the service tab of our web page at Send a Service Request www.rottlermfg.com or contact the Rottler Factory Service at service@rottlermfg.com for assistance and your service request.


You may also call Rottler at 1-800-452-0534 or 1-253-872-7050

Please ensure you have the Machine Model and Serial Number available when contacting Rottler for Service


Right side Spindle Base:




Left Side Spindle Base:




Spindle Base Top View:




Spindle Base Section A-A:




Spindle Base Section B-B:




Spindle Base Section C-C:




Spindle Base Section D-D:




Spindle Base Section E-E:




Spindle Base Section F-F:




F88S Tower Assembly:




F88S Motor Assembly:




F85S / F84S Motor Assembly:




Top Plate Assembly:




Centering Gear Housing:




Auto Centering Motor and Clutch:

Lower Spindle:



Draw Bar / Centering Assembly:




ASSEMBLY PROCEDURE


- ① ASSEMBLE RING (6183A) AND SPRING (6182A) ONTO NOSE (6169M). PRESS NOSE INTO DRAWBAR (6169N). CAUTION KEYWAY (X) AND LOCKING EARS (Y) TO BE TIMED 90° AS SHOWN. INSTALL (2) 1/4 X 3/4 LONG DOWEL PINS (J)
- ② INSERT CENTERING SHAFT (6243M) FROM TOP. SLIDE ON SPLINED SPACER (6267A). PIN WITH 3/16 X 3/4 LONG ROLL PIN (K)
- ③ ASSEMBLE COLLAR (6420D), SPRING (6274D), AND SPACER (6274H), SLIDE OVER CENTERING SHAFT UNTIL COLLAR (6420D) LOCKS WITH ROLLPIN (R). LOCK IN PLACE WITH HALF DOG SET SCREW (L). SLIDE ON LOCK SPACER (6420F) AND COLLAR (6420E). (LOOKING FROM TOP) ROTATE COUNTER CLOCKWISE UNTIL STOPPED. ROTATE CENTERING SHAFT CLOCKWISE 2 TURNS. PIN WITH 3/16 X 5/8 LONG ROLL PIN (M)

6169S F-85/84
6169R F-88 DRAWBAR/CENTERING SHAFT ASSEMBLY

Upper Housing F80S (Belt Drive):



Pendant Swing Arm:



Pendant Assembly:


Assembly Image and Parts List are unavailable at this time.

Please visit the service tab of our web page at Send a Service Request www.rottermfg.com or contact the Rottler Factory Service at service@rottermfg.com for assistance and your service request.


You may also call Rottler at 1-800-452-0534 or 1-253-872-7050

Please ensure you have the Machine Model and Serial Number available when contacting Rottler for Service


F84S Machine Bed:




F85S / F88S Machine Bed:




F88S / F85S / F84S Runway:




Way Cover Assembly:




Column Drive Assembly:



Column Drive Gear Housing:



6580W Chip Shield Assembly:



OPTIONS

Optional Equipment

Optional Equipment Catalog and Parts Manual are located on the Manual CD shipped with machine.

This page intentionally left blank

MSDS

The Material Data Safety Sheets list shown in this section are the substances and materials that an operator is most likely to come in contact with while using this machine.

Other substances and materials are used in the manufacture, testing, and shipping of this machine. A complete list of the Material Data Safety Sheets of substances and materials used by Rottler Manufacturing during manufacturing, testing, and shipping is located on the Manual CD shipped with the machine. Material Data Safety Sheets are also located on the company web site: <http://www.rottlermfg.com/documentation.php>

1) Mobil Vactra Oil #2



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17 Oct 2008
 Page 1 of 8

MATERIAL SAFETY DATA SHEET

SECTION 1 PRODUCT AND COMPANY IDENTIFICATION

PRODUCT

Product Name: MOBIL VACTRA OIL NO. 2
Product Description: Base Oil and Additives
Product Code: 600494-00, 970716
Intended Use: Lubricant

COMPANY IDENTIFICATION

Supplier: EXXON MOBIL CORPORATION
 3225 GALLOWS RD.
 FAIRFAX, VA. 22037 USA

24 Hour Health Emergency: 609-737-4411
Transportation Emergency Phone: 800-424-9300
ExxonMobil Transportation No.: 281-834-3296
Product Technical Information: 800-662-4525, 800-947-9147
MSDS Internet Address: <http://www.exxon.com>, <http://www.mobil.com>

SECTION 2 COMPOSITION / INFORMATION ON INGREDIENTS

No Reportable Hazardous Substance(s) or Complex Substance(s).

SECTION 3 HAZARDS IDENTIFICATION

This material is not considered to be hazardous according to regulatory guidelines (see (M)SDS Section 15).

POTENTIAL HEALTH EFFECTS

Low order of toxicity. Excessive exposure may result in eye, skin, or respiratory irritation. High-pressure injection under skin may cause serious damage.

NFPA Hazard ID: Health: 0 Flammability: 1 Reactivity: 0
HMIS Hazard ID: Health: 0 Flammability: 1 Reactivity: 0

NOTE: This material should not be used for any other purpose than the intended use in Section 1 without expert advice. Health studies have shown that chemical exposure may cause potential human health risks which may vary from person to person.

SECTION 4 FIRST AID MEASURES

INHALATION

Remove from further exposure. For those providing assistance, avoid exposure to yourself or others. Use adequate respiratory protection. If respiratory irritation, dizziness, nausea, or unconsciousness occurs, seek immediate medical assistance. If breathing has stopped, assist ventilation with a mechanical device or use



Product Name: MOBIL VACTRA OIL NO. 2
Revision Date: 17Oct2008
Page 2 of 8

mouth-to-mouth resuscitation.

SKIN CONTACT

Wash contact areas with soap and water. If product is injected into or under the skin, or into any part of the body, regardless of the appearance of the wound or its size, the individual should be evaluated immediately by a physician as a surgical emergency. Even though initial symptoms from high pressure injection may be minimal or absent, early surgical treatment within the first few hours may significantly reduce the ultimate extent of injury.

EYE CONTACT

Flush thoroughly with water. If irritation occurs, get medical assistance.

INGESTION

First aid is normally not required. Seek medical attention if discomfort occurs.

SECTION 5 FIRE FIGHTING MEASURES

EXTINGUISHING MEDIA

Appropriate Extinguishing Media: Use water fog, foam, dry chemical or carbon dioxide (CO₂) to extinguish flames.

Inappropriate Extinguishing Media: Straight Streams of Water

FIRE FIGHTING

Fire Fighting Instructions: Evacuate area. Prevent runoff from fire control or dilution from entering streams, sewers, or drinking water supply. Firefighters should use standard protective equipment and in enclosed spaces, self-contained breathing apparatus (SCBA). Use water spray to cool fire exposed surfaces and to protect personnel.

Hazardous Combustion Products: Smoke, Fume, Aldehydes, Sulfur oxides, Incomplete combustion products, Oxides of carbon

FLAMMABILITY PROPERTIES

Flash Point [Method]: >205C (401F) [ASTM D-92]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Autoignition Temperature: N/D

SECTION 6 ACCIDENTAL RELEASE MEASURES

NOTIFICATION PROCEDURES

In the event of a spill or accidental release, notify relevant authorities in accordance with all applicable regulations. US regulations require reporting releases of this material to the environment which exceed the applicable reportable quantity or oil spills which could reach any waterway including intermittent dry creeks. The National Response Center can be reached at (800)424-8802.

SPILL MANAGEMENT



Product Name: MOBIL VACTRA OIL NO. 2
Revision Date: 17Oct2008
Page 3 of 8

Land Spill: Stop leak if you can do it without risk. Recover by pumping or with suitable absorbent.

Water Spill: Stop leak if you can do it without risk. Confine the spill immediately with booms. Warn other shipping. Remove from the surface by skimming or with suitable absorbents. Seek the advice of a specialist before using dispersants.

Water spill and land spill recommendations are based on the most likely spill scenario for this material; however, geographic conditions, wind, temperature, (and in the case of a water spill) wave and current direction and speed may greatly influence the appropriate action to be taken. For this reason, local experts should be consulted. Note: Local regulations may prescribe or limit action to be taken.

ENVIRONMENTAL PRECAUTIONS

Large Spills: Dike far ahead of liquid spill for later recovery and disposal. Prevent entry into waterways, sewers, basements or confined areas.

SECTION 7 HANDLING AND STORAGE

HANDLING

Prevent small spills and leakage to avoid slip hazard.

Static Accumulator: This material is a static accumulator.

STORAGE

Do not store in open or unlabelled containers. Keep away from incompatible materials.

SECTION 8 EXPOSURE CONTROLS / PERSONAL PROTECTION

Exposure limits/standards for materials that can be formed when handling this product: When mists / aerosols can occur, the following are recommended: 5 mg/m³ - ACGIH TLV, 10 mg/m³ - ACGIH STEL, 5 mg/m³ - OSHA PEL.

NOTE: Limits/standards shown for guidance only. Follow applicable regulations.

ENGINEERING CONTROLS

The level of protection and types of controls necessary will vary depending upon potential exposure conditions. Control measures to consider:
No special requirements under ordinary conditions of use and with adequate ventilation.

PERSONAL PROTECTION

Personal protective equipment selections vary based on potential exposure conditions such as applications, handling practices, concentration and ventilation. Information on the selection of protective equipment for use with this material, as provided below, is based upon intended, normal usage.

Respiratory Protection: If engineering controls do not maintain airborne contaminant concentrations at a level which is adequate to protect worker health, an approved respirator may be appropriate. Respirator



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17 Oct 2008
 Page 4 of 8

selection, use, and maintenance must be in accordance with regulatory requirements, if applicable. Types of respirators to be considered for this material include:

No special requirements under ordinary conditions of use and with adequate ventilation.

For high airborne concentrations, use an approved supplied-air respirator, operated in positive pressure mode. Supplied air respirators with an escape bottle may be appropriate when oxygen levels are inadequate, gas/vapor warning properties are poor, or if air purifying filter capacity/rating may be exceeded.

Hand Protection: Any specific glove information provided is based on published literature and glove manufacturer data. Glove suitability and breakthrough time will differ depending on the specific use conditions. Contact the glove manufacturer for specific advice on glove selection and breakthrough times for your use conditions. Inspect and replace worn or damaged gloves. The types of gloves to be considered for this material include:

No protection is ordinarily required under normal conditions of use.

Eye Protection: If contact is likely, safety glasses with side shields are recommended.

Skin and Body Protection: Any specific clothing information provided is based on published literature or manufacturer data. The types of clothing to be considered for this material include:

No skin protection is ordinarily required under normal conditions of use. In accordance with good industrial hygiene practices, precautions should be taken to avoid skin contact.

Specific Hygiene Measures: Always observe good personal hygiene measures, such as washing after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants. Discard contaminated clothing and footwear that cannot be cleaned. Practice good housekeeping.

ENVIRONMENTAL CONTROLS

See Sections 6, 7, 12, 13.

SECTION 9 PHYSICAL AND CHEMICAL PROPERTIES

Typical physical and chemical properties are given below. Consult the Supplier in Section 1 for additional data.

GENERAL INFORMATION

Physical State: Liquid
Color: Brown
Odor: Characteristic
Odor Threshold: N/D

IMPORTANT HEALTH, SAFETY, AND ENVIRONMENTAL INFORMATION

Relative Density (at 15 C): 0.883
Flash Point [Method]: >205C (401F) [ASTM D-92]
Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0
Autoignition Temperature: N/D
Boiling Point / Range: N/D
Vapor Density (Air = 1): > 2 at 101 kPa
Vapor Pressure: <0.013 kPa (0.1 mm Hg) at 20 C
Evaporation Rate (n-butyl acetate = 1): N/D
pH: N/A



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17Oct2008
 Page 5 of 8

Log Pow (n-Octanol/Water Partition Coefficient): >3.5
Solubility in Water: Negligible
Viscosity: 68 cSt (68 mm²/sec) at 40 C | 8.6 cSt (8.6 mm²/sec) at 100C
Oxidizing Properties: See Sections 3, 15, 16.

OTHER INFORMATION

Freezing Point: N/D
Melting Point: N/A
Pour Point: -6°C (21°F)
DMSO Extract (mineral oil only), IP-346: <3 %wt

SECTION 10 STABILITY AND REACTIVITY

STABILITY: Material is stable under normal conditions.

CONDITIONS TO AVOID: Excessive heat. High energy sources of ignition.

MATERIALS TO AVOID: Strong oxidizers

HAZARDOUS DECOMPOSITION PRODUCTS: Material does not decompose at ambient temperatures.

HAZARDOUS POLYMERIZATION: Will not occur.

SECTION 11 TOXICOLOGICAL INFORMATION

ACUTE TOXICITY

Route of Exposure	Conclusion / Remarks
Inhalation	
Toxicity (Rat): LC50 > 5000 mg/m ³	Minimally Toxic. Based on test data for structurally similar materials.
Irritation: No end point data.	Negligible hazard at ambient/normal handling temperatures. Based on assessment of the components.
Ingestion	
Toxicity (Rat): LD50 > 5000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Skin	
Toxicity (Rabbit): LD50 > 5000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Irritation (Rabbit): Data available.	Negligible irritation to skin at ambient temperatures. Based on test data for structurally similar materials.
Eye	
Irritation (Rabbit): Data available.	May cause mild, short-lasting discomfort to eyes. Based on test data for structurally similar materials.

CHRONIC/OTHER EFFECTS

Contains:

Base oil severely refined: Not carcinogenic in animal studies. Representative material passes IP-346, Modified Ames test, and/or other screening tests. Dermal and inhalation studies showed minimal effects; lung non-specific infiltration of immune cells, oil deposition and minimal granuloma formation. Not sensitizing in test animals.



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17 Oct 2008
 Page 6 of 8

Additional information is available by request.

The following ingredients are cited on the lists below: None.

	--REGULATORY LISTS SEARCHED--		
1 = NTP CARC	3 = IARC 1	5 = IARC 2B	
2 = NTP SUS	4 = IARC 2A	6 = OSHA CARC	

SECTION 12 ECOLOGICAL INFORMATION

The information given is based on data available for the material, the components of the material, and similar materials.

ECOTOXICITY

Material -- Not expected to be harmful to aquatic organisms.

MOBILITY

Base oil component -- Low solubility and floats and is expected to migrate from water to the land. Expected to partition to sediment and wastewater solids.

PERSISTENCE AND DEGRADABILITY

Biodegradation:

Base oil component -- Expected to be inherently biodegradable

BIOACCUMULATION POTENTIAL

Base oil component -- Has the potential to bioaccumulate, however metabolism or physical properties may reduce the bioconcentration or limit bioavailability.

SECTION 13 DISPOSAL CONSIDERATIONS

Disposal recommendations based on material as supplied. Disposal must be in accordance with current applicable laws and regulations, and material characteristics at time of disposal.

DISPOSAL RECOMMENDATIONS

Product is suitable for burning in an enclosed controlled burner for fuel value or disposal by supervised incineration at very high temperatures to prevent formation of undesirable combustion products.

REGULATORY DISPOSAL INFORMATION

RCRA Information: The unused product, in our opinion, is not specifically listed by the EPA as a hazardous waste (40 CFR, Part 261D), nor is it formulated to contain materials which are listed as hazardous waste. It does not exhibit the hazardous characteristics of ignitability, corrosivity or reactivity and is not formulated with contaminants as determined by the Toxicity Characteristic Leaching Procedure (TCLP). However, used product may be regulated.

Empty Container Warning Empty Container Warning (where applicable): Empty containers may contain residue and can be dangerous. Do not attempt to refill or clean containers without proper instructions. Empty drums should be



Product Name: MOBIL VACTRA OIL NO. 2
 Revision Date: 17Oct2008
 Page 7 of 8

completely drained and safely stored until appropriately reconditioned or disposed. Empty containers should be taken for recycling, recovery, or disposal through suitably qualified or licensed contractor and in accordance with governmental regulations. DO NOT PRESSURISE, CUT, WELD, BRAZE, SOLDER, DRILL, GRIND, OR EXPOSE SUCH CONTAINERS TO HEAT, FLAME, SPARKS, STATIC ELECTRICITY, OR OTHER SOURCES OF IGNITION. THEY MAY EXPLODE AND CAUSE INJURY OR DEATH.

SECTION 14 TRANSPORT INFORMATION

LAND (DOT) : Not Regulated for Land Transport

LAND (TDG) : Not Regulated for Land Transport

SEA (IMDG) : Not Regulated for Sea Transport according to IMDG-Code

AIR (IATA) : Not Regulated for Air Transport

SECTION 15 REGULATORY INFORMATION

OSHA HAZARD COMMUNICATION STANDARD: When used for its intended purposes, this material is not classified as hazardous in accordance with OSHA 29 CFR 1910.1200.

NATIONAL CHEMICAL INVENTORY LISTING: AICS, IECSC, DSL, EINECS, ENCS, KECI, PICCS, TSCA

EPCRA: This material contains no extremely hazardous substances.

SARA (311/312) REPORTABLE HAZARD CATEGORIES: None.

SARA (313) TOXIC RELEASE INVENTORY: This material contains no chemicals subject to the supplier notification requirements of the SARA 313 Toxic Release Program.

The Following Ingredients are Cited on the Lists Below: None.

--REGULATORY LISTS SEARCHED--

1 = ACGIH ALL	6 = TSCA 5a2	11 = CA P65 REPRO	16 = MN RTK
2 = ACGIH A1	7 = TSCA 5e	12 = CA RTK	17 = NJ RTK
3 = ACGIH A2	8 = TSCA 6	13 = IL RTK	18 = PA RTK
4 = OSHA Z	9 = TSCA 12b	14 = LA RTK	19 = RI RTK
5 = TSCA 4	10 = CA P65 CARC	15 = MI 293	

Code key: CARC=Carcinogen; REPRO=Reproductive

SECTION 16 OTHER INFORMATION

N/D = Not determined, N/A = Not applicable

THIS SAFETY DATA SHEET CONTAINS THE FOLLOWING REVISIONS:



Product Name: MOBIL VACTRA OIL NO. 2
Revision Date: 17Oct2008
Page 8 of 8

No revision information is available.

The information and recommendations contained herein are, to the best of ExxonMobil's knowledge and belief, accurate and reliable as of the date issued. You can contact ExxonMobil to insure that this document is the most current available from ExxonMobil. The information and recommendations are offered for the user's consideration and examination. It is the user's responsibility to satisfy itself that the product is suitable for the intended use. If buyer repackages this product, it is the user's responsibility to insure proper health, safety and other necessary information is included with and/or on the container. Appropriate warnings and safe-handling procedures should be provided to handlers and users. Alteration of this document is strictly prohibited. Except to the extent required by law, republication or retransmission of this document, in whole or in part, is not permitted. The term, "ExxonMobil" is used for convenience, and may include any one or more of ExxonMobil Chemical Company, Exxon Mobil Corporation, or any affiliates in which they directly or indirectly hold any interest.

Internal Use Only

MHC: 0B,0B,0,0,0,0

PPEC: A

DGN: 2007221XUS (1014962)

Copyright 2002 Exxon Mobil Corporation, All rights reserved